

[Manuals.plus](#) /

› [ALEASHA](#) /

› ALEASHA AL-1A69G Brushed Gold Wall Mount Pot Filler Faucet Instruction Manual

ALEASHA AL-1A69G

ALEASHA AL-1A69G Brushed Gold Wall Mount Pot Filler Faucet Instruction Manual

Model: AL-1A69G | Brand: ALEASHA

1. SAFETY INFORMATION

Please read all instructions carefully before installation and use. Keep this manual for future reference.

- This pot filler faucet is designed for **cold water use only**. Connecting it to a hot water supply may cause damage or injury.
- Ensure all water supply lines are turned off before beginning installation.
- If you are unsure about any part of the installation process, consult a qualified plumber.
- Regularly check for leaks after installation and during use.

2. PRODUCT OVERVIEW

Key Features

- **Material:** Constructed from solid brass for durability and resistance to rust and corrosion.
- **Design:** Features a dual-handle design with a 360° swivel arm for flexible positioning and easy pot filling. The folding arm retracts to save space when not in use.
- **Aerators:** Includes a standard 1.8 GPM aerator for water efficiency and splash prevention, and an additional 3.5 GPM aerator for faster filling. Both are removable for cleaning.
- **Valve Cores:** Equipped with durable brass valve cores, with a spare included for convenience.
- **Functionality:** Double closing function ensures reliable water control.

Components (What's in the Box)

WHAT ARE IN THE BOX




Image: The package includes the pot filler faucet, a pair of gloves, an installation guide, Teflon tape, a hex key, an extra 4 GPM aerator, an NPT 1/2 inch connector, a valve, a wrench, screws, and Fischer nylon anchors.

3. SPECIFICATIONS

Technical Specifications

Feature	Specification
Brand	ALEASHA
Model Name	AL-1A69G
Recommended Uses	Kitchen
Mounting Type	Wall Mount
Finish Type	Brushed
Material	Brass

Color	Brushed Gold
Number of Handles	2
Hole Count	1
Installation Type	Single Hole
Maximum Flow Rate	1.8 Gallons Per Minute (GPM)
Spout Height	2.83 Inches
Spout Reach	23.5 Inches
Item Weight	3.49 pounds
Product Dimensions	12 x 7.8 x 1.5 inches

Product Dimensions Diagram




Image: Detailed diagram illustrating the dimensions of the pot filler faucet, including the 0.9 inch (23mm) threaded connection, 2.2 inch (55mm) nipple length, 8.5 inch (215mm) height, 23.5 inch (597mm) total reach, and 12.7 inch (323mm) arm length.

4. INSTALLATION GUIDE

Before You Begin

- Turn off the main water supply to your kitchen.
- Clear the area above your stove where the faucet will be installed.
- Ensure you have the necessary tools: adjustable wrench, pipe wrench, drill, level, pencil, and the included hex key and Teflon tape.

Step-by-Step Installation

1. **Mark Mounting Position:** Position the mounting plate against the wall at the desired height above your stove. Use a level to ensure it is straight and mark the drill points with a pencil.




Image: Use the faucet's base to mark the precise location for drilling on the wall.

2. **Drill Holes and Insert Anchors:** Drill holes at the marked positions using a 15/64 inch (6mm) drill bit. Insert the provided Fischer nylon anchors into the drilled holes.




Image: Drill holes and insert the wall anchors to secure the faucet base.

3. **Prepare and Install Base:** Apply 4-5 wraps of Teflon tape to the NPT 1/2 inch threaded connection on the wall. Attach the base and gasket to the wall using the provided screws, ensuring a tight and secure fit.




Image: Apply Teflon tape to the water pipe connection and mount the base plate with the gasket.

4. **Attach Faucet Body:** Carefully align the pot filler faucet body with the installed base. Secure it by tightening the set screw with the hex key.




Image: Attach the main faucet body to the base and tighten the securing screw.

5. **Connect to Plumbing:** Ensure the 2.2 inch brass nipple is properly connected to your plumbing and the faucet. Apply Teflon tape during this connection to prevent leaks.




Image: The 2.2 inch brass nipple connects the faucet to the water pipe. Apply Teflon tape for a secure, leak-free seal.

6. **Test for Leaks:** Slowly turn on the main water supply. Check all connections for any signs of leakage. If leaks occur, turn off the water, tighten connections, and re-test.

Installation Video

Your browser does not support the video tag.

Video: An official ALEASHA HOME video demonstrating the installation process of the Wall Mount Pot Filler Faucet. This video provides a visual guide to complement the written instructions.

5. OPERATION

Using Your Pot Filler Faucet

- **Extend the Arm:** Gently pull the folding arm of the faucet to extend it over your pot on the stove. The 360° swivel joints allow for flexible positioning to reach all burners.

DUAL 360° SWING JOINTS FOR FLEXIBLE POSITIONING



Image: The dual 360° swing joints allow the faucet to extend and reach various positions over the stove, making it easy to fill pots on any burner.


- **Turn On Water:** Use the dual handles to turn on the cold water flow. The faucet is designed for fast water injection.
- **Turn Off Water:** Turn both handles to the off position to stop the water flow. The double closing function provides added security against drips.
- **Retract the Arm:** Once done, gently fold the arm back against the wall to save space and keep your cooking area clear.

6. MAINTENANCE

Cleaning and Care

- **Surface Cleaning:** Clean the faucet regularly with a soft, damp cloth and mild soap. Avoid using abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the brushed gold finish.
- **Aerator Maintenance:** If water flow becomes weak or irregular, the aerator may be clogged. Unscrew the aerator from the spout, clean any debris or mineral buildup, and rinse thoroughly before reattaching. An extra aerator (3.5 GPM) is provided for replacement or faster flow.

REMOVABLE AERATOR



Note: Designed for delivering cold water only

1.8 GPM water flow, no splashing, water-efficient
An extra aerator(3.5 GPM)for fast filling

Image: The faucet features a removable aerator. A standard 1.8 GPM aerator is installed, and an additional 3.5 GPM aerator is included for faster filling.

- **Valve Core Replacement:** A spare brass valve core is included. If you experience persistent dripping or issues with water control, the valve core may need replacement. Consult the installation guide for instructions on disassembling and reassembling the valve.

7. TROUBLESHOOTING

Common Issues and Solutions

- **Issue: Water Leakage**
Solution: Ensure all connections, especially the NPT 1/2 inch connection to the wall, are tightly secured. Verify that sufficient Teflon tape was applied during installation. Check the valve cores for any damage or improper seating.
- **Issue: Low Water Flow**
Solution: The aerator might be clogged with debris or mineral deposits. Remove and clean the aerator as described in the Maintenance section.
- **Issue: Faucet Arm Does Not Move Smoothly**
Solution: Check for any obstructions around the swivel joints. Ensure the joints are clean and free of debris.
- **Issue: Dripping from Spout**

Solution: This often indicates a worn or faulty valve core. Replace the valve core with the spare provided, following the instructions in the Maintenance section.

8. WARRANTY AND SUPPORT

Warranty Information

The ALEASHA AL-1A69G Pot Filler Faucet comes with a **5-year limited warranty**. This warranty covers manufacturing defects and ensures the product is free from material and workmanship flaws under normal use.

Additionally, the product is covered by a **90-day return policy** from the date of purchase.

Customer Support

For any questions, technical assistance, or warranty claims, please contact ALEASHA customer support. Refer to your purchase documentation for specific contact details or visit the official ALEASHA website.