

[Manuals.plus](#) /

› [ZONEKIZ](#) /

› ZONEKIZ Children's Desk and Chair Set (Model 312-107V80WT) - User Manual

ZONEKIZ 312-107V80WT

ZONEKIZ Children's Desk and Chair Set (Model 312-107V80WT) - User Manual

Brand: ZONEKIZ | Model: 312-107V80WT

INTRODUCTION

This manual provides essential instructions for the assembly, operation, and maintenance of your ZONEKIZ Children's Desk and Chair Set. Designed for children aged 5-8 years, this set offers a comfortable and functional space for various activities such as writing, reading, drawing, and playing. Please read these instructions carefully before assembly and use to ensure safe and optimal performance of the product.

Safety Information

- Always supervise children when using the desk and chair.
- Ensure all screws and fasteners are securely tightened before use and periodically check for looseness.
- Do not allow children to climb on the desk or chair.
- Keep small parts away from young children during assembly to prevent choking hazards.
- Place the furniture on a flat, stable surface.

PACKAGE CONTENTS

Before beginning assembly, please verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- 1x Children's Desk
- 1x Matching Chair
- 1x Hardware Pack (screws, dowels, etc.)
- 1x Assembly Manual (illustrated)



Figure 1: Complete ZONEKIZ Children's Desk and Chair Set.

SETUP AND ASSEMBLY INSTRUCTIONS

The ZONEKIZ Children's Desk and Chair Set requires assembly. An illustrated assembly manual is included in the package for easy and quick setup. It is recommended that one person performs the assembly.

Before You Begin:

- Clear a spacious area for assembly.
- Lay out all components and hardware.
- Refer to the included illustrated manual for detailed step-by-step instructions.
- Tools for assembly are not included and may be required (e.g., screwdriver).

General Assembly Steps:

1. Identify all parts according to the parts list in the assembly manual.
2. Attach the main desk panels using the provided hardware.
3. Assemble the chair components, ensuring a stable structure.
4. Install the storage shelves, sliding tray, and drawer.
5. Secure all connections firmly. Do not overtighten screws.
6. Once assembled, ensure the desk and chair are stable and all parts are correctly aligned.




Figure 2: Product dimensions and structural overview for assembly.

OPERATING INSTRUCTIONS

The ZONEKIZ Children's Desk and Chair Set is designed for versatile use, providing a dedicated space for your child's activities.

Using the Desk:

- **Work Surface:** The main desktop provides ample space for writing, drawing, reading, and other creative tasks.

- **Sliding Tray:** A convenient sliding tray is located beneath the main desktop, ideal for storing pencils, crayons, paper, or small craft supplies. Gently pull the tray out to access its contents and push it back in when not in use.
- **Storage Shelves:** The desk features multiple open shelves and compartments for organizing books, toys, and other essentials. Arrange items neatly for easy access.
- **Drawer:** A single drawer with a handle provides enclosed storage for items you wish to keep out of sight or protect from dust. Pull the handle to open and push to close.



Figure 3: Overview of storage features.



Figure 4: Detail of the sliding tray and drawer.

Using the Chair:

- The chair is designed to fit comfortably under the desk, saving space when not in use.
- Ensure the child sits properly with their back against the chair's backrest for ergonomic support.



 Ensemble de 2 pièces

 Sûr et élégant

 Pour les enfants de 5-8 ans

 Assemblage nécessaire

UN CADEAU PARFAIT POUR VOS ENFANTS

Figure 5: Multi-functional use of the desk and chair set.

MAINTENANCE

Proper care and maintenance will extend the life of your ZONEKIZ Children's Desk and Chair Set.

- **Cleaning:** Wipe the surface with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Regular Checks:** Periodically inspect all screws and connections to ensure they remain tight. Retighten if necessary to maintain stability and safety.
- **Avoid Moisture:** Protect the furniture from excessive moisture and direct sunlight to prevent warping or discoloration.
- **Weight Limits:** Adhere to the recommended weight limits for the desk (30 kg) and chair (50 kg) to prevent damage.

TROUBLESHOOTING

If you encounter any issues with your ZONEKIZ Children's Desk and Chair Set, refer to the following common solutions:

- **Wobbly Desk/Chair:**
 - Check all assembly screws and ensure they are tightened securely.
 - Ensure the furniture is placed on a level surface.
- **Drawer/Sliding Tray Sticking:**
 - Ensure the drawer/tray is properly aligned on its runners.
 - Check for any obstructions or debris in the tracks.
- **Missing Parts:**
 - Review the package contents list and assembly manual. If parts are genuinely missing, contact customer support.

SPECIFICATIONS

Brand	ZONEKIZ
Model Number	312-107V80WT
Color	White
Material	Engineered Wood (MDF)
Desk Dimensions (L x W x H)	90 x 45 x 90 cm (35.4 x 17.7 x 35.4 inches)
Chair Dimensions (L x W x H)	35 x 31.5 x 65 cm (13.8 x 12.4 x 25.6 inches)
Tabletop Height	61 cm (24 inches)
Desk Weight Capacity	30 kg (66 lbs)
Chair Weight Capacity	50 kg (110 lbs)
Drawer Weight Capacity	3 kg (6.6 lbs)
Number of Drawers	1
Recommended Age	5-8 Years
Assembly Required	Yes (1 person recommended)

WARRANTY AND SUPPORT

For specific warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. If you require assistance with assembly, missing parts, or have any questions regarding the product, please contact ZONEKIZ customer support through your purchase platform or the official brand website. Please have your model number (**312-107V80WT**) and purchase details ready when contacting support.