

[Manuals.plus](#) /

> [iWALK](#) /

> iWALK LinkPod X Portable Charger User Manual

iWALK LPX001

iWALK LinkPod X Portable Charger User Manual

Model: LPX001

Brand: iWALK

INTRODUCTION

Thank you for choosing the iWALK LinkPod X Portable Charger. This compact and versatile power bank is designed to provide convenient and fast charging for a wide range of mobile devices, including iPhones, Samsung Galaxy phones, and AirPods. Featuring interchangeable USB-C and Lightning plugs, a 5000mAh capacity, and a clear LED power display, the LinkPod X ensures you stay powered throughout your day. This manual provides essential information on setup, operation, maintenance, and troubleshooting to help you get the most out of your device.



Image: The iWALK LinkPod X Portable Charger in purple, demonstrating its interchangeable USB-C and Lightning plugs and digital battery display.

SETUP

1. Initial Charging of the Power Bank

Before first use, fully charge your iWALK LinkPod X. Connect the provided USB-C charging cable to the power bank's USB-C input port and the other end to a compatible USB power adapter (not included). The LED display will show the charging progress, indicating 100% when fully charged.

2. Changing the Charging Plugs (X-Change Technology)

The LinkPod X features interchangeable USB-C and Lightning plugs to support various devices. Follow these steps to swap the plugs:

1. Locate the small locking/unlocking button just below the currently installed plug.
2. Slide the button to the "OFF" position (unlock).
3. Gently pull the installed plug upwards to remove it.
4. Insert the desired plug (USB-C or Lightning) into the slot, ensuring it is correctly oriented.
5. Slide the button to the "ON" position (lock) to secure the new plug in place.



Image: Visual guide demonstrating the "OFF" (unlocked) and "ON" (locked) positions for changing the interchangeable charging plugs.

The protective silicone cover also has a dedicated slot to store the extra plug when not in use, ensuring it is not lost.



Image: The iWALK LinkPod X showing its protective silicone cover and the integrated storage slot for the unused interchangeable plug.

OPERATING INSTRUCTIONS

1. Charging Your Device

Once the correct plug is installed, simply connect the iWALK LinkPod X directly to your smartphone or

other compatible device's charging port. The power bank will automatically begin charging your device. The LED display on the power bank will illuminate to show its remaining battery percentage.



Image: The iWALK LinkPod X connected to an iPhone, illustrating its compact design and how it provides power directly to the device.

2. Understanding the LED Power Display

The integrated LED display provides a real-time percentage of the power bank's remaining battery capacity. This allows you to easily monitor the power level and know when it's time to recharge the LinkPod X.

3. Fast Charging Capability

The LinkPod X supports 20W fast charging, significantly reducing the time required to charge your devices. Ensure your device also supports fast charging for optimal performance.



Image: A visual representation of the 20W fast charging feature, showing rapid charging times for compatible devices.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the power bank. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures. If storing for extended periods, ensure it is charged to about 50-70% capacity.
- **Protective Silicone Cover:** The included silicone cover helps protect the power bank from scratches and minor impacts. Ensure it is properly fitted for maximum protection.

TROUBLESHOOTING

Problem: The power bank is not charging my device.

- Ensure the correct charging plug (USB-C or Lightning) is securely installed and locked.
- Check if the power bank itself has sufficient charge (refer to the LED display).
- Try connecting the power bank to a different device to rule out a device-specific issue.
- Ensure there is no debris in the charging port of your device or the power bank.

Problem: The power bank is not charging itself.

- Verify that the USB-C charging cable is properly connected to both the power bank and the power adapter.
- Try using a different USB-C cable and/or power adapter.
- Ensure the power outlet is functional.

Problem: The LED display is not working or showing incorrect information.

- Attempt to fully charge and then discharge the power bank to recalibrate the display.
- If the issue persists, contact customer support.

SPECIFICATIONS

Feature	Detail
Model Number	LPX001

Battery Capacity	5000 Milliamp Hours (mAh)
Connector Type	USB Type C and Lightning (Interchangeable)
Product Dimensions	5 x 8 x 3 cm
Weight	250 g
Special Features	USB-C and USB-L, Digital Display, Fast Charging, Lightweight, Pocket Size, Scratch Resistant
Manufacturer	U2O GLOBAL CO.,LTD.
Country of Origin	China



Image: The back of the product packaging, detailing product specifications and manufacturer information.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the contact details below:

- **Manufacturer:** U2O GLOBAL CO.,LTD.

- **General Service Email:** service@iwalk.net
- **US/MX International Sales Email:** sales@iwalk.net
- **US/MX International Sales Phone:** +1 347 200 8459
- **UK/EU Products Ltd Email:** support@iwalk.net
- **UK/EU Products Ltd Phone:** +44 7944011697
- **EU Phone:** +48 223001980
- **Official Website:** www.iwalkworld.com/service

Please retain your proof of purchase for any warranty claims.