

BESTOPE MIX MS-C233

BESTOPE MIX 5-in-1 Hair Curler Instruction Manual

Model: MS-C233 | Brand: BESTOPE MIX

INTRODUCTION

This manual provides essential information for the safe and effective use of your BESTOPE MIX 5-in-1 Hair Curler. Please read all instructions carefully before use and retain this manual for future reference. This device is designed to help you achieve various hair styles, from tight curls to loose waves, using its interchangeable ceramic tourmaline barrels.

IMPORTANT SAFETY WARNINGS

To ensure a comfortable, pleasant, and safe experience, please observe the following guidelines:

- **Maintain Safe Distance:** The curling iron heats up significantly. Ensure it does not come too close to your skin to prevent accidental burns.
- **Wear Protective Gloves:** Always wear the insulated gloves provided with the accessories. These high-quality burn protection gloves are included for your safety.
- **Ensure Proper Power Distribution:** Avoid overloading power strips by connecting multiple high-power electrical appliances simultaneously. The curling iron has a power consumption of 100W. Pay attention to electrical safety and distribution when plugging in the device.
- **Select Correct Temperature:** The curling iron offers two temperature settings: 150°C and 210°C. Use 150°C for soft and fine hair, and 210°C for thick, coarse, and dense hair.
- **Limit Styling Time:** Do not leave the curling iron on the same section of hair for more than 10 seconds. Prolonged heat exposure can excessively damage your hair. Adhering to the 10-second limit helps ensure good curling results while protecting your hair.
- **Automatic Shut-off:** The device features a 30-minute automatic shut-off function for added safety.
- **Dual Voltage:** The curling iron supports dual voltage (110-240V), making it suitable for travel.

SETUP AND COMPONENTS

Your BESTOPE MIX 5-in-1 Hair Curler comes with multiple interchangeable barrels to create various curl types.

Alle Gelegenheiten



Image: Instructions for attaching and detaching the curling barrels. To open, rotate right. To close, rotate left.

Interchangeable Barrels:

- **32mm Barrel:** For large, loose waves and volume.
- **25mm Barrel:** For medium waves and curls.
- **9mm Barrel:** For tight, defined curls.
- **9-19mm Conical Barrel:** For varied, natural-looking curls.
- **25mm Wave Barrel (3-barrel waver):** For mermaid-style waves.

Schutzbeschichtung mit Freigegebenen Negativen Ionen



Image: Visual guide to the five interchangeable barrels and the distinct curl patterns each creates, including 25mm wave, 25mm, 32mm, 9-19mm conical, and 9mm barrels.

Attaching and Detaching Barrels:

1. Ensure the device is unplugged and completely cool before changing barrels.
2. To attach a barrel, align the barrel with the base unit and rotate it to the left until it clicks securely into place.
3. To detach a barrel, rotate it to the right until it unlocks, then gently pull it off.

OPERATING INSTRUCTIONS

Follow these steps for effective and safe hair curling:

1. **Prepare Hair:** Ensure your hair is clean, dry, and detangled.
2. **Select Barrel:** Choose the desired barrel size for your preferred curl type and attach it securely.
3. **Plug In and Power On:** Plug the device into a suitable power outlet. Turn on the curling iron.
4. **Set Temperature:** Select the appropriate temperature setting:
 - **150°C:** For fine or soft hair.

- **210°C:** For thick or coarse hair.

Schnell Einfach Meerjungfrauenwellen

3 Mal Schneller mit
Lockenstab 3 Fässern



Image: The device features PTC heating technology, allowing it to reach optimal temperature in approximately 30 seconds. Two temperature settings are available: 150°C and 210°C.

5. **Heat Up:** Allow the curling iron to heat up for approximately 30 seconds.
6. **Section Hair:** Divide your hair into manageable sections using clips.
7. **Curl Hair:** Wearing the provided heat-protective gloves, wrap a section of hair around the chosen barrel. Hold for no more than 10 seconds.
8. **Release Curl:** Gently release the hair section from the barrel.
9. **Repeat:** Continue this process for all sections of your hair.
10. **Cool Down:** After styling, turn off the device and unplug it. Allow it to cool completely before storing.



Image: Examples of hair styling using the interchangeable barrels, demonstrating how to wrap hair around a single barrel and how to use the three-barrel waver for mermaid waves.

MAINTENANCE AND CARE

Proper maintenance ensures the longevity and performance of your hair curler.

- **Cleaning:** Ensure the device is unplugged and completely cool before cleaning. Wipe the barrels and handle with a soft, damp cloth. Do not use abrasive cleaners or immerse the device in water.
- **Storage:** Store the curling iron and its barrels in a cool, dry place, away from moisture and direct sunlight. Ensure the power cord is not tightly wrapped around the device, as this can cause damage.
- **Cord Care:** The 2.5m 360° swivel power cord is designed to prevent tangling. Avoid twisting or pulling the cord excessively.



Wavy



Curly



Coils

...?

Mehrere Stile für Ihre Wahl



Image: Illustration of the barrel's protective coating, highlighting the ceramic tourmaline layer designed to distribute heat evenly and reduce frizz by emitting negative ions.

TROUBLESHOOTING

If you encounter issues with your BESTOPE MIX Hair Curler, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Not properly plugged in; power outlet issue; device malfunction.	Ensure the plug is fully inserted. Test the outlet with another appliance. If still not working, contact customer support.
Device is not heating up.	Temperature setting too low; internal heating element issue.	Check that the temperature is set correctly (150°C or 210°C). Allow 30 seconds for heating. If problem persists, contact customer support.

Problem	Possible Cause	Solution
Curls are not holding.	Incorrect temperature for hair type; hair not dry; hair section too large; not holding long enough (but not over 10s).	Ensure hair is completely dry. Use the correct temperature for your hair type. Take smaller sections of hair. Hold for up to 10 seconds.
Barrel is loose or detaches.	Barrel not securely attached.	Ensure the barrel is rotated fully to the left until it clicks into place.

SPECIFICATIONS

- **Model Number:** MS-C233
- **Brand:** BESTOPE MIX
- **Material:** Ceramic Tourmaline
- **Color:** Rose
- **Barrel Sizes:** 32mm, 25mm, 9mm, 9-19mm (conical), 25mm (wave)
- **Temperature Settings:** 150°C, 210°C
- **Max. Temperature:** 210°C
- **Heating Technology:** PTC (Positive Temperature Coefficient)
- **Heat-up Time:** Approximately 30 seconds
- **Power Source:** Corded Electric
- **Voltage:** 110-240V (Dual Voltage)
- **Power Consumption:** 100W
- **Cord Length:** 2.5 meters (360° Swivel Cord)
- **Automatic Shut-off:** 30 minutes
- **Product Dimensions:** 23.7 x 13.8 x 13.8 cm
- **Item Weight:** 1.07 Kilograms
- **Manufacturer:** Dongguan MeStar Electric Co.,LTD
- **Country of Origin:** China

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact BESTOPE MIX customer service. Keep your purchase receipt as proof of purchase for any warranty claims.

Customer Service: Please visit the official BESTOPE MIX website or contact your retailer for support contact details.