#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- , **HP** /
- > HP Multimedia Speaker DHS-5100 User Manual

#### **HP DHS-5100**

# **HP Multimedia Speaker DHS-5100 User Manual**

Comprehensive instructions for setup, operation, and maintenance.

## 1. Introduction

The HP Multimedia Speaker DHS-5100 is designed to provide a rich audio experience for computers and other compatible devices. Featuring a dual speaker design, RGB lighting, and Bluetooth 5 connectivity, these speakers offer versatile audio playback options.



Image 1: Overview of the HP Multimedia Speaker DHS-5100.

# 2. PRODUCT FEATURES

- 360° Surround Sound Effect: Designed to deliver immersive audio.
- Dual Speaker Design: Provides stereo sound output.
- Multi-Device Compatibility: Connects to various devices including computers and smartphones.
- Bluetooth® 5 Connectivity: Equipped with a high-performance Bluetooth 5.2 chip for stable wireless connections.
- RGB Light Effect: Integrated lighting to enhance the audio experience.
- USB Powered: Receives power via a USB connection.



Image 2: Diagram highlighting key features such as 2x5W power, Bluetooth 5 connectivity, and RGB light effect.

#### 3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 2 x HP Multimedia Speakers DHS-5100
- 1 x Integrated USB Power and 3.5mm Audio Cable with In-line Controller
- 1 x User Manual / Product Notice

#### 4. SETUP INSTRUCTIONS

Follow these steps to set up your HP Multimedia Speaker DHS-5100:

- 1. **Connect the Speakers:** The two speakers are connected to each other via a fixed cable. Ensure this connection is secure.
- 2. **Connect Power:** Plug the USB-A connector of the integrated cable into a powered USB port (e.g., on your computer, a USB wall adapter, or a power bank). The speakers are USB powered and do not

contain an internal battery.

- 3. **Connect Audio (AUX Mode):** If using the 3.5mm audio jack, plug it into the audio output port of your device (e.g., computer, smartphone).
- 4. Power On: Long press the 'M' (Mode) button on the in-line controller to power on the speakers.



Image 3: The dual speaker setup with the integrated cable and in-line controller.

#### 5. OPERATING INSTRUCTIONS

#### 5.1 Power On/Off

- Power On: Long press the 'M' (Mode) button on the in-line controller.
- Power Off: Long press the 'M' (Mode) button again.

## 5.2 Mode Selection (Bluetooth / AUX)

• Double press the 'M' (Mode) button on the in-line controller to switch between Bluetooth and AUX (wired) modes.

#### **5.3 Volume Control**

• Adjust the volume using the physical volume slider on the in-line controller. Note that this controls the speaker's internal volume and may not synchronize with your device's volume level.

#### 5.4 Bluetooth Pairing

To connect your device via Bluetooth:

1. Ensure the speakers are powered on and in Bluetooth mode (double press 'M' button if necessary).

- 2. On your audio device (smartphone, computer), enable Bluetooth and search for available devices.
- 3. Select "HP DHS-5100" from the list of devices to pair.
- 4. Once paired, the speakers will indicate a successful connection, and audio will play wirelessly.



Image 4: The speaker highlighting its Bluetooth 5 connectivity for seamless audio streaming.

# 5.5 RGB Light Control

The speakers feature integrated RGB lighting:

- **Change RGB Mode:** Single press the RGB button on the in-line controller to cycle through different light modes and color combinations.
- Night Light Mode: Double press the RGB button for a constant white light.
- Turn RGB Off: Long press the RGB button to turn off the lighting.



Image 5: The speakers showcasing their dynamic RGB light effects.

# 6. MAINTENANCE

To ensure the longevity and optimal performance of your speakers:

- Clean the speakers with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- Keep the speakers away from water, excessive moisture, and extreme temperatures.
- Do not attempt to disassemble or repair the speakers yourself. This may void the warranty.

# 7. TROUBLESHOOTING

If you encounter issues with your HP Multimedia Speaker DHS-5100, refer to the following common problems and solutions:

#### • No Sound:

- Ensure the speakers are powered on.
- Check that the USB power cable is securely connected to a powered port.
- Verify the volume level on both the in-line controller and your connected device.
- Confirm the correct audio mode (Bluetooth or AUX) is selected.
- If using AUX, ensure the 3.5mm audio jack is fully inserted into both the speaker cable and your device.

#### • Bluetooth Connection Issues:

• Ensure the speakers are in Bluetooth pairing mode.

- Disable and re-enable Bluetooth on your device, then attempt to re-pair.
- Move your device closer to the speakers to ensure it is within range.
- Clear previous Bluetooth pairings on your device and try connecting again.

# • RGB Lights Not Functioning:

- Ensure the speakers are powered on.
- Press the RGB button to cycle through light modes or turn them on if they were previously off.

# • Distorted or Cracking Sound:

- Reduce the volume on both the speakers and your connected device.
- Ensure audio cables are securely connected and not damaged.
- $\circ\,$  Test with a different audio source or device to isolate the problem.

# 8. SPECIFICATIONS

Model Name	HP Multimedia Speaker DHS-5100
Speaker Type	Computer Speakers
Connectivity Technology	Wireless (Bluetooth), Wired (3.5mm AUX)
Wireless Communication Technology	Bluetooth 5
Speaker Maximum Output Power	10 Watts (2 x 5W)
Audio Output Mode	Stereo
Surround Sound Channel Configuration	2.0
Power Source	USB Powered (No internal battery)
Control Method	Touch (via in-line controller buttons)
Colour	Black & Transparent
Product Dimensions	8D x 12.6W x 8H Centimeters
Item Weight	465 Grams
Indoor/Outdoor Usage	Indoor
Manufacturer	HP
Country of Origin	China

# Dependable. Compact. Powerful. Height 126 mm Width 80 mm

Image 6: Detailed dimensions of a single HP DHS-5100 speaker.

# 9. WARRANTY AND SUPPORT

The HP Multimedia Speaker DHS-5100 comes with a standard limited manufacturer's warranty. For specific warranty terms, duration, and conditions, please refer to the warranty card included in your package or visit the official HP support website.

# **Contact Support**

For technical assistance, warranty claims, or product inquiries, please contact HP customer support:

• Manufacturer: HP, Manufacturer Name Itd.

• Address: Street No. 24/4, New Delhi, India - 110011

• Contact: +91-801-000-2400

• Email: service@manufacturer.com