

Goldair GRPF-1632

Goldair GRPF-1632 Rechargeable Pedestal Fan User Manual

Model: GRPF-1632

1. INTRODUCTION

Thank you for purchasing the Goldair GRPF-1632 Rechargeable Pedestal Fan. This manual provides essential information for the safe and efficient operation, assembly, maintenance, and troubleshooting of your fan. Please read these instructions thoroughly before use and retain them for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

- Always ensure the fan is placed on a stable, level surface to prevent tipping.
- Do not insert fingers or any objects through the fan grille when the fan is operating.
- Keep the fan away from water or other liquids. Do not use in wet environments.
- Unplug the fan from the power source before cleaning, maintenance, or when not in use.
- Do not operate the fan with a damaged cord or plug. Contact qualified service personnel for repair.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Use only the charging adapter supplied with the fan.
- Do not block air openings.

3. PRODUCT OVERVIEW

The Goldair GRPF-1632 is a 16-inch rechargeable pedestal fan designed for versatile cooling. It features a robust construction, multiple speed settings, and an adjustable head for directional airflow. Its rechargeable

battery provides cordless operation, enhancing portability.



This image displays the complete Goldair Rechargeable Pedestal Fan. It features a white fan head with a protective grille and five blades, an adjustable silver-colored pole, a white and black control panel housing the fan's functions, and a stable black round base.

4. PACKAGE CONTENTS

- Fan Head Assembly (including blades and grilles)
- Adjustable Pedestal Pole
- Round Base
- Base Fixing Screw
- Power Adapter/Charger
- User Manual

5. SETUP AND ASSEMBLY

Follow these steps to assemble your Goldair Pedestal Fan:

- Attach the Base:** Place the pedestal pole onto the round base. Align the holes and secure the pole to the base using the provided fixing screw from underneath the base. Tighten securely.
- Mount the Fan Head:** Carefully slide the fan head assembly onto the top of the pedestal pole. Ensure it clicks into place or is secured according to the specific design (some models may have a screw or locking mechanism).
- Check Stability:** Once assembled, gently test the fan's stability on a flat surface.

6. OPERATING INSTRUCTIONS

Familiarize yourself with the control panel on the fan body:

- Power Button:** Press to turn the fan ON or OFF.
- Speed Settings:** Press the speed button repeatedly to cycle through different fan speeds (e.g., Low, Medium, High). Indicator lights will show the current speed.
- Oscillation Button:** Press to activate or deactivate the oscillation function, which allows the fan head to sweep from side to side.
- Timer Button:** If available, press to set a timer for automatic shutdown (e.g., 1 hour, 2 hours, 4 hours).
- Tilt Adjustment:** Manually adjust the angle of the fan head up or down to direct airflow as desired. Hold the fan head firmly and tilt it to the desired position.

7. CHARGING THE BATTERY

The Goldair GRPF-1632 fan is equipped with a rechargeable battery for cordless operation. To charge the fan:

1. Ensure the fan is turned OFF.
2. Connect the power adapter to the charging port on the fan body.
3. Plug the adapter into a standard electrical outlet.
4. The charging indicator light will illuminate (e.g., red for charging, green for fully charged).
5. Allow the fan to charge completely before its first cordless use. Charging time may vary.

The fan can also operate while connected to the power adapter.

8. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your fan.

- Before Cleaning:** Always unplug the fan from the power outlet and ensure it is turned off.
- Exterior Cleaning:** Wipe the exterior surfaces of the fan with a soft, damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish.
- Grille and Blades:** To clean dust from the fan blades and inside the grilles, you may need to carefully remove the front grille. Refer to the assembly instructions in reverse for safe removal. Use a soft brush or vacuum cleaner with a brush attachment to remove accumulated dust. Ensure all parts are dry before reassembling.
- Storage:** When not in use for extended periods, store the fan in a cool, dry place, preferably in its original packaging, to protect it from dust and damage.

9. TROUBLESHOOTING

If you encounter issues with your fan, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply or low battery.	Ensure the power adapter is securely plugged in and the outlet is functional. Charge the fan battery if operating wirelessly.
Weak airflow.	Fan speed is too low or grilles are obstructed.	Increase the fan speed setting. Clean any dust or debris from the front and rear grilles and blades.
Fan is noisy.	Loose parts or dust accumulation.	Ensure all assembly screws are tightened. Clean the fan blades and grilles to remove any dust buildup.
Oscillation not working.	Oscillation function is not activated.	Press the oscillation button to activate the function.

10. SPECIFICATIONS

- Brand:** Goldair
- Model Number:** GRPF-1632
- Electric Fan Design:** Floor Fan
- Blade Length:** 16 Inches
- Number of Blades:** 3
- Material:** Aluminum
- Controller Type:** Button Control
- Item Weight:** 4 kg
- Product Dimensions:** 62.8D x 13W x 56.5H centimetres
- Colour:** Multicolor (as per product specifications)

11. WARRANTY AND CUSTOMER SUPPORT

Goldair products are manufactured to high standards and are warranted against defects in materials and workmanship. For specific warranty terms and conditions, please refer to the warranty card included with your purchase or visit the official Goldair website. For technical support, spare parts, or service inquiries, please contact Goldair customer support through their official channels.