

[Manuals.plus](#) /

> [Ingco](#) /

> Ingco CVLI2001 20V Battery Operated Vacuum Cleaner Instruction Manual

Ingco CVLI2001

Ingco CVLI2001 20V Battery Operated Vacuum Cleaner Instruction Manual

Model: CVLI2001 | Brand: Ingco

INTRODUCTION

Thank you for choosing the Ingco CVLI2001 20V Battery Operated Vacuum Cleaner. This manual provides essential information for the safe operation, maintenance, and troubleshooting of your new vacuum cleaner. Please read this manual thoroughly before use and retain it for future reference.

SAFETY INSTRUCTIONS

Always observe basic safety precautions to reduce the risk of fire, electric shock, or injury when using this appliance.

- Read all instructions before operating the vacuum cleaner.
- Do not use the vacuum cleaner outdoors or on wet surfaces.
- Do not allow children to operate the vacuum cleaner. Close supervision is necessary when used near children.
- Do not pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without the dust cup and filter in place.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Disconnect the battery pack before making any adjustments, changing accessories, or storing the appliance.
- Store the vacuum cleaner indoors in a cool, dry place.

PACKAGE CONTENTS

Carefully unpack your Ingco CVLI2001 vacuum cleaner and check for the following items:

- Ingco CVLI2001 20V Battery Operated Vacuum Cleaner unit
- Crevice Nozzle
- Brush Attachment
- User Manual

Note: The 20V battery pack and charger are sold separately and are not included with this unit.



An image showing the Ingco CVLI2001 20V Battery Operated Vacuum Cleaner. The device is primarily yellow and black, featuring a compact, ergonomic design with a handle and a wrist strap. A 20V battery pack is shown attached to the base of the handle. This product is sold without the battery and charger, which are available separately.

PRODUCT OVERVIEW

Familiarize yourself with the main components of your vacuum cleaner:

- **Main Unit:** The body of the vacuum cleaner containing the motor and dust collection system.
- **Dust Cup:** Transparent container for collecting dust and debris.
- **Filter:** Located inside the dust cup, essential for trapping fine particles.
- **Power Switch:** Controls the ON/OFF function of the vacuum.
- **Battery Port:** Where the 20V battery pack connects.
- **Nozzle/Attachment Port:** For attaching the crevice nozzle or brush attachment.

SETUP

1. Battery Installation

1. Ensure the vacuum cleaner is switched OFF.
2. Align the 20V Ingco battery pack (sold separately) with the battery port on the vacuum cleaner.
3. Slide the battery pack firmly into place until it clicks, indicating a secure connection.
4. To remove, press the battery release button (if present on your battery model) and slide the battery out.

2. Attaching Accessories

1. Select the desired attachment (crevice nozzle or brush attachment).
2. Align the attachment with the nozzle port on the front of the vacuum cleaner.
3. Push the attachment firmly onto the port until it is securely in place.

OPERATING INSTRUCTIONS

1. Powering On/Off

1. Ensure a charged battery is installed.
2. To turn ON, slide the power switch to the 'I' (ON) position.
3. To turn OFF, slide the power switch to the 'O' (OFF) position.

2. Vacuuming

1. Turn on the vacuum cleaner.
2. Direct the nozzle or attached accessory towards the area to be cleaned.
3. Move the vacuum cleaner slowly over the surface to allow for effective suction.
4. For upholstery, use the brush attachment for gentle cleaning.
5. For tight spaces and corners, use the crevice nozzle.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your vacuum cleaner.

1. Emptying the Dust Cup

Empty the dust cup after each use or when the debris reaches the 'MAX' fill line.

1. Ensure the vacuum cleaner is OFF and the battery is removed.
2. Locate the dust cup release button/latch.
3. Press the release and detach the dust cup from the main unit.
4. Hold the dust cup over a waste bin and empty its contents.
5. Reattach the dust cup securely until it clicks into place.

2. Cleaning the Filter

Clean the filter regularly to maintain suction power. It is recommended to clean the filter after every 3-5 uses, or more frequently depending on usage.

1. With the dust cup removed, carefully pull out the filter assembly.
2. Tap the filter gently over a waste bin to remove loose dust.
3. If necessary, rinse the filter under cold running water. Do NOT use detergent.
4. Allow the filter to air dry completely for at least 24 hours before reinserting. Do NOT use a dryer or heat gun.

5. Once dry, place the filter back into the dust cup and reattach the dust cup to the vacuum cleaner.

3. Storage

When not in use, store the vacuum cleaner in a clean, dry place, away from direct sunlight and extreme temperatures. Ensure the battery is removed if storing for extended periods.

TROUBLESHOOTING

If you encounter issues with your vacuum cleaner, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery not installed correctly. Battery is discharged.	Ensure battery is fully inserted and clicked into place. Charge the battery pack.
Low suction power.	Dust cup is full. Filter is clogged. Nozzle/hose is blocked.	Empty the dust cup. Clean or replace the filter. Check for and remove any obstructions in the nozzle or hose.
Unusual noise during operation.	Obstruction in the fan or nozzle. Loose part.	Turn off and remove battery, then check for and remove obstructions. Contact customer support if noise persists.

SPECIFICATIONS

Technical details for the Ingco CVLI2001 20V Battery Operated Vacuum Cleaner:

Feature	Specification
Model Number	CVLI2001
Brand	Ingco
Voltage	20 Volts
Power Source	Battery Powered (Battery and Charger sold separately)
Wattage	20 watts
Item Weight	100 Grams
Product Dimensions	10 x 20 x 37 cm
Noise Level	80 dB
Special Features	Lightweight
Filter Type	Cloth
Surface Recommendation	Upholstery
Capacity	1 Liters

WARRANTY AND SUPPORT

Ingco products are manufactured to high-quality standards and are guaranteed against manufacturing defects. Please refer to your purchase documentation or the official Ingco website for specific warranty terms and conditions applicable to your region.

For technical assistance, spare parts, or warranty claims, please contact your local Ingco dealer or authorized service center. Keep your proof of purchase for warranty validation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0CL57SQJV>

More documents and user manuals: <https://manuals.plus/>