

Manuals.plus /

› Pinkfong /

› Pinkfong Baby Shark Sing & Learn Smart Phone and Book Set User Manual

Pinkfong PFBS_Sing&Learn

Pinkfong Baby Shark Sing & Learn Smart Phone and Book Set User Manual

Model: PFBS_Sing&Learn

INTRODUCTION

This manual provides instructions for the safe and proper use of your Pinkfong Baby Shark Sing & Learn Smart Phone and Book Set. This interactive educational toy is designed to engage children aged 1 to 3 years with songs, sounds, and phrases, promoting early learning and developmental skills.

SETUP

Battery Installation

1. Locate the battery compartment on the back of the smart phone toy.
2. Using a small screwdriver, open the battery compartment cover.
3. Insert three (3) AAA batteries, ensuring correct polarity (+/-). Batteries are not included.
4. Securely close the battery compartment cover with the screw.



Figure 1: Battery compartment with three AAA batteries.

Description: This image displays the back of the yellow Baby Shark smart phone toy, showing the open battery compartment. Three AAA batteries are visible inside, indicating the correct placement for power. The compartment is secured by a small screw.

Initial Power On

After installing the batteries, locate the On/Off switch on the back of the smart phone toy. Slide the switch to the "On" position to activate the toy.



Figure 2: On/Off switch location.

Description: This image highlights the On/Off switch located on the lower back of the yellow Baby Shark smart phone toy. The switch is clearly labeled with "OFF" and "ON" positions, indicating how to power the device.

Video: Product Overview and Setup

Description: This video provides a brief overview of the Pinkfong Baby Shark Sing & Learn Smart Phone and Book Set, including a demonstration of battery installation and initial use of the toy's features.

OPERATING INSTRUCTIONS

The smart phone toy features 12 press-play buttons and a Star button for interactive learning and entertainment.

Number Mode

- Press any of the 12 numbered buttons (0-9) to hear the corresponding number spoken aloud.
- Some buttons may also play sounds related to fruits, shapes, or other objects.

Song Mode

- Press the **Star button** (located at the bottom of the phone) to play 9 popular nursery rhymes.
- The Star button also activates the Baby Shark voice, providing interactive phrases.
- The toy includes an autoplay button for continuous music playback.

Enjoy children's favorite nursery rhymes, series, and more!



Pinkfong Baby Shark -
Kids' Songs & Stories
70+ Million subscribers

Includes the iconic 'Baby Shark Dance' song,
#1 Most Viewed Video on YouTube – with over 13 Billion views!




Figure 3: Smart phone features and modes.

Description: This image provides a detailed view of the Baby Shark smart phone toy, highlighting its various buttons and their functions. It illustrates the Number Mode for learning numbers and the Star button for activating Song Mode with nursery rhymes and Baby Shark phrases.

Lyrics Book

- The included mini lyrics booklet contains the words to the songs and rhymes played by the smart phone.
- Encourage children to follow along with the lyrics while the songs play.



Figure 4: Smart phone and lyrics book.

Description: This image displays the yellow Baby Shark smart phone toy next to the colorful lyrics book. The book is open to show some of the song lyrics, demonstrating how the two components work together for an enhanced learning experience.

Additional Features

- **Vibrant LED Lights:** Lights flash with sounds and music to enhance engagement.
- **Child-Friendly Speaker:** Designed for safe listening.
- **Soft Fins:** The toy features smooth and soft fins for tactile exploration.
- **Attachable Chain:** A hole is provided to attach a chain or string for convenient carrying.



Figure 5: Additional toy features.

Description: This image focuses on specific design elements of the Baby Shark smart phone toy, including its soft fins, the speaker grille, and a small hole for attaching a chain or string, illustrating its child-friendly and portable design.

MAINTENANCE

Cleaning

To clean the toy, wipe it with a soft, damp cloth. Do not immerse the toy in water or use harsh cleaning agents, as this may damage the electronic components.

Battery Replacement

When sounds become faint or lights dim, it is time to replace the batteries. Follow the battery installation steps outlined in the Setup section.

Storage

Store the toy in a cool, dry place away from direct sunlight and extreme temperatures. If the toy will not be used for an extended period, remove the batteries to prevent leakage.

TROUBLESHOOTING

- **No Sound/Lights:**

- Ensure the On/Off switch is in the "On" position.
- Check if the batteries are correctly installed and not depleted. Replace with fresh AAA batteries if necessary.

- **Intermittent Operation:**

- This may indicate low battery power. Replace the batteries.
- Ensure the battery compartment cover is securely closed.

- **Toy Automatically Turns Off:**

- The toy is designed to enter a sleep mode after 5 minutes of inactivity to conserve battery life. Press any button to reactivate it.

SPECIFICATIONS

Feature	Detail
Product Dimensions	10 x 5 x 0.04 inches
Item Weight	10.8 ounces
Model Number	PFBS_Sing&Learn
Recommended Age	12 months - 5 years
Batteries Required	3 AAA batteries (not included)
Manufacturer	The Pinkfong Company, Inc.



Figure 6: Product dimensions.

Description: This image illustrates the key dimensions of the Pinkfong Baby Shark Sing & Learn Smart Phone and Book Set, including the length, width, and height of both the book and the smart phone toy, providing a clear visual reference for its size.

WARRANTY AND SUPPORT

This product is manufactured by The Pinkfong Company, Inc. For any questions, concerns, or support regarding your Pinkfong Baby Shark Sing & Learn Smart Phone and Book Set, please refer to the manufacturer's official website or contact their customer service. Specific warranty details may vary and are typically provided with the product packaging or on the manufacturer's website.