

[Manuals.plus](#) /

> [JOY worker](#) /

> JOY worker 35" x 20" Electric Standing Desk User Manual

JOY worker GHED121D-1P-88

JOY worker 35" x 20" Electric Standing Desk User Manual

Model: GHED121D-1P-88

1. SETUP INSTRUCTIONS

The JOY worker Electric Standing Desk is designed for straightforward assembly. All necessary screws and accessories are included for a quick installation, typically completed within 15 minutes. Follow the steps below to ensure proper setup.

1.1 Unpacking and Component Check

Carefully unpack all components from the box. Verify that all parts listed in the assembly guide are present and undamaged. Refer to the image below for a visual overview of the desk dimensions and components.

Desk Dimensions



Electric Height Adjustable Standing Desk

JW-GHED121D-1P88-W

White

G.W.: 42.99lbs/19.5kg

MEAS: 40.9" x 23" x 6.1" / 104 x 58.5 x 15.5cm

Attention!

The 40.9" refers to the box size, while the desk itself is 35".



Image: Detailed dimensions of the JOY worker 35" x 20" Electric Standing Desk, showing its compact size and 176 lbs weight capacity.

1.2 Assembly Process

Begin by attaching the legs to the desktop. Ensure all connections are secure. The desk features a solid one-piece tabletop, eliminating seams for a smooth and durable surface. This design simplifies assembly compared to multi-piece desktops.



Whole-Piece Desktop

seamless, smooth & durable



Others Table Top

Uneven Top In 2 Splice Pieces
bumps and noise caused by gaps



Image: Illustration highlighting the seamless, smooth, and durable whole-piece desktop design of the JOY worker desk.

The desk is constructed with an all-steel frame, providing maximum stability and sturdiness. Ensure all screws are tightened as per the instructions to achieve the stated 176 lbs support capacity.

20% thicker than normal desks

🛡️ Increased Durability 🏠 Improved Stability ❤️ Better Aesthetics



Image: Comparison showing the 20% thicker desktop of the JOY worker desk, contributing to increased durability, improved stability, and better aesthetics.

2. OPERATING INSTRUCTIONS

The JOY worker Electric Standing Desk offers smooth and quiet height adjustment with a user-friendly digital control panel.

2.1 Height Adjustment

Transition effortlessly from sitting to standing positions. The desk can adjust from a minimum height of 28.3 inches to a maximum height of 46.5 inches at a speed of 25mm/s. The motor operates quietly, with noise levels under 50 dB, ensuring minimal disruption to your work environment.

Different Heights For all ideas

Height adjustment from 28.3" to 46.5"



Image: Visual representation of the desk's height adjustment range, from 28.3 inches to 46.5 inches, suitable for various working postures.

Ultra Quiet Design




Image: Diagram illustrating the ultra-quiet operation of the desk, with noise levels around 50dB, comparable to falling leaves and significantly quieter than normal voice.

2.2 Memory Presets

The LED screen control panel features 3 programmable memory modes. This allows you to save your preferred sitting and standing heights for quick and convenient adjustments. Simply press the corresponding memory button (1, 2, or 3) to automatically move the desk to your desired height.

Digital Control Panel

Control whatever you want




Image: Close-up of the digital control panel, showing the LED display, memory buttons (1, 2, 3), and up/down arrows for precise height adjustments.

3. MAINTENANCE

To ensure the longevity and optimal performance of your JOY worker Electric Standing Desk, regular maintenance is recommended.

- **Cleaning:** Wipe the desktop and legs with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners that could damage the finish.
- **Cable Management:** Periodically check and organize cables to prevent tangles and ensure smooth operation during height adjustments.
- **Secure Fastenings:** Ensure all screws and connections remain tight. Re-tighten if any looseness is detected.
- **Weight Limit:** Do not exceed the maximum weight recommendation of 176 lbs (80 kg) to prevent damage to the motor and frame.

For households with children, ensure the desk is securely fastened to the wall if necessary, especially considering its robust 176 lbs support capacity. Improper assembly or overloading may lead to instability.

4. TROUBLESHOOTING

If you encounter any issues with your JOY worker Electric Standing Desk, refer to the common troubleshooting steps and videos below.

4.1 General Troubleshooting

For a comprehensive guide on common issues and their solutions, please watch the official troubleshooting video provided by ERGOJOY.

Your browser does not support the video tag.

Video: Official troubleshooting guide for JOY worker standing desks, covering various error codes and solutions.

4.2 Resolving Unequal Leg Lift

If one leg of your desk is not synchronizing its lift with the other, follow the instructions in this specific troubleshooting video.

Your browser does not support the video tag.

Video: Instructions on how to resolve issues where the left leg of the standing desk is unable to synchronize its lift.

5. SPECIFICATIONS

Feature	Detail
Brand	JOY worker
Model Number	GHED121D-1P-88
Product Dimensions (D x W x H)	19.7"D x 34.65"W x 46.4"H
Minimum Height	28.3 Inches
Maximum Height	46.5 Inches
Maximum Weight Recommendation	176 Pounds (80 kg)
Material Type	Alloy Steel, Engineered Wood
Lifting Mechanism	Electric
Noise Level	Under 50 dB
Assembly Time (Estimated)	15 minutes

6. WARRANTY INFORMATION

The JOY worker Electric Standing Desk comes with a limited warranty. For specific details regarding coverage and duration, please refer to the warranty documentation included with your product packaging.

Optional protection plans are also available for extended coverage:

- 2-Year Protection Plan
- 3-Year Protection Plan

7. CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your JOY worker Electric Standing Desk, please contact the manufacturer directly. You can find contact information on the official JOY worker brand store or through the product packaging.

Visit the official JOY worker store for more information: [JOY worker Store](#)