



[Manuals.plus](#) /

› [COLAMY](#) /

› COLAMY Big and Tall Gaming Chair 91311 Instruction Manual

COLAMY 91311

COLAMY Big and Tall Gaming Chair 91311 Instruction Manual

Model: 91311

INTRODUCTION

Thank you for choosing the COLAMY Big and Tall Gaming Chair, Model 91311. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new chair. Please read these instructions carefully before use and retain them for future reference.

SAFETY INFORMATION

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Follow assembly instructions precisely. Incorrect assembly can lead to instability and injury.
- Do not stand on the chair.
- Do not use the chair as a step stool.
- Maximum weight capacity: 400 lbs (181 kg). Do not exceed this limit.
- Keep children away from moving parts during adjustment.
- Regularly check all bolts and screws to ensure they are tight.

PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present in your package.

- Backrest
- Seat Cushion
- Armrests (2)
- Base (Star Base)
- Casters (5)

- Gas Lift Cylinder
- Mechanism Plate
- Lumbar Support Pillow
- Headrest Pillow
- Hardware Pack (screws, washers, Allen key)

ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your COLAMY Gaming Chair. It is recommended to assemble the chair on a soft, clean surface to prevent damage.

1. **Attach Casters to Base:** Insert each of the five casters into the holes at the end of each leg of the star base. Push firmly until they click into place.
2. **Insert Gas Lift:** Place the gas lift cylinder into the center hole of the assembled star base.
3. **Attach Mechanism to Seat:** Align the mechanism plate with the screw holes on the underside of the seat cushion. Ensure the front of the mechanism faces the front of the seat. Secure with screws and washers using the provided Allen key.
4. **Attach Armrests:** Secure the armrests to the sides of the seat cushion using the designated screws. Do not overtighten initially to allow for minor adjustments.
5. **Connect Backrest to Seat:** Attach the backrest to the seat cushion using the screws provided. Ensure proper alignment before tightening all screws on the armrests and backrest.
6. **Place Assembled Top onto Gas Lift:** Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring it is centered and stable.
7. **Attach Pillows:** Position the lumbar support pillow and headrest pillow as desired for comfort. The headrest typically attaches via straps over the top of the backrest.



Image: Fully assembled COLAMY Gaming Chair in a typical gaming environment.

OPERATING INSTRUCTIONS

Your COLAMY Gaming Chair offers several adjustable features for personalized comfort.

1. Seat Height Adjustment

To adjust the seat height, locate the lever on the right side, beneath the seat. Pull the lever up while seated to lower the chair, or pull it up while standing to raise the chair. Release the lever to lock the height.

Adjustable Reclining Chair



Image: Visual representation of seat height adjustment and recline angles (90-150 degrees).

2. Backrest Recline Function

The backrest can be reclined between 90 and 150 degrees. Pull the recline lever, typically on the right side of the seat, and lean back to your desired angle. Release the lever to lock the backrest in position.

3. 4D Armrest Adjustments

The 4D armrests offer multiple adjustment options:

- **Height Adjustment:** Press the button on the side of the armrest and move it up or down.
- **Forward/Backward:** Slide the armrest pad forward or backward.
- **Left/Right:** Slide the armrest pad left or right.
- **Rotation:** Rotate the armrest pad inward or outward.

■ Big Tall 4D Backrest Wrapped Support Immersive Gaming Experience



Image: Detailed view of the 4D adjustable armrests and their range of motion.

4. Tilt Tension Adjustment

The tilt tension knob, located underneath the seat, allows you to control the resistance when reclining. Turn clockwise to increase tension (making it harder to recline) and counter-clockwise to decrease tension (making it easier to recline).

5. 360-Degree Swivel

The chair features a 360-degree swivel for easy movement and access to your workspace.

Your browser does not support the video tag.

Video: Demonstration of the COLAMY Gaming Chair's adjustable features, including armrest movement, seat height, and recline function.

MAINTENANCE

- **Cleaning:** Wipe clean with a damp cloth. For tougher stains, use a mild soap solution and wipe dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Hardware Check:** Periodically check all screws and bolts to ensure they are securely tightened. Retighten as necessary to maintain stability.

- **Caster Care:** Keep casters free of hair and debris to ensure smooth rolling.
- **Material Care:** The chair is made of PU leather and carbon fiber leather. Avoid prolonged exposure to direct sunlight or extreme temperatures to prevent material degradation.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair is wobbly or unstable.	Loose screws or incorrect assembly.	Check and tighten all screws and bolts. Ensure the gas lift is properly seated in the base.
Chair does not adjust height.	Gas lift cylinder malfunction or lever not engaged.	Ensure the height adjustment lever is fully engaged. If the issue persists, the gas lift may need replacement.
Backrest does not recline or lock.	Recline mechanism issue or lever not engaged.	Verify the recline lever is fully engaged. Check for any obstructions in the mechanism.
Casters do not roll smoothly.	Debris caught in casters or damaged casters.	Clean any hair or debris from the caster wheels. If damaged, casters may need replacement.
Creaking or noise when moving.	Loose connections or friction between parts.	Tighten all screws. Apply a small amount of silicone lubricant to moving parts if necessary, avoiding contact with upholstery.

SPECIFICATIONS


Feature	Detail
Brand	COLAMY
Model Name	91311
Color	Black
Material	Leather (PU Leather, Carbon Fiber Leather), Foam, Polyester, Metal Frame
Product Dimensions (D x W x H)	24.8"D x 29.53"W x 49.21"H
Item Weight	51.81 Pounds
Maximum Weight Recommendation	400 Pounds
Adjustable Features	Adjustable Height, 4D Armrests, Reclining Backrest (90-150 degrees), Tilt Tension, 360-degree Swivel

Feature	Detail
Included Components	Casters, Lumbar Support, Headrest
Gas Lift	Class 4 SGS Certified Gas Cylinder
Base	Heavy Duty Metal Base
Casters	Scratch & Noise-Free PU Casters
Frame Material	1.5MM thickness coated steel frame
Seat Cushion	High-density molded foam, extra thick and wide padded seat



Image: Diagram illustrating the full dimensions of the COLAMY Gaming Chair.

■ Material Defines Quality



- **Class 4 SGS Certified Gas Cylinder**
More Smooth and Safer

- **Heavy Duty Metal Base**
More Aesthetic and Durable



- **Scratch&Noise-Free PU Caster**
Pass 100,000 Rolling Durability Test



Image: Illustration of key components including the Class 4 gas cylinder, heavy-duty metal base, and scratch-free PU casters.

■ Invest In Quality Long Lasting Comfort



■ 1.5MM thickness
coated steel Frame

■ High density
Molded Foam

■ Extra thick and wide
padded seat cushion

Image: Cross-section highlighting the 1.5mm thick steel frame and high-density molded foam in the seat cushion.

WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please contact COLAMY customer service. Refer to your purchase documentation or the official COLAMY website for contact details.

Website: [COLAMY Official Store](#)