

[Manuals.plus](#) /

› [THRONMAX](#) /

› THRONMAX Space C2 Wireless AIR 2.4 Microphone Kit User Manual

THRONMAX SPACE C2

THRONMAX Space C2 Wireless AIR 2.4 Microphone Kit User Manual

Model: SPACE C2

INTRODUCTION

The THRONMAX Space C2 Wireless AIR 2.4 Microphone Kit provides exceptional audio capture through its Series IV 2.4GHz digital wireless transmission. This kit is designed for clear and reliable sound recording across various platforms, including cameras and mobile devices. This manual will guide you through the setup, operation, and maintenance of your microphone kit.

PACKAGE CONTENTS

Upon opening your THRONMAX Space C2 Wireless AIR 2.4 Microphone Kit, you should find the following items:

- Two (2) Wireless Microphones (Transmitters)
- One (1) Wireless Receiver
- Data Cable (USB Type-C)
- User Manual
- Windshields (Furry)
- Various adapter cables for different devices (e.g., 3.5mm jack, USB-C, Lightning)
- Carrying Case

PRODUCT COMPONENTS

The THRONMAX Space C2 kit includes two transmitters (microphones) and one receiver, all featuring a uniform, compact design. The receiver is distinguishable by its display screen.



Image: The THRONMAX Space C2 Wireless Microphone Kit, showing two transmitters and one receiver. The units are black, cylindrical, and feature a ribbed top section. The receiver has a small display screen.

Transmitters (Microphones)

Each transmitter is equipped with a microphone, a power button, and a USB Type-C port for charging. They are designed to be discreetly clipped onto clothing.



Image: A close-up of one of the THRONMAX Space C2 transmitters clipped to the collar of a dark blue shirt, demonstrating its compact and wearable design. Blue indicator lights are visible.

Receiver

The receiver unit features a small display screen that shows important information such as DB levels, connection status, and battery life for both connected microphones. It also has control buttons for adjusting settings and a USB Type-C port for connectivity and charging.



Image: The THRONMAX Space C2 Wireless Microphone Kit, highlighting the receiver unit with its active display showing signal strength and battery indicators for two channels.

SETUP GUIDE

The THRONMAX Space C2 is designed for plug-and-play simplicity with minimal setup required.

1. Charging

Before first use, ensure all units (transmitters and receiver) are fully charged using the provided USB Type-C data cable. The USB Type-C port is located at the bottom of each unit.

2. Connecting the Receiver

The receiver can be connected to various recording devices:

- **To Cameras (DSLRs, Mirrorless):** Mount the receiver onto your camera's hot shoe. Connect the receiver to your camera's microphone input (typically a 3.5mm jack) using the appropriate adapter cable.
- **To Mobile Devices (Smartphones, Tablets):** Connect the receiver to your device's port (USB-C for

Android/newer iPhones, Lightning for older iPhones) using the relevant adapter cable.

3. Powering On & Pairing

Press and hold the power button on each transmitter and the receiver to turn them on. The units are designed to automatically pair. The receiver's screen will display connection status and audio levels for each active microphone.

OPERATING INSTRUCTIONS

1. Wearing the Microphones

Clip the transmitters onto your clothing, ensuring the microphone grille is facing towards your mouth for optimal sound capture. The compact design allows for discreet placement.

2. Audio Monitoring and Adjustment

The receiver's display provides real-time monitoring of audio levels (DB levels) for both channels. Use the control buttons on the receiver to adjust gain or toggle connections as needed. Each microphone records on a single mono track, which can be processed as dual mono or stereo in post-production.

3. Omnidirectional Pickup Pattern

The microphones feature an omnidirectional pickup pattern, meaning they capture sound equally from all directions. This is ideal for lavalier use where the microphone's exact orientation might vary.

4. Battery Management

The THRONMAX Space C2 offers approximately 8 hours of battery life per transmitter. If one microphone runs out of battery during a long recording session, you can swap it with the second fully charged microphone to extend your recording time without interruption.

SPECIFICATIONS

| Feature | Detail |
|-------------------------|---|
| Brand | THRONMAX |
| Model Number | SPACE C2 |
| Connectivity Technology | UHF (2.4GHz Digital Wireless) |
| Connector Type | USB Type-C |
| Special Feature | Volume Control |
| Compatible Devices | Camera, Smartphones (via adapters) |
| Color | White |
| Polar Pattern | Unidirectional (Omnidirectional for lavalier use) |
| Item Weight | 77 Grams |
| Microphone Form Factor | Lavalier |

| | |
|---------------------|---|
| Power Source | Corded Electric (Rechargeable Lithium Ion batteries included) |
| Number of Batteries | 3 Lithium Ion batteries required (included) |
| Number of Channels | 1 (Dual mono recording supported) |
| Recommended Uses | Video Conference, Video Recording, Voice Recording |
| UPC | 850025244664 |

MAINTENANCE

To ensure the longevity and optimal performance of your THRONMAX Space C2 Wireless Microphone Kit:

- Keep the units clean and free from dust and moisture. Use a soft, dry cloth for cleaning.
- Store the kit in its provided carrying case when not in use to protect it from physical damage.
- Avoid exposing the units to extreme temperatures or direct sunlight.
- Regularly charge the units to maintain battery health, even if not used frequently.

TROUBLESHOOTING

If you encounter issues with your THRONMAX Space C2 Wireless Microphone Kit, consider the following:

- **No Audio/Poor Audio Quality:** Ensure all units are fully charged and powered on. Verify that the receiver is correctly connected to your recording device's microphone input. Check the DB levels on the receiver's screen. Ensure microphones are positioned correctly.
- **Connection Issues:** Confirm that both transmitters and the receiver are within range (2.4GHz digital wireless). Power cycle all units (turn off and on again) to re-establish pairing.
- **Buttons Not Responding:** If buttons feel 'mushy' or do not pop back out, gently press them multiple times. If the issue persists, contact customer support.

WARRANTY AND SUPPORT

The THRONMAX Space C2 Wireless AIR 2.4 Microphone Kit comes with a 1-year manufacturer warranty. For further support, product information, or to explore other THRONMAX products, please visit the [THRONMAX Official Store](#).