

Pro60

TWS Pro60 Wireless Bluetooth Headset User Manual

Model: Pro60 | Brand: Generic

1. INTRODUCTION

Thank you for choosing the TWS Pro60 Wireless Bluetooth Headset. This manual provides detailed instructions on how to set up, operate, and maintain your new earbuds, ensuring you get the best possible audio experience. The Pro60 features advanced Bluetooth 5.3 technology for stable and fast connections, HiFi sound quality with deep bass, and an IPX7 waterproof rating, making them ideal for various activities.



Figure 1.1: TWS Pro60 Wireless Bluetooth Earbuds in their charging case, showcasing their sleek black design with green accents.

2. WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- Bluetooth Earbuds (TWS Pro60)
- Wireless Charging Case
- USB Charging Cable
- User Manual

3. SETUP GUIDE

3.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. The charging time for the earbuds is approximately 1 hour.

1. Place the earbuds into the charging case, ensuring they are correctly seated.
2. Connect the provided USB charging cable to the charging port on the case and plug the other end into a USB power source (e.g., computer, wall adapter).
3. The indicator lights on the case and earbuds will show charging status. They will typically turn off or change color when fully charged.



Figure 3.1: The TWS Pro60 charging case and earbuds, highlighting the extended battery life of up to 24 hours with the charging case, while individual earbuds offer approximately 6 hours of playback.

3.2 Pairing with Your Device

The TWS Pro60 earbuds feature one-step auto-pairing for convenience.

1. Ensure Bluetooth is enabled on your smartphone, tablet, or other compatible device.
2. Open the charging case. The earbuds will automatically power on and enter pairing mode.
3. On your device, search for Bluetooth devices and select "PRO60" from the list.
4. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.

The earbuds support Single Mode (using one earbud), Binaural Mode (using both earbuds for stereo sound), and Sharing Mode (allowing two people to listen to the same audio from one device, each with one earbud).




Figure 3.2: Illustration of the one-step auto-pairing process for the TWS Pro60 earbuds, showing how they connect to a device via Bluetooth.

4. OPERATING INSTRUCTIONS

4.1 Touch Controls

The TWS Pro60 earbuds feature intuitive touch controls for easy management of music and calls.

Action	Control
Play/Pause Music	Tap once on either earbud
Answer/End Call	Tap once on either earbud
Hang Up Call	Tap once on either earbud during a call
Next Song	Double-tap the Right earbud
Previous Song	Double-tap the Left earbud
Volume Up	Hold the Right earbud

Action	Control
Volume Down	Hold the Left earbud
Activate Voice Assistant	Triple-tap either earbud



Figure 4.1: Diagram illustrating the ergonomic design and smart touch controls of the TWS Pro60 earbuds, showing various tap and hold functions.

4.2 Wearing the Earbuds

The earbuds are ergonomically designed for a secure and comfortable fit. Gently insert each earbud into your ear canal and rotate slightly until it feels snug and stable. This ensures optimal sound quality and noise isolation.

4.3 Sound Quality and Features

Experience enhanced bass stereo sound powered by 13mm dual coil dynamic drivers and a titanium membrane shock speaker. The earbuds feature an intelligent denosing engine and reverse noise cancelling for a clear audio experience.



Figure 4.2: Detailed view of the TWS Pro60's internal components, illustrating the advanced speaker technology that delivers Super Hi-Fi Sound Quality.

4.4 Water Resistance

The TWS Pro60 earbuds boast an IPX7 waterproof rating, meaning they are protected against immersion in water up to 1 meter for 30 minutes. This makes them suitable for workouts and use in various weather conditions. However, they are not designed for swimming or prolonged submersion.

4.5 Device Compatibility

The TWS Pro60 earbuds are compatible with most Bluetooth-enabled devices, including smartphones, tablets, laptops, and desktops.



Figure 4.3: The TWS Pro60 earbuds demonstrating compatibility with a wide range of devices, including laptops, desktops, smartphones, and tablets.

5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your TWS Pro60 earbuds.

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.
- **Charging Contacts:** Ensure the charging contacts on both the earbuds and the case are clean and free of debris to maintain a good connection.
- **Water Exposure:** While IPX7 rated, always dry the earbuds thoroughly after exposure to water or sweat before placing them back in the charging case.

6. TROUBLESHOOTING

If you encounter any issues with your TWS Pro60 earbuds, refer to the following common problems and solutions:

- **Earbuds not pairing or connecting:**

- Ensure both earbuds are fully charged.
- Make sure Bluetooth is enabled on your device.
- Place earbuds back into the charging case, close the lid, wait a few seconds, then open the lid and try pairing again.
- Forget "PRO60" from your device's Bluetooth settings and try to pair again.
- Ensure no other Bluetooth devices are interfering.

- **No sound from one or both earbuds:**

- Check the volume level on both your device and the earbuds.
- Ensure earbuds are properly connected to your device.
- Try resetting the earbuds (refer to manufacturer's specific reset instructions if available, otherwise, place in case and reconnect).

- **Charging issues:**

- Verify the charging cable is securely connected to both the case and the power source.
- Ensure the charging contacts on the earbuds and case are clean.
- Try a different USB port or power adapter.

- **Poor sound quality or disconnections:**

- Move closer to your connected device to reduce interference. The Bluetooth range is approximately 15 meters.
- Ensure there are no physical obstructions between the earbuds and your device.
- Check for any firmware updates for your device or earbuds (if applicable).

7. SPECIFICATIONS

Key technical specifications for the TWS Pro60 Wireless Bluetooth Headset:

Feature	Detail
Model Name	TWS Pro60
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.3
Bluetooth Range	15 Meters
Battery Life (Earbuds)	6 Hours
Charging Time	1 Hour
Water Resistance Level	IPX7 (Water Resistant)
Control Type	Touch Control
Noise Control	Active Noise Cancellation (Denosing Engine)
Earpiece Shape	Bud (In Ear)
Item Weight	1.48 Ounces
Material	Composite

Feature	Detail
Compatible Devices	Laptops, Smart Phones
Recommended Uses	Calling, Cycling, Exercising, Running, Travel

8. WARRANTY AND SUPPORT

Information regarding product warranty and customer support was not provided in the available data. For details on warranty coverage, technical support, or service inquiries, please refer to the product packaging, any included warranty cards, or visit the manufacturer's official website.

Manufacturer: TWS

