

**Peg Perego IKAC0038--IN31**

# Peg Perego Tatamia Kit Instruction Manual

Soft Seat Cover & Play Bar Accessory

## 1. INTRODUCTION

Thank you for choosing the Peg Perego Tatamia Kit. This accessory kit is designed to enhance the comfort and entertainment for your child when using the Peg Perego Tatamia high chair. This manual provides important information regarding the assembly, use, maintenance, and safety of your new Tatamia Kit.

Please read this instruction manual carefully before installation and use. Keep this manual for future reference.

## 2. SAFETY INFORMATION

**WARNING:**

- Always ensure the Tatamia Kit is securely attached to the Peg Perego Tatamia high chair before placing a child in it.
- Never leave a child unattended in the high chair, even with the kit installed. Adult supervision is always required.
- Regularly inspect all components for wear, damage, or loose parts. Discontinue use if any damage is found.
- Keep all packaging materials away from children to prevent suffocation.
- This kit is designed exclusively for use with the Peg Perego Tatamia high chair. Do not attempt to use it with other high chair models.

## 3. PACKAGE CONTENTS

Before proceeding with assembly, please verify that all components are present in the package:

- 1 x Soft-Touch Seat Cover (Azzurro - Light Blue)

- 1 x Play Bar with attached toys



Image 3.1: Contents of the Peg Perego Tatamia Kit, showing the soft seat cover and the detachable play bar with three hanging toys.

## 4. SETUP

Follow these steps to install the Tatamia Kit onto your Peg Perego Tatamia high chair:

### 4.1. Installing the Soft-Touch Seat Cover

1. Ensure your Tatamia high chair is clean and free of debris.
2. Carefully place the Soft-Touch Seat Cover over the existing high chair seat.
3. Align the openings in the seat cover with the high chair's harness straps and any other attachment points.
4. Thread the high chair's harness straps through the corresponding slots in the seat cover. Ensure all straps are accessible and can be fastened securely.
5. Smooth out the cover to ensure a snug and wrinkle-free fit.

### 4.2. Attaching the Play Bar

1. Locate the attachment points on the sides of your Tatamia high chair, typically near the armrests.
2. Align the ends of the Play Bar with these attachment points.

3. Press firmly until you hear a click, indicating that the Play Bar is securely locked into place.
4. Gently pull on the Play Bar to ensure it is firmly attached and will not detach during use.



Image 4.1: The Peg Perego Tatamia Kit fully installed on a high chair, demonstrating the proper fit of the seat cover and the position of the play bar.

## 5. OPERATING

The Tatamia Kit enhances your child's experience in the high chair:

- **Soft-Touch Seat Cover:** Provides additional padding and a comfortable surface for your child during meal times or play.
- **Play Bar:** The integrated play bar with hanging toys offers entertainment and stimulates your child's senses. The toys are designed to be engaging and can be interacted with by your child.

Ensure the child is properly secured with the high chair's harness system at all times, even when the play bar is in use.

## 6. MAINTENANCE

### 6.1. Cleaning the Soft-Touch Seat Cover

The seat cover is made of 100% Polyester material.

- Remove the seat cover from the high chair.
- Wipe clean with a damp cloth and mild soap.
- For deeper cleaning, the cover can be hand washed in cold water with a gentle detergent.
- Do not bleach.
- Air dry thoroughly before reattaching to the high chair. Do not tumble dry.

### 6.2. Cleaning the Play Bar and Toys

- Wipe the play bar and attached toys with a damp cloth and mild soap.
- Do not immerse the play bar or toys in water.
- Allow to air dry completely before reattaching.

### 6.3. Storage

When not in use, store the Tatamia Kit in a clean, dry place away from direct sunlight and extreme temperatures.

## 7. TROUBLESHOOTING

- **Issue:** Play Bar does not attach securely.  
**Solution:** Ensure the attachment points on the high chair are clear of obstructions. Verify that the Play Bar is aligned correctly and press firmly until it clicks into place.
- **Issue:** Seat Cover appears wrinkled or ill-fitting.  
**Solution:** Remove the cover and re-align it, ensuring all harness straps are properly threaded through the designated slots. Smooth out any wrinkles from the center outwards.
- **Issue:** Toys on the Play Bar are not engaging the child.  
**Solution:** Ensure the Play Bar is positioned at an appropriate height for the child to reach and interact with the toys. Consider rotating the toys or introducing new ones if they are detachable.

## 8. SPECIFICATIONS

Feature	Specification
Model Number	IKAC0038--IN31
Product Dimensions	8 x 12.5 x 29 inches
Item Weight	1.76 pounds
Maximum Weight Recommendation	45 Pounds
Material Type	Polyester
Material Composition	100% Polyester
Batteries Required	No
Is Portable	Yes
Color	Azzurro (Light Blue)
Age Range (Description)	Infant

## 9. WARRANTY AND SUPPORT

For information regarding warranty coverage, product registration, or technical support, please refer to the official Peg Perego website or contact their customer service directly.

You can typically find contact information and detailed warranty policies on the manufacturer's official website: [Peg Perego Official Website](#)

Please have your product model number (IKAC0038--IN31) and purchase information ready when contacting support.