

[Manuals.plus](#) /

› [Energizer](#) /

› Energizer E303633200 Hybrid LED Headlamp User Manual

Energizer E303633200

Energizer E303633200 Hybrid LED Headlamp User Manual

Model: E303633200

INTRODUCTION

This manual provides instructions for the safe and effective use of your Energizer E303633200 Hybrid LED Headlamp. Please read this manual thoroughly before initial operation and retain it for future reference. This headlamp is designed for hands-free illumination in various environments.

PRODUCT OVERVIEW



Image 1: The Energizer E303633200 Hybrid LED Headlamp. This image shows the headlamp with its black adjustable elastic strap, featuring the 'Energizer' logo. The lamp unit itself is black, housing two LED lenses, and also displays the 'Energizer' logo on its body. The design emphasizes hands-free functionality.

The Energizer E303633200 is a powerful and versatile headlamp, featuring a hybrid design for optimal performance. It provides 1000 lumens of bright LED light, suitable for various tasks requiring hands-free illumination.

SETUP

1. Battery Installation

Your Energizer E303633200 headlamp requires two CR123A batteries for operation. These batteries are included with your purchase.

1. Locate the battery compartment on the headlamp unit. This is typically found at the rear or side of the main light housing.
2. Carefully open the battery compartment cover.
3. Insert the two CR123A batteries according to the polarity indicators (+ and -) marked inside the compartment. Ensure correct orientation to prevent damage.
4. Securely close the battery compartment cover until it clicks into place, ensuring a tight seal.

2. Strap Adjustment

The headlamp features an adjustable elastic strap for a comfortable and secure fit.

- Place the headlamp on your head.
- Adjust the elastic strap using the buckles on either side until the headlamp feels snug but not overly tight. The strap should hold the headlamp securely in place during movement.

OPERATING INSTRUCTIONS

Power On/Off and Mode Selection

The headlamp is operated via a single power button, typically located on the top or side of the main light unit.

- **To Turn On:** Press the power button once. The headlamp will typically activate in its default or last-used mode.
- **To Cycle Modes:** While the headlamp is on, press the power button repeatedly to cycle through the available light modes (e.g., High, Low, Spot, Flood, Hybrid). The specific sequence may vary.
- **To Turn Off:** Press and hold the power button for approximately 2 seconds, or cycle through all modes until the light turns off. Some models may turn off with a single press after a few seconds in a specific mode.

Hybrid Feature

The hybrid feature allows for optimized light output, combining different beam patterns or brightness levels to suit various tasks. Refer to the mode cycling instructions to activate and utilize the hybrid lighting option.

MAINTENANCE

Battery Replacement

When the light output diminishes significantly or the headlamp fails to turn on, it is time to replace the batteries. Follow the battery installation steps outlined in the Setup section, ensuring to use fresh CR123A batteries.

Cleaning

To maintain optimal performance and appearance:

- Wipe the headlamp body with a soft, damp cloth.
- Do not use abrasive cleaners or solvents, as these can damage the finish or internal components.
- Clean the lens gently with a lens cloth to ensure maximum light output.

Storage

If storing the headlamp for an extended period, remove the batteries to prevent leakage and potential damage to the device. Store in a cool, dry place away from direct sunlight.

TROUBLESHOOTING

- **Headlamp does not turn on:**
 - Ensure batteries are inserted correctly with proper polarity.
 - Replace with fresh CR123A batteries.
 - Check for any visible damage to the battery compartment or contacts.
- **Light is dim or flickers:**
 - Batteries may be low. Replace with fresh CR123A batteries.
 - Ensure battery contacts are clean and free of corrosion.

SPECIFICATIONS

Brand	Energizer
Model Number	E303633200
Light Source Type	LED
Luminosity	1000 Lumens
Power Source	Battery Powered
Battery Type	2 x CR123A (included)
Voltage	6 Volts (DC)
Special Features	Hybrid
Item Weight	200 g
Package Dimensions	8.2 x 7.8 x 3.2 cm

WARRANTY AND SUPPORT

For information regarding warranty coverage, product support, or spare parts availability, please refer to the documentation included with your purchase or visit the official Energizer website. You may also visit the [Energizer Store on Amazon](#) for additional product information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question