

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Peg Perego](#) /

> [Peg Perego Tatamia Kit-High Chair Accessory-Soft Seat Cover & Play Bar-Verde \(Light Green\) Instruction Manual](#)

Peg Perego IKAC0038--IN34

Peg Perego Tatamia Kit Instruction Manual

MODEL: IKAC0038--IN34

Introduction

The Peg Perego Tatamia Kit is designed to enhance the comfort and entertainment for your child when using the Tatamia high chair. This accessory kit includes a soft-touch seat cover and an engaging play center, making meal times and play times more enjoyable.

This manual provides essential information for the proper assembly, use, maintenance, and troubleshooting of your Tatamia Kit.



Image: The Peg Perego Tatamia Kit, featuring a light green soft seat cover and a vibrant play bar with hanging toys, installed on

a high chair.

Package Contents

Please ensure all components are present before beginning assembly:

- 1 x Soft-Touch Seat Cover (Verde - Light Green)
- 1 x Play Bar with attached toys

Safety Information

Always prioritize your child's safety. Read and understand all instructions before use.

- Ensure the kit is securely attached to the Peg Perego Tatamia high chair before placing your child in it.
- Never leave your child unattended in the high chair.
- Regularly inspect the seat cover and play bar for any signs of wear, damage, or loose parts. Discontinue use if any damage is found.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- The play bar is for entertainment only and should not be used as a handle or for lifting the high chair.

Setup Instructions

1. **Unpack Components:** Carefully remove the seat cover and play bar from their packaging.
2. **Install Soft-Touch Seat Cover:**
 - Ensure your Tatamia high chair is clean and dry.
 - Drape the seat cover over the high chair seat, aligning the openings for the harness straps and the seat belt buckle.
 - Thread the high chair's harness straps and buckle through the corresponding openings in the seat cover. Ensure the cover fits snugly and smoothly over the entire seat.
3. **Attach Play Bar:**
 - Locate the attachment points on the sides of your Tatamia high chair, typically near the armrests.
 - Align the ends of the play bar with these attachment points.
 - Press firmly until you hear a click, indicating the play bar is securely locked into place. Gently pull on the play bar to confirm it is stable and cannot be easily dislodged.



Image: A detailed view of the play bar, highlighting its colorful design and the secure attachment points to the high chair frame.

Operating Instructions

- **Using the Seat Cover:** The soft-touch seat cover provides additional comfort for your child. It is designed to be used with the high chair's existing harness system. Always secure your child with the high chair's

harness when using the seat cover.

- **Using the Play Bar:** The play bar is designed to entertain your child. The hanging toys can be moved and interacted with. Ensure the play bar is always securely attached before allowing your child to play with it.

Maintenance

- **Seat Cover Cleaning:** The seat cover is made of 100% Polyester. It can be spot cleaned with a damp cloth and mild soap. For deeper cleaning, refer to the care label on the seat cover for specific washing instructions. Allow to air dry completely before reattaching to the high chair.
- **Play Bar Cleaning:** Wipe the play bar and toys with a damp cloth and mild soap. Do not immerse the play bar in water.
- **Storage:** When not in use, store the kit in a clean, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

- **Play Bar Not Attaching Securely:**
 - Ensure the high chair's attachment points are clear of obstructions.
 - Verify that the play bar is correctly aligned with the attachment points. Apply firm, even pressure until it clicks into place.
- **Seat Cover Does Not Fit:**
 - This kit is specifically designed for the Peg Perego Tatamia high chair. Ensure you are using the correct high chair model.
 - Adjust the cover to ensure all edges are properly aligned and smoothed out.

Specifications

| Feature | Detail |
|-------------------------------|--|
| Model Number | IKAC0038--IN34 |
| Product Dimensions | 8 x 12.5 x 29 inches |
| Item Weight | 1.89 pounds |
| Material Type | Polyester |
| Material Composition | 100% Polyester |
| Maximum Weight Recommendation | 45 Pounds (for high chair, not kit itself) |
| Color | Verde (Light Green) |
| Is Portable | Yes |

Warranty and Support

For warranty information, product support, or to purchase replacement parts, please contact Peg Perego customer service directly. Refer to the official Peg Perego website or product packaging for the most current contact details.

Website: www.pegpereggo.com