

[manuals.plus](#) /

› [PlayStation](#) /

› [PlayStation 5 Disc Edition Console \(Slim\) User Manual](#)

PlayStation CFI-2000

PlayStation 5 Disc Edition Console (Slim) User Manual

Model: CFI-2000

1. INTRODUCTION

Welcome to the world of PlayStation 5. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your PlayStation 5 Disc Edition (Slim) console. Please read this manual thoroughly before using your console to ensure proper and safe operation.

2. SAFETY INFORMATION

Always observe the following safety precautions to prevent injury, electrical shock, fire, or damage to the console.

- Do not use the console near water or moisture.
- Ensure proper ventilation around the console to prevent overheating.
- Use only the power cord supplied with the console.
- Do not disassemble or modify the console. Refer all servicing to qualified personnel.
- Keep the console and accessories out of reach of small children.

3. WHAT'S IN THE Box

Verify that all items are present in your package:

- PlayStation 5 Disc Edition Console (Slim)
- DualSense Wireless Controller
- HDMI Cable
- AC Power Cord
- USB Cable (for controller charging/connection)
- Base (for vertical or horizontal orientation)

- Printed Materials (Quick Start Guide, Safety Guide)

4. SETUP

4.1 Console Placement

Place your PS5 console on a flat, stable surface. The Slim model includes a detachable base that allows for both vertical and horizontal orientation. Ensure adequate space around the console for proper airflow.



Image: The PlayStation 5 Disc Edition (Slim) console shown in its vertical orientation alongside the DualSense wireless controller. This illustrates the console's design and the included controller.

4.2 Connecting to a TV

1. Connect one end of the supplied HDMI cable to the HDMI OUT port on the PS5 console.
2. Connect the other end of the HDMI cable to the HDMI input on your TV.

4.3 Power Connection

1. Connect the supplied AC power cord to the AC IN connector on the PS5 console.
2. Plug the power cord into a wall outlet.

4.4 Initial Setup

1. Press the power button on the console to turn it on.
2. Connect your DualSense wireless controller to the console using the USB cable and press the PS button.
3. Follow the on-screen instructions to complete the initial setup, including language selection, internet connection, and user profile creation.

5. OPERATING THE CONSOLE

5.1 Powering On/Off

- **To turn on:** Press the power button on the console or the PS button on a paired controller.
- **To turn off:** From the control center, select Power > Turn Off PS5. Alternatively, press and hold the power button on the console until it beeps twice.
- **Rest Mode:** From the control center, select Power > Enter Rest Mode. In Rest Mode, the console consumes less power and can charge controllers, download updates, and keep games suspended.

5.2 Navigating the User Interface

Use the DualSense controller to navigate the PS5 Home Screen. The Home Screen provides access to your games, media apps, settings, and the PlayStation Store.



Image: The PlayStation 5 Disc Edition (Slim) console displayed horizontally, accompanied by the DualSense wireless controller. This view highlights the console's compact design when laid flat.

5.3 Connecting Peripherals

- **DualSense Controller:** Connect via USB for initial pairing and charging. Once paired, it can be used wirelessly.
- **USB Devices:** Use the USB ports on the front and back of the console for external storage, charging cables, or other compatible accessories.

5.4 Playing Games

- **Disc Games:** Insert a game disc into the disc drive. The game will appear on your Home Screen. Select it to start playing or install.
- **Digital Games:** Download games from the PlayStation Store. Once downloaded, they will appear on your Home Screen.

- **Backward Compatibility:** The PS5 console can play a vast library of supported PlayStation 4 games. Insert PS4 game discs or download digital PS4 titles you own.

6. SYSTEM SOFTWARE UPDATES

Regularly update your PS5 system software to ensure optimal performance, access new features, and maintain security. The console can be set to download updates automatically in Rest Mode.

- Go to **Settings > System > System Software > System Software Update and Settings**.
- Select **Update System Software** to check for and install available updates.

7. MAINTENANCE AND CARE

- **Cleaning:** Use a soft, dry cloth to clean the console's exterior. Do not use liquid cleaners or solvents.
- **Ventilation:** Ensure the console's vents are not blocked. Dust accumulation can affect performance; periodically clean vents with compressed air if necessary.
- **Disc Drive:** Handle game discs by the edges to avoid scratches. Keep the disc drive free of foreign objects.

8. TROUBLESHOOTING

If you encounter issues with your PS5 console, try the following common solutions:

Problem	Solution
No power	Check power cord connections. Try a different power outlet.
No video output	Ensure HDMI cable is securely connected. Try a different HDMI port on your TV or a different HDMI cable. Check TV input source.
Controller not responding	Connect the controller to the console with a USB cable to re-pair it. Ensure the controller is charged. Reset the controller by pressing the small button on the back with a pin.
Disc not reading	Clean the disc with a soft cloth. Ensure the disc is inserted correctly.
Console overheating	Ensure proper ventilation. Do not place the console in an enclosed space. Clean dust from vents.

For more detailed troubleshooting, visit the official PlayStation Support website.

9. SPECIFICATIONS

Feature	Detail
Model Number	CFI-2000

Feature	Detail
Dimensions (approx.)	43 x 36 x 16.8 cm (Parcel Dimensions)
Weight (approx.)	4.88 kg (Parcel Weight)
Storage	Ultra-High Speed SSD (Integrated I/O)
Optical Drive	Disc Drive (detachable)
Audio	3D Audio (Tempest 3D AudioTech)
Connectivity	HDMI Out, USB Type-A, USB Type-C, Ethernet, Wi-Fi
Power Supply	AC 100-240V, 50/60Hz
Manufacturer	Sony Interactive Entertainment
Country of Origin	China
Release Date	Jan. 1 2024

10. WARRANTY AND SUPPORT

Your PlayStation 5 console comes with a limited manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions.

For technical support, frequently asked questions, and additional resources, please visit the official PlayStation Support website:

Visit PlayStation
Support

You can also find more information and explore other PlayStation products at the official PlayStation Store:

Visit PlayStation Store