

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [InnoGIO](#) /

› [InnoGIO GIOwarm Fast Duo Double Bottle Warmer and Sterilizer User Manual](#)

InnoGIO GIO-370

InnoGIO GIOwarm Fast Duo Double Bottle Warmer and Sterilizer User Manual

Model: GIO-370

[Introduction](#)

[Safety Instructions](#)

[Product Overview](#)

[Setup](#)

[Operating Instructions](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. INTRODUCTION

This user manual provides essential information for the safe and effective use of your InnoGIO GIOwarm Fast Duo Double Bottle Warmer and Sterilizer. Please read these instructions carefully before first use and retain them for future reference. This appliance is designed to warm baby bottles, food, and sterilize bottles and accessories, offering convenience and efficiency for parents.

2. IMPORTANT SAFETY INSTRUCTIONS

WARNING: Failure to follow these safety instructions may result in fire, electric shock, or personal injury.

- Always place the appliance on a stable, heat-resistant, and level surface, away from children.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance matches your local mains voltage before connecting.
- Unplug the appliance from the outlet when not in use and before cleaning. Allow it to cool before handling.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has

been damaged in any manner.

- Keep the power cord away from hot surfaces.
- Do not use accessories not recommended by the manufacturer, as this may cause hazards.
- Extreme caution must be used when moving an appliance containing hot liquids.
- Always add water to the heating chamber before turning on the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- This appliance is for household use only. Do not use outdoors.
- Always check the temperature of the warmed food or liquid before feeding to a baby.
- Keep children away from the appliance during operation.

3. PRODUCT OVERVIEW

The InnoGIO GIOwarm Fast Duo is a versatile appliance designed for warming and sterilizing baby feeding items. It features a dual basket system for simultaneous processing of two items.



Figure 1: Front view of the InnoGIO GIOWarm Fast Duo. The device is white with gold accents, featuring a digital display and control buttons on the front panel. It has two raised sections at the top, indicating its dual capacity.

Components:

- **Main Unit:** Houses the heating element and control panel.
- **Digital Control Panel:** Features an intuitive display and touch buttons for mode selection and temperature adjustment.
- **Double Basket:** Designed to hold two bottles or food jars simultaneously.
- **Non-Stick Heating Plate:** Ensures efficient heating and easy cleaning.
- **Lid:** Helps retain heat and steam during operation.

4. SETUP

Before using your InnoGIO GIOwarm Fast Duo for the first time, follow these steps:

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Wipe the main unit with a damp cloth. Wash the double basket and lid with warm soapy water, rinse thoroughly, and dry. The non-stick heating plate should be wiped clean.
3. **Placement:** Place the appliance on a clean, dry, stable, and heat-resistant surface. Ensure there is adequate ventilation around the unit.
4. **Power Connection:** Plug the power cord into a suitable electrical outlet. The display will illuminate, indicating the unit is ready for use.



Figure 2: The InnoGIO GIOwarm Fast Duo shown with a baby bottle inserted and various accessories. This illustrates the capacity and how items are placed within the unit for warming or sterilization.

5. OPERATING INSTRUCTIONS

The GIOwarm Fast Duo offers five versatile operating modes:

General Operation Steps:

1. Place the desired bottles or food jars into the double basket.
2. Add the appropriate amount of distilled water to the heating chamber (refer to specific mode instructions for water levels).
3. Place the lid on the appliance.
4. Select the desired operating mode using the digital control panel.
5. The appliance will begin its cycle. An audible alert (five beeps) will sound when the cycle is complete, and the unit will automatically shut off.
6. Carefully remove the warmed or sterilized items, being cautious of hot steam and surfaces. Always check the temperature of food/liquid before feeding.

Operating Modes:

- **Rapid Heating:**

This mode quickly warms baby food or milk. Add water to the heating chamber according to the volume of liquid to be warmed. Select the "Rapid Heating" mode and adjust the target temperature if necessary. The appliance will heat the contents to the set temperature efficiently.

- **Keep Warm:**

Designed to maintain a constant, safe temperature for milk or food. After warming, select the "Keep Warm" mode. The appliance will hold the temperature, ensuring the contents are ready when needed. Monitor the duration to prevent bacterial growth.

- **Defrost:**

Safely thaws frozen breast milk or pre-frozen baby food. Place the frozen item in the basket and add water. Select the "Defrost" mode. This gentle process helps preserve nutrients.

- **Breast Milk Warming:**

Heats breast milk gently to an optimal temperature, typically body temperature, to preserve its essential nutrients. Use the recommended water level for breast milk warming and select this specific mode.

- **Sterilization:**

Sterilizes baby bottles, pacifiers, and other accessories by steam, eliminating up to 99.9% of bacteria and germs. Place clean items upside down in the basket. Add approximately 100-120ml of distilled water to the heating chamber. Select the "Sterilization" mode. The cycle will run until completion, indicated by the audible alert and automatic shut-off.

6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance ensure the longevity and hygienic operation of your GLOWARM Fast Duo.

- **Always unplug the appliance** and allow it to cool completely before cleaning.
- **Main Unit:** Wipe the exterior with a damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Double Basket and Lid:** Wash in warm soapy water, rinse thoroughly, and dry. These parts are typically dishwasher-safe (top rack only), but hand washing is recommended for best care.
- **Non-Stick Heating Plate:** Wipe clean with a soft, damp cloth. For stubborn residue, use a mild

detergent. Avoid scratching the non-stick surface.

- **Descaling:** Over time, mineral deposits (limescale) may build up on the heating plate, especially in areas with hard water. To descale, mix 50ml of white vinegar with 100ml of cold water and pour it into the heating chamber. Let it stand for 30 minutes (do not heat). Pour out the solution and rinse the chamber thoroughly with clean water. Repeat if necessary. Descale monthly or as needed.

7. TROUBLESHOOTING

If you encounter issues with your InnoGIO GIOwarm Fast Duo, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|--|--|--|
| Appliance does not turn on. | Not plugged in; power outage; faulty outlet. | Ensure the power cord is securely plugged into a working outlet. Check your household's circuit breaker. |
| Food/milk not heating sufficiently or taking too long. | Insufficient water; incorrect mode selected; limescale buildup; item too cold/large. | Ensure adequate water is added. Select the correct heating mode. Descale the heating plate if necessary. For frozen items, use the defrost mode first. |
| Sterilization cycle not effective. | Insufficient water; items not properly placed; lid not sealed. | Ensure 100-120ml of water is used. Place items upside down to allow steam circulation. Ensure the lid is securely closed. |
| Audible alert (beeps) not sounding. | Malfunction. | If the appliance completes its cycle but no alert sounds, contact customer support. |

If the problem persists after trying these solutions, please contact InnoGIO customer support or your retailer.

8. SPECIFICATIONS

- **Model:** GIOwarm Fast Duo (GIO-370)
- **Manufacturer:** INNOGIO
- **Functions:** Rapid Heating, Keep Warm, Defrost, Breast Milk Warming, Sterilization
- **Features:** Double Basket, Digital Control Panel, Non-Stick Heating Plate, Overheat Protection, Automatic Shut-off, Audible Alert
- **Power Supply:** 220-240V~ 50/60Hz (*Note: Specific voltage not provided in source, typical European standard assumed.*)
- **Power Consumption:** Not specified in product information.

9. WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your product or consult the retailer from whom you purchased the InnoGIO GIOwarm Fast Duo. Warranty terms and conditions may vary by region and retailer.

For technical support, spare parts, or service inquiries, please contact InnoGIO customer service or your

local distributor. Contact details can typically be found on the manufacturer's official website or on your purchase receipt.

Related Documents - GIO-370

| | |
|---|--|
|  | <p><u>InnoGIO GIOwarm Mini Portable Bottle Warmer User Manual</u></p> <p>User manual for the InnoGIO GIOwarm Mini portable bottle warmer, detailing its features, assembly, usage, cleaning, and troubleshooting.</p> |
|  | <p><u>innoGIO GIO warm Portable Baby Bottle Warmer User Manual</u></p> <p>User manual for the innoGIO GIO warm Portable Baby Bottle Warmer (Model GIO-370), detailing assembly, operation, cleaning, safety precautions, troubleshooting, and bottle compatibility.</p> |
|  | <p><u>innoGIO GIO warm Mini Portable Bottle Warmer User Manual</u></p> <p>User manual for the innoGIO GIO warm Mini portable bottle warmer, detailing assembly, operation, cleaning, safety precautions, and troubleshooting for warming baby bottles.</p> |
|  | <p><u>Instrukcja Obsługi InnoGIO GIO-255 Bezpieczny Robot Niania Dziecięca</u></p> <p>Kompleksowa instrukcja obsługi dla InnoGIO GIO-255 Bezpieczny Robot Niania Dziecięca, obejmująca konfigurację, obsługę, funkcje, rozwiązywanie problemów i specyfikacje.</p> |
|  | <p><u>InnoGIO GIOpumpkin Silikonové noční světlo Uživatelská příručka GIO-146 CZ</u></p> <p>Uživatelská příručka pro silikonové noční světlo InnoGIO GIOpumpkin (Model GIO-146 CZ). Obsahuje bezpečnostní upozornění, technické parametry, návod k použití pro nastavení jasu a časovače a obsah balení.</p> |
|  | <p><u>InnoGIO GIOmum Line Comfort Wearable Electric Breast Pump GIO-357 Instruction Manual</u></p> <p>User manual for the InnoGIO GIOmum Line Comfort wearable electric breast pump (GIO-357). Learn about setup, operation, cleaning, and troubleshooting for optimal milk expression.</p> |