

## Slime 10201

# Slime 10201 Sealant Replacement Cartridge Instruction Manual

For Smart Spair Ultra Car Flat Tire Repair Kit

## INTRODUCTION

This manual provides essential instructions for the safe and effective use of the Slime 10201 Sealant Replacement Cartridge. This cartridge is designed exclusively for the Slime Smart Spair Ultra Car Flat Tire Repair Kit (Part #50158) to recharge its tire sealant component. Please read all instructions carefully before use.

## SAFETY INFORMATION

**WARNING:** Contains ethylene glycol, natural rubber latex. Harmful or fatal if swallowed. May produce allergic reaction by skin contact. Repeated or prolonged (oral) exposure may cause kidney damage.

**Keep out of reach of children.** Do not eat, drink, or smoke when using this product. Avoid breathing in mist, spray, and vapors. Avoid ingestion and skin contact. Wear eye protection and protective gloves.

**IF SWALLOWED:** Do not induce vomiting. Call a poison center, doctor, or emergency services if you feel unwell.

**On SKIN:** Wash with plenty of soap and water.

**WARNING:** This product exposes you to ethylene glycol, a reproductive toxicant. For more information, visit [P65Warnings.ca.gov](https://www.p65warnings.ca.gov).

## PRODUCT OVERVIEW

The Slime 10201 Sealant Replacement Cartridge is a 22oz (650ml) refill designed to replenish the sealant in your Slime Smart Spair Ultra Car Flat Tire Repair Kit. It provides a temporary tire repair solution, allowing you to drive to a service station for a permanent repair.





Image 1: Slime 10201 Sealant Replacement Cartridge. This image shows the green bottle of Slime emergency tire sealant, labeled with "REFILL PART #10201 - SLIME.COM".



Image 2: The Slime 10201 Sealant Replacement Cartridge shown alongside the compatible Smart Spair Ultra Car/Trailer Flat Tire Repair Kit. An arrow indicates that the cartridge fits into the kit. The kit is designed for tire repair with a push of a button, requiring no jack or tools.

For more information on the Smart Spair Ultra Kit, visit: <https://qrs.ly/k3eyis4>

## SETUP AND INSTALLATION (REPLACING THE SEALANT CARTRIDGE)

Follow these steps to replace the sealant cartridge in your Slime Smart Spair Ultra Flat Tire Repair Kit:

1. **Release Bottle:** Pull and hold the sealant bottle release lever on the side of the unit.
2. **Remove Empty Bottle:** Grab the bottle by the black neck and pull upward away from the unit. Once the empty bottle is removed, release the lever.
3. **Install New Bottle:** Align the parts on the new sealant bottle neck with the unit and insert the new sealant bottle as shown.

4. **Secure Bottle:** Release the bottle release lever to lock the bottle in place. Ensure the bottle is locked and cannot be pulled up or moved.



Image 3: A hand pulling the release lever on the tire repair kit to prepare for bottle removal or installation.





Image 4: A hand removing an empty sealant bottle from the tire repair kit.



Image 5: A hand inserting a new Slime sealant bottle into the tire repair kit, aligning it correctly.

For detailed visual instructions on removing and installing the sealant bottle, refer to the product packaging or scan the QR code on the bottle label.







Image 6: Diagram illustrating the steps for removing and installing the sealant bottle into the tire repair unit.

Scan for instructions: <https://qrs.ly/qff9b1d>

## OPERATING INSTRUCTIONS (USING THE SMART SPAIR ULTRA KIT WITH SEALANT)

Once the replacement sealant cartridge is installed, operate your Smart Spair Ultra Flat Tire Repair Kit according to its original instructions. Generally, the process involves:

1. Connect the kit's hose to the tire valve stem.
2. Plug the kit into your vehicle's 12V power outlet.
3. Activate the compressor to inject sealant and inflate the tire to the recommended PSI.
4. Drive immediately for a short distance (e.g., 1-2 miles) to allow the sealant to spread and seal the puncture.
5. Recheck tire pressure and reinflate if necessary.

**Important:** Treated tires should be repaired by a qualified tire professional at the earliest opportunity. It is recommended to drive no more than 100 miles or for 3 days (whichever comes first) after using Slime Tire Sealant. Advise the tire professional that Slime is in the tire.

## MAINTENANCE AND STORAGE

- Store the sealant cartridge and tire repair kit in a cool, dry place, away from direct sunlight and extreme temperatures.
- Check the expiration date on the sealant cartridge periodically. Replace expired sealant to ensure effectiveness.
- Ensure the sealant bottle is securely locked into the unit when not in use to prevent accidental spills.

If the sealant is too cold, it may not dispense properly. Allow the product to warm to room temperature before use if stored in cold conditions.

## TROUBLESHOOTING

- **Sealant not dispensing:** Ensure the cartridge is correctly installed and locked. If stored in cold temperatures, allow the sealant to warm up. Check the kit's power connection.
- **Tire not inflating:** Verify the hose connection to the tire valve is secure. Check the kit's power source. Ensure the tire valve is not obstructed.
- **Leak persists after use:** Slime sealant is designed for temporary repairs of punctures up to 1/4 inch (6mm). Larger punctures, sidewall damage, or bead leaks may not be sealed. Seek professional tire repair immediately.

If issues persist, consult the full Smart Spair Ultra Flat Tire Repair Kit manual or contact Slime customer support.

## SPECIFICATIONS

Feature	Detail
Product Name	Slime 10201 Sealant Replacement Cartridge
Model Number	10201
Brand	Slime
Material	Sealant (Liquid)
Volume	22 fl. oz. (650 mL)



Compatibility	Slime Smart Spair Ultra Car Flat Tire Repair Kit (Part #50158)
Item Weight	1.25 pounds
Dimensions (L x W x H)	2.87 x 2.87 x 8.27 inches
Water Resistance Level	Water Repellent
UPC	716281511622

## WARRANTY AND SUPPORT

Slime provides a quick emergency tire repair. Treated tires should be repaired by a qualified tire professional at the earliest opportunity to ensure safety and proper cleaning of tire pressure sensor, if so equipped. We recommend treated tires be repaired within 3 days or 100 miles (whichever comes first) after use of Slime Tire Sealant. Advise the tire professional that Slime is in the tire.

For warranty information, please visit the official Slime website: [www.slime.com/warranty](http://www.slime.com/warranty)

**Manufacturer:** ITW Global Tire Repair, 125 Venture Drive, Suite 210, San Luis Obispo, CA 93401 USA

**Contact:** (888) 457-5463

Slime 10201 Sealant Replacement Cartridge Instruction Manual. All rights reserved.

## Related Documents - 10201



### [Slime Tire Care Products Catalog and Guide](#)

Explore the comprehensive range of Slime tire sealants, inflators, repair kits, and accessories designed for automotive, bicycle, and industrial use. Learn about Slime's commitment to environmental safety and product innovation.






### [Slime Truck Spair Emergency Flat Tire Repair Kit: Instructions and Guide](#)

Comprehensive guide to the Slime Truck Spair Emergency Flat Tire Repair kit, including product features, safety warnings, step-by-step repair instructions, and troubleshooting tips for common issues. Learn how to use the 12V air compressor and Slime sealant for emergency tire repairs.



### [Slime Safety Spair Emergency Flat Tire Repair Instructions](#)

Comprehensive guide to using the Slime Safety Spair for emergency flat tire repair, including step-by-step instructions for sealant application and air inflation, safety warnings, and sealant removal.

 <p><b>slime</b> <b>MOTO SPAIR</b> EMERGENCY FLAT TIRE REPAIR KIT</p> <p>12V DC INFLATOR TIRE SEALANT POWER ADAPTERS</p> <p><b>ATTENTION! READ ALL INSTRUCTIONS CAREFULLY</b> PREVENT PERSONAL INJURY AND PROPERTY DAMAGE.</p>	<p><a href="#">Slime Moto Spair Emergency Flat Tire Repair Kit - Instructions and Troubleshooting</a></p> <p>Comprehensive guide to the Slime Moto Spair emergency flat tire repair kit, including setup, usage, tire repair with sealant, sealant removal, troubleshooting, and warranty information. Features a 12V DC inflator, tire sealant, and power adapters.</p>
 <p><b>slime</b> <b>SMART SPAIR. PLUS</b> EMERGENCY FLAT TIRE REPAIR KIT</p> <p>12V DC INFLATOR TIRE SEALANT POWER ADAPTERS</p> <p><b>ATTENTION! READ ALL INSTRUCTIONS CAREFULLY</b> PREVENT PERSONAL INJURY AND PROPERTY DAMAGE.</p>	<p><a href="#">Slime Smart Spair Plus Emergency Flat Tire Repair Kit - Instructions and Guide</a></p> <p>Comprehensive guide for the Slime Smart Spair Plus Emergency Flat Tire Repair Kit. Learn how to use the tire sealant and inflator, troubleshoot common issues, and understand safety precautions for emergency tire repairs.</p>
 <p><b>slime</b> <b>FLAT TIRE</b> REPAIR KIT</p> <p>12V DC INFLATOR TIRE SEALANT POWER ADAPTERS</p> <p><b>ATTENTION! READ ALL INSTRUCTIONS CAREFULLY</b> PREVENT PERSONAL INJURY AND PROPERTY DAMAGE.</p>	<p><a href="#">Slime Flat Tire Repair Kit: Digital Inflator User Guide</a></p> <p>Comprehensive instructions for the Slime Flat Tire Repair Kit (Model #50123). Learn how to use AIR ONLY and AIR + SEALANT modes, troubleshoot common issues, and understand safety precautions for this 12V tire inflator.</p>