

XTREME DIGITAL LIFESTYLE ACCESSORIES MLB7-2014-RGB

Monster Smart LED Light Bar User Manual

Model: MLB7-2014-RGB

PRODUCT OVERVIEW

The Monster Smart LED Light Bar is a versatile lighting solution designed to enhance your environment with dynamic and customizable illumination. Featuring compatibility with popular smart home assistants like Alexa and Google Assistant, and powered by Razer Chroma for synchronized gaming experiences, this light bar offers a spectrum of colors and effects. Its unique color flow technology allows for multiple colors to be displayed simultaneously, creating immersive scenes and reactive lighting to music.



Image: The Monster Smart LED Light Bar shown alongside its retail packaging, highlighting its sleek design and key features.

PACKAGE CONTENTS

- Monster Smart LED Light Bar (1 unit)
- Multi-position base
- Power Adapter
- User Manual (this document)

SETUP GUIDE

1. Physical Placement

The Monster Smart LED Light Bar can be mounted in multiple positions to suit your setup. It can stand vertically or lay horizontally using the included multi-position base.



Image: Illustration demonstrating the light bar's flexibility for horizontal or vertical placement using its base.

2. Power Connection

1. Connect the power adapter to the light bar.
2. Plug the power adapter into a standard wall outlet. The light bar will power on.

3. App Installation and Pairing

To unlock the full potential of your Monster Smart LED Light Bar, download the Monster Smart App.

- Download the **Monster Smart App** from the [Google Play Store](#) or the [Apple App Store](#).
- Open the app and follow the on-screen instructions to create an account or log in.
- Add your new device by selecting the appropriate product category (e.g., Lighting > Smart Light Bar).
- Ensure your light bar is powered on and in pairing mode (often indicated by a blinking light). If not, you may need to manually put it into pairing mode by cycling power or holding a button (refer to the app's specific instructions for your model).
- Connect the light bar to your 2.4GHz Wi-Fi network through the app.



Image: A smartphone displaying the Monster Smart App, showing color selection and brightness controls, indicating ease of customization.

OPERATING INSTRUCTIONS

1. App Control

Once paired, use the Monster Smart App to control your light bar:

- **On/Off:** Toggle the power.
- **Brightness:** Adjust the light intensity.
- **Color Selection:** Choose from a wide spectrum of colors, including multi-white options (warm to cool white).
- **Color Flow:** Utilize the unique color flow feature to display multiple colors simultaneously, creating dynamic gradients and transitions.
- **Scenes:** Select from pre-set scenes or create your own custom lighting effects.
- **Music Mode:** Activate Music Mode to make the lights react and pulse to the beat of your audio.
- **Scheduling:** Set timers and schedules for automated lighting.



Image: A visual representation of the RGBW+IC Color Flow feature, demonstrating its ability to display multiple colors and dynamic transitions.

2. Voice Control Integration

The light bar is compatible with Amazon Alexa, Google Assistant, and Siri for convenient voice control.

- Link your Monster Smart App account to your preferred voice assistant through their respective apps (e.g., Alexa app, Google Home app).
- Once linked, you can use commands such as:
 - "Alexa, turn on the light bar."
 - "Hey Google, set the light bar to blue."
 - "Siri, dim the light bar to 50%."

3. Razer Chroma RGB Sync

For an enhanced gaming experience, sync your light bar with Razer Chroma RGB.

- Ensure your light bar is connected to the Monster Smart App.
- Download and install the Razer Synapse software on your PC.
- Follow the instructions within Razer Synapse to detect and integrate your Monster Smart Light Bar.
- Once integrated, your light bar will synchronize its lighting effects with your Razer Chroma-enabled PC accessories, games, and music.



Image: A gaming desk setup featuring the Monster Smart LED Light Bar, demonstrating its seamless integration with Razer Chroma RGB for synchronized lighting effects across multiple devices.



Image: The official Razer Chroma RGB logo, indicating compatibility and integration with the light bar.

4. Sound-Reactive Lighting

The light bar features a built-in microphone that allows it to react to ambient sounds and music.

- Activate the "Music Mode" within the Monster Smart App.
- The lights will then pulse and change colors in sync with the rhythm of your music or other audio.




Image: The Monster Smart LED Light Bar displaying dynamic color changes, visually representing its sound-reactive capabilities.

MAINTENANCE

To ensure the longevity and optimal performance of your Monster Smart LED Light Bar, follow these simple maintenance guidelines:

- **Cleaning:** Gently wipe the light bar with a soft, dry cloth. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the surface.
- **Handling:** Handle the light bar with care. Avoid dropping it or subjecting it to strong impacts.
- **Environment:** Use the light bar in a dry indoor environment. It is not water resistant.
- **Power:** Always unplug the device before cleaning or if it will be unused for an extended period.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light bar does not turn on.	No power, loose connection.	Ensure the power adapter is securely plugged into the light bar and a working wall outlet. Test the outlet with another device.
Cannot connect to Wi-Fi or app.	Incorrect Wi-Fi band, incorrect pairing mode, network interference.	<ul style="list-style-type: none"> ◦ Ensure your Wi-Fi network is 2.4GHz. The light bar does not support 5GHz networks. ◦ Confirm the light bar is in pairing mode (often a blinking light). If not, try power cycling the device (unplug and plug back in) or refer to the app for specific reset instructions. ◦ Move the light bar closer to your Wi-Fi router. ◦ Restart your router.
Razer Chroma RGB sync not working.	Software issue, incorrect setup.	<ul style="list-style-type: none"> ◦ Ensure the Monster Smart App is updated and the light bar is connected. ◦ Verify Razer Synapse is installed and updated on your PC. ◦ Check the Razer Synapse software for device detection and integration settings. Some users report issues with the PC app; ensure you have the latest version and try reinstalling if problems persist.
Light bar does not remember color settings after power cycle.	Specific device behavior.	Some smart devices may not retain specific color settings when power is completely cut (e.g., via an automated switch). This is often a design characteristic. Use the app or voice control to re-apply settings.
Voice control not responding.	Incorrect linking, internet connection issue.	Ensure your Monster Smart App account is correctly linked to Alexa/Google Assistant. Check your internet connection and the status of your voice assistant device.

SPECIFICATIONS

Feature	Detail
Brand	XTREME DIGITAL LIFESTYLE ACCESSORIES
Model Number	MLB7-2014-RGB
Color	Multi-colored
Form Factor	Bar
Connectivity Technology	Wi-Fi (2.4GHz only)
Special Feature	Color Changing, Sound-Reactive, Razer Chroma RGB Compatible
Material	Polycarbonate (PC)
Water Resistance Level	Not Water Resistant

Feature	Detail
Remote Control Included?	No (App/Voice Controlled)
Number of Pieces	1
Item Weight	5.6 ounces
Package Dimensions	10.75 x 3.62 x 1.69 inches
Manufacturer	Jem Accessories Inc
UPC	805106895006

OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video: An official product video showcasing the Monster Smart Lighting system, demonstrating various applications in different rooms, app control, voice control, and integration with gaming setups. The video highlights the versatility and dynamic color capabilities of the lights.

For further assistance, please visit the [XTREME DIGITAL LIFESTYLE ACCESSORIES Store](#) on Amazon.

© 2024 XTREME DIGITAL LIFESTYLE ACCESSORIES. All rights reserved.