

[Manuals.plus](#) /

› [Inateck](#) /

› Inateck Bluetooth Keyboard and Mouse Bundle User Manual

Inateck KB01103 and MS02001

Inateck Bluetooth Keyboard and Mouse Bundle User Manual

Models: KB01103 (Keyboard), MS02001 (Mouse)

INTRODUCTION

This manual provides comprehensive instructions for the Inateck Bluetooth Keyboard (KB01103) and Mouse (MS02001) bundle. Please read this manual carefully before use to ensure proper operation and to maximize the product's lifespan. This bundle offers multi-device connectivity and wide compatibility for various operating systems.



Image: The Inateck Bluetooth Keyboard (KB01103) and Mouse (MS02001) bundle, showcasing both devices.

PACKAGE CONTENTS

- Inateck Bluetooth Keyboard (KB01103)
- Inateck Wireless Mouse (MS02001)
- USB-A Receiver (for mouse)
- USB-C Receiver (for mouse)
- User Manual (this document)

SETUP GUIDE

Keyboard Setup (Bluetooth)

1. **Charge the Keyboard:** Ensure the keyboard is fully charged before first use.
2. **Turn On:** Locate the power switch on the keyboard and slide it to the "ON" position.
3. **Enter Pairing Mode:** Press and hold the Bluetooth pairing key (usually indicated by a Bluetooth icon or a specific function key combination) until the indicator light flashes, signifying it's in pairing mode.

4. **Enable Bluetooth on Your Device:** On your computer, tablet, or smartphone, go to Bluetooth settings and turn Bluetooth on.
5. **Select Keyboard:** In the list of available devices, select "Inateck KB01103" (or similar name).
6. **Confirm Pairing:** Follow any on-screen prompts to complete the pairing process. Some devices may require you to enter a code displayed on the screen using the keyboard.
7. **Connect Multiple Devices:** The keyboard supports connecting to three devices. Use dedicated keys (e.g., BT1, BT2, BT3) to switch between pairing modes for each device.

Mouse Setup (Wireless Receiver)

1. **Install Batteries:** Open the battery compartment on the bottom of the mouse and insert the required batteries (not specified, assuming standard AA/AAA).
2. **Locate Receivers:** The mouse comes with both USB-A and USB-C wireless adapters, conveniently stored in a slot at the bottom of the mouse.
3. **Connect Receiver:**
 - For USB-A port: Plug the USB-A receiver into an available USB-A port on your computer.
 - For USB-C port: Plug the USB-C receiver into an available USB-C port on your computer.
4. **Turn On:** Slide the power switch on the bottom of the mouse to the "ON" position.
5. **Automatic Connection:** The mouse should automatically connect to your device. No additional pairing is typically required for the wireless receiver connection.

Dual Wireless Channels

Click the key at the bottom to switch between devices with USB A/C interfaces



Image: The Inateck mouse demonstrating its dual wireless channels (USB-A and USB-C receivers) for flexible connectivity.

OPERATING INSTRUCTIONS

Multi-Device Connectivity (Keyboard)

The Inateck KB01103 keyboard allows you to connect and seamlessly switch between up to three different Bluetooth-enabled devices. This feature is ideal for users who work across multiple platforms or devices.

- **Pairing:** Follow the "Keyboard Setup" steps for each of the three devices, assigning them to a specific Bluetooth channel (e.g., BT1, BT2, BT3).
- **Switching:** To switch between connected devices, simply press the corresponding Bluetooth channel key (e.g., **Fn + 1** for device 1, **Fn + 2** for device 2, **Fn + 3** for device 3). The keyboard will automatically connect to the selected device.




Image: Diagram illustrating the seamless switching capability of the Inateck keyboard, allowing connection to three devices simultaneously.

Wide Compatibility

The KB01103 keyboard is designed for broad compatibility and can automatically identify your device's system for hassle-free connections across various platforms.

- **Supported Operating Systems:**

- Windows
- iPadOS
- Android
- iOS

Perfectly Compatible with

iPad OS

iOS

Windows

Android



Image: Visual representation of the Inateck keyboard's compatibility with iPadOS, iOS, Windows, and Android devices.

Convenient Shortcut Keys (Keyboard)

The keyboard features an extra row of dedicated function shortcut keys, optimized for Windows and iPadOS, allowing for quick access to common operations with a single press.

Keyboard Function Keys

Icon/Key	Function
	Lock Screen
	Adjust brightness down
	Adjust brightness up
	Task View / Show Desktop
	Take a screenshot of current screen
	Switch keyboard layout
◀▶	Last, Play/Pause, Next (Media Controls)
	Mute, Volume up or down
	Device switching (Bluetooth channels)
del	Delete

Note: Only partial touch gestures are supported on Android.

An Extra Row Function Keys for Windows and iPadOS

Note: Only partial touch gestures are supported on Android



 Undo

 Adjust brightness up or down

 Lock

 Task View

 Take a screenshot of current screen

 Switch keyboard layout

 Last, Play/Pause, Next

 Mute, Volume up or down

 Device switching

 Delete

Image: Close-up view of the Inateck keyboard highlighting the dedicated row of function keys and their corresponding icons.

Powerful Trackpad (Keyboard)

The integrated trackpad on the KB01103 keyboard offers smooth, stain-resistant performance with support for various gestures.

- **Palm Rejection:** Designed to ignore accidental touches from your palm while typing, ensuring accurate cursor control.

- **Multi-touch Gestures:** Supports common multi-touch gestures for enhanced navigation and control (e.g., scrolling, zooming, switching applications).



Powerful Trackpad

Smooth/ Stain-resistant

Palm Rejection



Multi-touch Gestures



Image: Demonstrates the keyboard's trackpad features, including palm rejection and multi-touch gesture capabilities.

Mouse Features (MS02001)

- **High Precision:** The mouse features a DPI (Dots Per Inch) of 1500, ensuring smooth control and precise navigation for various tasks.


- **Comfortable Design:** Ergonomically designed with a "skin-like" material for a comfortable grip during extended use.
- **Smooth Sliding:** Engineered for fast navigation and smooth movement across surfaces.

Skin-like Material More Comfortable to Use



Image: Close-up of the Inateck mouse, highlighting its skin-like material for enhanced comfort.

Fast Navigation Smooth Sliding



DPI=1500

Image: Depicts the Inateck mouse in use, emphasizing its fast navigation and smooth sliding capabilities with a DPI of 1500.

Comfortable to Touch



✗ Too flat



✗ Too steep

Image: Illustrates the ergonomic design of the Inateck mouse, showing how it fits comfortably in the hand compared to "too flat" or "too steep" designs.

MAINTENANCE

Proper maintenance will help extend the life of your Inateck keyboard and mouse.

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the surfaces of the keyboard and mouse. For stubborn dirt, slightly

dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.

- **Storage:** When not in use for extended periods, store the devices in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** If the devices use replaceable batteries, remove them if not in use for a long time to prevent leakage. For rechargeable devices, avoid fully draining the battery frequently to prolong its lifespan.

TROUBLESHOOTING

If you encounter issues with your Inateck keyboard or mouse, please refer to the following common solutions:

- **Device Not Connecting/Pairing:**
 - Ensure both the keyboard and mouse are powered on and fully charged/have fresh batteries.
 - Make sure Bluetooth is enabled on your host device (for keyboard).
 - Ensure the wireless receiver is properly plugged into a working USB port (for mouse).
 - Move the devices closer to your host device to rule out range issues.
 - Try unpairing and re-pairing the keyboard.
 - Restart your host device.
- **Lag or Disconnection:**
 - Check for interference from other wireless devices (e.g., Wi-Fi routers, other Bluetooth devices).
 - Ensure the devices are within optimal operating range.
 - Replace batteries or recharge the devices.
- **Keys Not Responding (Keyboard):**
 - Check if the keyboard is connected to the correct device channel.
 - Clean under the keys if debris is suspected.
- **Cursor Jumps/Inaccurate (Mouse):**
 - Clean the optical sensor on the bottom of the mouse.
 - Use the mouse on a clean, non-reflective surface.
 - Ensure the receiver is not obstructed.

SPECIFICATIONS

Feature	Detail
Brand	Inateck
Keyboard Model	KB01103
Mouse Model	MS02001
Connectivity Technology (Keyboard)	Bluetooth (Triple Channels)
Connectivity Technology (Mouse)	Wireless (USB-A & USB-C Receivers)
Special Feature (Keyboard)	Integrated Touchpad, Shortcut Keys

Feature	Detail
Compatible Devices	Tablet, PC, Smartphone (Windows, iPadOS, Android, iOS)
Mouse DPI	1500
Date First Available	October 18, 2023

WARRANTY AND SUPPORT

Inateck products are designed for reliability and performance. For warranty information or technical support, please contact Inateck customer service through their official website or the retailer where the product was purchased.
Inateck Official Website: www.inateck.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question