

[Manuals.plus](#) /

> [HOOBRO](#) /

> HOOBRO Tall Side Table Set of 2 and End Table Set of 2 with Charging Station Bundle User Manual

HOOBRO BF03DHP201-BG112BZP201

HOOBRO Tall Side Table & End Table Set User Manual

Model: BF03DHP201-BG112BZP201

Brand: HOOBRO

1. INTRODUCTION

Thank you for choosing the HOOBRO Tall Side Table Set and End Table Set with Charging Station. This manual provides essential information for the assembly, operation, maintenance, and troubleshooting of your new furniture. Please read these instructions carefully before assembly and retain them for future reference.

2. PRODUCT OVERVIEW

This bundle includes two tall side tables and two end tables, designed to offer versatile storage and charging solutions for various spaces in your home. Each piece features a sturdy metal frame and rustic brown finish, blending industrial style with practical functionality.



Image: The complete HOOBRO Tall Side Table and End Table Set, showcasing all four tables in their distinct designs.

Key Features:

- **Utility End Table:** Compact design (15"L x 11"W x 28.9"H for tall tables) suitable as a telephone table, nightstand, sofa table, or small entryway table.
- **Multifunctional Use:** The smaller bedside table (15"L x 11"W x 21.7"H) is space-saving and lightweight, ideal for living rooms, bedrooms, balconies, dorms, and tight spaces.
- **Integrated Charging Station:** End tables are equipped with 2 3-prong AC outlets and 2 USB ports for

convenient charging of devices. A 59-inch power cord is included.

- **Firm and Stable Construction:** Features solid matte black metal legs and shelves, ensuring durability.
- **Adjustable Feet:** Four adjustable feet provide stability on uneven surfaces and protect floors from scratches.
- **Easy Assembly & Cleaning:** Supplied with complete parts, clear instructions, and tools for straightforward assembly. The tabletop is easy to wipe clean.



Image: Two tall side tables positioned on either side of a sofa in a living room, demonstrating their practical use as end tables.



Image: Two tall side tables serving as nightstands beside a bed in a bedroom, highlighting their versatility.



Image: An end table with an integrated charging station placed next to an armchair, showing its utility for charging devices.

Three Forms

A variety of installation methods provide you with a convenient user experience.



Image: Visual representation of three different assembly configurations for the end table, offering flexible setup options.

3. PACKAGE CONTENTS

Please check the package carefully to ensure all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Tabletop Panels (Tall Tables & End Tables)
- Metal Frame Components (Legs, Support Bars)
- Mesh Shelf Panels
- Charging Station Unit (for End Tables)
- Power Cord (integrated with charging station)
- Adjustable Feet
- Assembly Hardware (Screws, Allen Wrench, etc.)
- Assembly Guide

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of your HOOBRO tables is designed to be straightforward. Please follow the detailed instructions provided in the included Assembly Guide. Ensure you have enough space and the necessary tools (an Allen wrench is typically provided).

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches. Verify all parts listed in the "Package Contents" section are present.
2. **Assemble Frame:** Attach the metal legs to the support bars using the provided screws. Do not fully tighten screws until all components are loosely assembled.
3. **Attach Shelves:** Secure the mesh shelf and any additional wooden shelves to the metal frame.
4. **Install Tabletop:** Attach the tabletop panel to the assembled frame. For end tables, ensure the charging station opening aligns correctly.
5. **Install Charging Station (End Tables Only):** Carefully insert the charging station unit into its designated slot on the tabletop and secure it with screws.
6. **Tighten All Screws:** Once all components are in place, gradually tighten all screws to ensure a stable and secure structure.
7. **Adjust Feet:** Screw in the adjustable feet at the bottom of each leg.



Image: Close-up of the adjustable feet, illustrating their 360-degree rotation for leveling the table on uneven surfaces.

Important: Always refer to the specific diagrams and step-by-step instructions in your physical Assembly Guide for the most accurate and safe assembly process.

5. OPERATING INSTRUCTIONS (CHARGING STATION)

The end tables in this set feature a built-in charging station for your convenience.

1. **Power Connection:** Plug the integrated 59-inch power cord from the charging station into a standard 120V AC wall outlet.
2. **AC Outlets:** Use the two 3-prong AC outlets (120V/12A) to power devices such as lamps, laptops, or other small appliances.
3. **USB Ports:** Use the two USB ports (5V/2A) to charge smartphones, tablets, and other USB-powered devices.



- 2 AC Outlets -
120V/12A



- 2 USB Ports -
5V/2A



- Power Cord -
4.9-Foot



Image: Detailed view of the charging station, showing the two AC outlets, two USB ports, and the power cord icon, along with their specifications.

Safety Note: Do not overload the outlets. Ensure devices plugged in do not exceed the maximum current rating. Keep liquids away from the charging station.

6. MAINTENANCE

To ensure the longevity and appearance of your HOOBRO tables, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the tabletop and metal frame with a soft, damp cloth. For stubborn marks, a mild detergent can be used, followed by drying with a clean cloth. Avoid abrasive cleaners or harsh chemicals.
- **Spills:** Clean up spills immediately to prevent staining or damage to the surface.
- **Stability Check:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Environment:** Avoid placing the tables in direct sunlight or near heat sources, as this may cause material degradation over time.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Table is wobbly/unstable.	Uneven floor; screws not fully tightened.	Adjust the leveling feet at the bottom of the legs until the table is stable. Ensure all assembly screws are securely tightened.
Charging station not working.	Power cord not plugged in; outlet issue; device not compatible.	Ensure the power cord is securely plugged into a working wall outlet. Test the outlet with another device. Check if your device requires specific charging protocols not supported by standard USB (e.g., fast charging).
Missing parts during assembly.	Packaging oversight.	Double-check all packaging materials. If parts are genuinely missing, contact HOOBRO customer support with your purchase details.

8. SPECIFICATIONS

Feature	Detail
Brand	HOOBRO
Model	BF03DHP201-BG112BZP201
Tall Side Table Dimensions	15"L x 11"W x 28.9"H (38cm x 28cm x 73.5cm)
End Table Dimensions	15"L x 11"W x 21.7"H (38cm x 28cm x 55cm)
Frame Material	Metal
Charging Station (End Tables)	2 AC Outlets (120V/12A), 2 USB Ports (5V/2A)
Power Cord Length	59 inches (150cm)
Included Components	Assembly Guide, all necessary parts and tools




Image: Detailed dimensions of the tall side table, including height, width, and depth, along with weight capacities for each shelf.




Image: Detailed dimensions of the end table with charging station, including height, width, depth, and power cord length, along with weight capacities.

9. WARRANTY AND SUPPORT

HOOBRO is committed to providing high-quality products. For any questions, concerns, or assistance with your product, please contact HOOBRO customer support. Please have your purchase details and model number ready when contacting support.

For more information, visit the official HOOBRO website or refer to your purchase documentation for specific warranty terms and conditions.

[Visit the HOOBRO Store on Amazon](#)

