

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Satisfyer](#) /

› [Satisfyer Pixie Dust Clitoral Stimulator User Manual](#)

Satisfyer 360593

Satisfyer Pixie Dust Clitoral Stimulator User Manual

Model: 360593

INTRODUCTION

Thank you for choosing the Satisfyer Pixie Dust. This device is designed for clitoral stimulation, combining innovative Air Pulse technology with powerful vibrations to provide a unique experience. Please read this manual carefully before first use to ensure safe and optimal operation. Keep this manual for future reference.

Important Safety Information

- This product is intended for adult use only.
- Do not use if you have any medical conditions that may be aggravated by vibration or pressure. Consult a physician if unsure.
- Discontinue use immediately if you experience any discomfort or pain.
- Keep out of reach of children.
- Do not use the device while charging.
- Only use the original charging cable provided with the device.
- Clean the device thoroughly before and after each use as instructed in the "Maintenance and Care" section.

PACKAGE CONTENTS

Please check that all items are present in your package:

- 1x Satisfyer Pixie Dust Clitoral Stimulator
- 1x USB Magnetic Charging Cable
- 1x User Manual (this document)



Image: The Satisfyer Pixie Dust product packaging, indicating the brand, product name, and a 15-year guarantee.

PRODUCT OVERVIEW AND FEATURES

The Satisfyer Pixie Dust is a compact and powerful clitoral stimulator. Its ergonomic design fits comfortably in your hand, and its medical-grade silicone ensures a smooth, body-safe experience.



Image: Front view of the Satisfyer Pixie Dust, highlighting its dual Air Pulse and Vibration capabilities.

Key Features:

- **Air Pulse Technology:** Provides contactless clitoral stimulation with intense pressure waves.
- **Vibration Function:** Offers deep and rumble vibrations for additional pleasure.
- **Dual Motors:** Equipped with two separately controlled motors for versatile stimulation.
- **Multiple Programs:** Features 11 pressure wave modes and 12 vibration programs.
- **Body-Safe Material:** Made from medical-grade silicone.
- **Waterproof (IPX7):** Suitable for use in the shower or bath.
- **Magnetic Charging:** Easy and secure charging.

SPECIFICATIONS PRODUIT




Image: Detailed diagram illustrating the product's components, including the magnetic charging port, soft silicone material, dual motors, air pulse opening for contactless stimulation, and intuitive controls for 11 pressure wave and 12 vibration programs.

CHARGING

Before first use, fully charge your Satisfyer Pixie Dust. A full charge typically takes approximately 2-3 hours.

1. Locate the magnetic charging contacts on the device.
2. Connect the magnetic USB charging cable to these contacts. Ensure a secure connection.
3. Plug the USB end of the cable into a standard USB power adapter (not included) or a computer USB port.
4. The indicator light on the device will illuminate or flash during charging. It will typically stop flashing or change color when fully charged.
5. Once fully charged, disconnect the cable from the device and the power source.

Note: Do not use the device while it is charging.

OPERATING INSTRUCTIONS

The Satisfyer Pixie Dust features intuitive controls for easy operation.



Image: Rear view of the device, displaying the three control buttons for power, air pulse functions, and vibration functions.

1. **Power On/Off:** Press and hold the power button (central button with a circle icon) for approximately 2 seconds to turn the device on or off. The indicator light will illuminate when the device is on.

2. Air Pulse Control:

- Press the Air Pulse button (top button with wave icon) to cycle through the 11 different pressure wave modes.
- Each press will switch to the next mode.

3. Vibration Control:

- Press the Vibration button (bottom button with two curved lines icon) to cycle through the 12 different vibration programs.
- Each press will switch to the next program.

4. Combining Functions:

You can use the Air Pulse and Vibration functions independently or simultaneously. Adjust each function to your preferred setting.

Experiment with different combinations of pressure wave modes and vibration programs to find your desired sensation.

MAINTENANCE AND CARE

Proper care will extend the lifespan of your Satisfyer Pixie Dust.

Cleaning:

- Clean the device thoroughly before and after each use.
- Wash the device with warm water and a mild, toy-friendly soap or a specialized toy cleaner.
- Rinse thoroughly to remove all soap residue.
- Dry the device completely with a lint-free cloth before storing.
- Do not use cleaners containing alcohol, petroleum, or acetone, as these can damage the silicone.

Storage:

- Store the device in a clean, dry, and dust-free place.
- Keep it away from direct sunlight and extreme temperatures.
- Avoid storing with other toys made of different materials to prevent material degradation.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully.
Device does not charge.	Charging cable not properly connected or damaged.	Ensure the magnetic cable is securely attached. Try a different USB power source. Contact support if the cable is damaged.
Weak Air Pulse or Vibration.	Low battery.	Recharge the device.
Device turns off unexpectedly.	Low battery.	Recharge the device.

If you encounter issues not listed here or if the solutions do not resolve the problem, please contact

SPECIFICATIONS

Brand	Satisfyer
Model Number	360593
Dimensions (L x W x H)	5.9 x 5.4 x 9.4 cm
Weight	0.28 grams
Material	Medical-grade Silicone
Waterproof Rating	IPX7 (submersible up to 1 meter for 30 minutes)
Battery	1 Lithium-polymer (included)
Air Pulse Modes	11
Vibration Programs	12

WARRANTY AND SUPPORT

Satisfyer products are known for their quality and durability. The Satisfyer Pixie Dust comes with a **15-year guarantee**, ensuring long-term satisfaction.

For warranty claims, technical support, or any questions regarding your device, please visit the official Satisfyer website or contact their customer service directly. Please have your model number (360593) and proof of purchase ready when contacting support.

DISPOSAL INFORMATION

This product contains electronic components and a rechargeable battery. Do not dispose of it with household waste. Please dispose of the device at an appropriate collection point for the recycling of electrical and electronic equipment (WEEE) in accordance with local regulations. Proper disposal helps prevent potential negative consequences for the environment and human health.