

[Manuals.plus](#) /

› [VERMESS](#) /

› VERMESS 48-Inch Computer Desk User Manual

VERMESS TJCBZ-VT

VERMESS 48-Inch Computer Desk User Manual

Model: TJCBZ-VT

INTRODUCTION

Thank you for choosing the VERMESS 48-Inch Computer Desk. This industrial-style desk is designed to enhance your home office, gaming setup, or study area with its ergonomic features, ample storage, and modern aesthetic. It includes a convenient keyboard tray, a CPU stand shelf, and extended monitor stands to support two monitors, promoting a comfortable and efficient workspace.

This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new desk.

PACKAGE CONTENTS

Before beginning assembly, please verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact VERMESS customer service for assistance.



Figure 1: All included parts and hardware for assembly.

- Wooden Desktop Panels (A, B, C, D)

- Metal Frame Components (E, F, G, H, I, J, K, L, M, N, O)
- Assembly Hardware (Screws, Nuts, Allen Wrench, Wrench)
- Adjustable Feet

ASSEMBLY INSTRUCTIONS

Assembly typically requires two people and takes approximately 1.5 to 2 hours. Follow these steps carefully. Do not fully tighten screws until all components are in place, unless specified.

Step 1: Assemble the Side Shelving Units

Begin by attaching the adjustable feet to the bottom of the vertical metal frames (Parts E, F, L, M). Then, secure the wooden shelves (Part D) to the frames using the provided screws. Pay close attention to the orientation of parts, especially for the keyboard tray mechanism.

Your browser does not support the video tag.

Video 1: Detailed installation guide for the VERMESS Computer Desk, demonstrating each assembly step.

Refer to the video above for a visual step-by-step guide on assembling the desk components, including the side shelving units and the main desktop frame.

Step 2: Attach the Main Desktop and Monitor Stand

Once the side units are assembled, connect them using the main desktop panel (Part B) and the monitor stand panel (Part A). Ensure all screw holes align before tightening. The X-frame crossbar (Part O) should be installed at the back for added stability.



Figure 2: The VERMESS 48-Inch Computer Desk fully assembled, showcasing its multi-tiered design and storage capabilities. Carefully lift and position the main desktop onto the assembled frames. Secure it with the appropriate screws. Then, attach the monitor stand to the top of the main desktop, ensuring it is centered and stable.

PRODUCT FEATURES

- **Ergonomic Design:** The elevated monitor stand (3.7" height) helps raise your screen to eye level, promoting better posture and reducing neck and back strain.
- **Ample Storage:** Features a pull-out keyboard tray, two-tier storage shelves, and a dedicated CPU stand shelf, providing organized space for all your office essentials.
- **Sturdy Structure:** Constructed with durable metal legs and a robust wood desktop, ensuring stability and a high bearing capacity. The X-frame crossbar further enhances stability.
- **Modern Aesthetic:** The rustic brown finish and minimalist design blend seamlessly with various home decor styles, making it suitable for home offices, living rooms, or bedrooms.

Enjoy Ergonomic Comfort

Raise your screen closer to eye level




Figure 3: Visual representation of the ergonomic benefits provided by the elevated monitor stand.



Smooth Keyboard Tray

Perfect for 108 or 87 keyboard and mouse

Figure 4: The integrated pull-out keyboard tray, designed for comfort and space-saving.

CARE AND MAINTENANCE

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Immediately wipe up any spills to prevent water damage or staining.
- **Heat Protection:** Use coasters or protective pads under hot items to prevent heat marks.
- **Weight Distribution:** Distribute weight evenly across the desktop and shelves to maintain stability and prevent warping.
- **Regular Checks:** Periodically check and tighten all screws and connections to ensure the desk remains stable and secure.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk wobbles after assembly.	Screws are not fully tightened; uneven floor; adjustable feet not properly adjusted.	Ensure all screws are securely tightened. Adjust the leveling feet at the bottom of the desk legs to compensate for uneven flooring.
Keyboard tray is stiff or sticks.	Rails are not aligned correctly; debris in the rails.	Check the alignment of the keyboard tray rails. Ensure they are installed correctly and parallel. Clean any dust or debris from the rails.
Parts do not align during assembly.	Incorrect orientation of parts; screws tightened prematurely.	Review the assembly video and diagrams carefully to ensure correct part orientation. Loosen all screws slightly, align the parts, then gradually tighten all screws.

SPECIFICATIONS

Feature	Detail
Brand	VERMESS
Model Number	TJCBZ-VT
Product Dimensions (D x W x H)	20.87"D x 47.24"W x 30.31"H
Color	Rustic Brown
Base Material	Metal (Iron)
Top Material Type	Wood
Item Weight	48.17 Pounds
Number of Shelves	3 (including CPU stand)
Keyboard Tray	Yes
Monitor Stand Height	3.7 Inches
Assembly Required	Yes (Recommended 2 people)

Product Dimension



Accessory: Mouse pad x 1(random color): 23.6" L x 11.8" W

Figure 5: Comprehensive dimensions of the VERMESS Computer Desk.

WARRANTY AND SUPPORT

The VERMESS 48-Inch Computer Desk comes with a limited warranty. For specific warranty details, please refer to the product packaging or contact VERMESS customer service. If you encounter any issues, require replacement parts, or have questions regarding your desk, please do not hesitate to contact our support team. We are committed to providing 24-hour service to ensure your satisfaction.

Contact information can typically be found on the product packaging or the VERMESS official website.