CAPHAUS B0CL9Q6MV8

CAPHAUS Twinkling Birch Tree Instruction Manual

Models: 4 FT, 6 FT, 8 FT

1. Introduction

Thank you for choosing the CAPHAUS Twinkling Birch Tree. This artificial tree features energy-efficient LED lights designed to bring a warm and enchanting glow to your indoor spaces. This manual provides essential information for safe setup, operation, and maintenance of your product.
Please read these instructions carefully before assembly and use, and retain them for future reference.

2. Product Overview

The CAPHAUS Twinkling Birch Tree is designed to mimic the natural beauty of a birch tree with illuminated branches. It is available in 4 FT, 6 FT, and 8 FT sizes, each featuring a stable base and a varying number of LED lights.

Image: Close-up view of the illuminated branches, showcasing the warm white LED lights.

Image: Product features highlighting IP44 and UL certification, lifelike appearance, creative freedom, and low maintenance.

Your browser does not support the video tag.

Video: This video provides a detailed look at the tree's components, including the branches, base, and trunk, and demonstrates various branch styles such as Birch, Bare Branch, Cherry Blossom, and Willow.

3. Specifications

Feature	Description
Brand	CAPHAUS
Material	Plastic
Frame Material	Plastic
Light Color	Warm White
Number of Light Sources	4 FT: 48 LEDs, 6 FT: 72 LEDs, 8 FT: 132 LEDs
Product Dimensions (8 FT Model)	10.24 x 10.24 x 96 inches (L x W x H)
Item Weight (8 FT Model)	10.71 pounds
Waterproof Rating	IP44
Safety Certification	UL588 Approved
Extension Cable	5-meter white extension cable included
Stakes (for 3 sets)	12 Stakes



Image: Detailed specifications for the 4 FT, 6 FT, and 8 FT models, including height, base size, and number of LED lights.

4. Setup Instructions

Follow these steps to assemble your CAPHAUS Twinkling Birch Tree:

1. **Install the Trunk Parts:** Carefully connect the trunk sections. Tighten the screw clockwise for secure fastening.
2. **Bend Down Branches:** Gently bend the flexible branches to your desired shape. The branches are designed for creative freedom in styling.
3. **Place in Setting:** Position the tree in your chosen indoor location.

Safety Notes:

- It is recommended to place the trees in a corner against a wall for added stability.
- Alternatively, secure the tree with the provided "L" clips or place heavy packs onto the base to prevent it from falling down.

Image: Step-by-step assembly guide for the CAPHAUS Twinkling Birch Tree, including safety recommendations for stability.

5. Operating Instructions

To operate your Twinkling Birch Tree:

1. Ensure the tree is properly assembled and stable.
2. Plug the power adapter into a standard electrical outlet.
3. Locate the mode switch (if applicable) on the power cord or adapter to cycle through different lighting effects or to turn the lights on/off.

Important:

- The LED lights are energy-efficient. If the light is on 24/7, the lamp life can last for approximately 4 months. If used for 8 hours at night, it can last for over a year.
- These are electronic products and are recommended for indoor use only.

6. Maintenance

Proper care will ensure the longevity of your CAPHAUS Twinkling Birch Tree:

- **Cleaning:** Gently wipe the branches and trunk with a soft, dry cloth to remove dust. Do not use liquid cleaners or immerse any part of the tree in water.
- **Storage:** When not in use, carefully disassemble the tree (if applicable) and store it in its original packaging or a protective container in a cool, dry place away from direct sunlight.
- **Indoor Use Only:** Although the product has an IP44 waterproof rating, it is designed for indoor use. Avoid prolonged exposure to outdoor elements to prevent damage.

7. Troubleshooting

If you encounter issues with your Twinkling Birch Tree, please refer to the following common solutions:

- **Lights Not Working:**
  - Ensure the power adapter is securely plugged into both the tree and the wall outlet.
  - Check if the wall outlet is functional by plugging in another device.
  - Verify that the mode switch (if present) is set to an 'ON' position or a desired lighting mode.
- **Tree is Unstable:**
  - Confirm that all trunk sections are securely fastened.
  - Place the tree in a corner against a wall.
  - Use the provided "L" clips to secure the base, or place heavy objects on the base for added stability.
- **Dim Lights:**
  - Ensure the power supply is adequate and stable.
  - Check for any visible damage to the wiring or individual LED bulbs.

If these steps do not resolve the issue, please contact CAPHAUS customer support for further assistance.

8. Warranty and Support

For warranty information or customer support, please refer to the product packaging or contact CAPHAUS directly through their official website or customer service channels. Keep your purchase receipt as proof of purchase.

© 2026 CAPHAUS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question