

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [HICON](#) /

> [HICON Mondo Gaming Chair - Ergonomic - Gaming Chair - Office Chair - Adjustable - Racing - Gaming Chair - White/Pink User Manual](#)

HICON HICON

HICON Mondo Gaming Chair User Manual

MODEL: HICON

1. Safety Information

Warning: Read this instruction manual carefully for safe assembly and use. Always pay attention to the user's weight and the stability of the chair. For more detailed information, please refer to the product packaging or the full instruction manual.

2. Product Overview

The HICON Mondo Gaming Chair is engineered to provide superior comfort and support for extended periods of use, whether for gaming, working, or relaxing. Its design integrates ergonomic principles with robust construction to ensure a healthy posture and long-lasting durability.

This gaming chair features a unique ergonomic design with a winged back that provides multi-point body contact, effectively distributing pressure and protecting your spine and lumbar region. It includes specialized head and lumbar pillows for comprehensive support, adapting to various body shapes.

The chair is highly versatile, offering a 360-degree swivel, smooth-rolling wheels for easy mobility, and a wide recline range from 90 to 170 degrees, suitable for working, playing, reading, or even napping. An adjustable, retractable footrest allows for comfortable relaxation. The seat and armrest heights are also adjustable to accommodate different desk heights and sitting preferences.

Constructed with a high-quality, hand-stitched PU leather covering an alloy frame and 12.5 cm high-density foam, the chair ensures both comfort and resilience. It is equipped with a state-of-the-art Class 4 gas lift and a solid mechanism, guaranteeing safety and stability. The chair has a robust maximum load capacity of 200 kg.





Figure 2.1: HICON Mondo Gaming Chair in pink and white.

3. Ergonomic Features

The HICON Mondo Gaming Chair is designed with your comfort and health in mind, incorporating several ergonomic features:

- **Winged Backrest:** Provides multi-point body contact to distribute pressure evenly and protect your spine and lumbar region.
- **Adjustable Lumbar Support:** Position the lumbar support to fit the natural curve of your lower back, ensuring optimal support and a relaxed, neutral posture.
- **Memory Foam Headrest:** The combination of memory foam and the headrest design adapts to your individual contours, providing comprehensive support and can help relieve pain.
- **Adjustable Armrests:** Ensure your arms are at approximately a 90-degree angle, aligning with your desk height to support your elbows comfortably. The width can also be adjusted to keep your elbows close to your body.
- **Retractable Footrest:** Allows you to recline and relax in a comfortable position, taking pressure off your legs and feet.

Ergonomic Design

De speciale ontwerpen van de rugleuning zijn aangepast aan de natuurlijke kromming van de wervelkolom.



Figure 3.1: Ergonomic Design highlighting neck, shoulder, back, and lumbar support.

Geheugenschuim Hoofdsteen

De combinatie van beide zorgt voor een unieke, allesomvattende ervaring.



Figure 3.2: Memory Foam Headrest and Lumbar Pillow, adapting to contours and providing comfort.

4. Setup and Assembly

While specific assembly instructions are typically provided with the product packaging, here is a general guide for setting up your HICON Mondo Gaming Chair:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out. Verify that all components listed in the product's assembly guide are present.
2. **Assemble the Base:** Insert the five caster wheels into the holes at the end of each leg of the chair's star base. Ensure they click securely into place.
3. **Install the Gas Lift:** Place the gas lift cylinder into the center hole of the assembled star base.
4. **Attach the Mechanism:** Secure the seat mechanism to the underside of the seat cushion using the provided screws. Ensure the front of the mechanism faces the front of the seat.
5. **Connect Seat to Base:** Carefully place the assembled seat cushion (with mechanism) onto the gas lift

cylinder.

6. **Attach the Backrest:** Align the backrest with the mounting brackets on the seat mechanism. Secure it using the provided screws.
7. **Install Armrests:** Attach the armrests to the sides of the seat and backrest, following the specific instructions for your model.
8. **Add Pillows:** Attach the headrest and lumbar support pillows using their straps.
9. **Final Check:** Once assembled, sit on the chair to test its stability and functionality. Ensure all screws are tightened and adjustments work smoothly.

5. Operating and Adjustments

To maximize comfort and ergonomic benefits, adjust your HICON Mondo Gaming Chair according to your body and preferences:

- **Seat Height Adjustment:** Locate the lever under the seat (usually on the right side). To raise the seat, lift the lever while taking your weight off the chair. To lower, lift the lever while seated. Adjust until your feet are flat on the floor and your knees are bent at a 90-110 degree angle. If your feet don't reach, consider using a footrest.
- **Seat Depth Adjustment:** Sit upright and adjust the seat depth so that there is approximately a 'fist distance' (four fingers) between the back of your knees and the front edge of the seat. This prevents pressure on blood vessels and nerves in your legs.
- **Backrest Recline:** Use the recline lever (typically on the left side) to adjust the backrest angle from 90 to 170 degrees. You can lock the backrest at your desired angle or set it to 'free float' for dynamic movement. When leaning back, ensure the chair moves smoothly. When sitting still, you should be able to sit upright without leaning on the backrest.
- **Armrest Adjustment:** Adjust the height of the armrests so that your forearms rest comfortably on them, ideally at the same height as your desk, forming a 90-degree angle at your elbows. Some models also allow for width adjustment to keep your elbows close to your body.
- **Footrest Operation:** Pull out the retractable footrest from under the seat. You can adjust its angle by 15 degrees for optimal relaxation. Push it back in when not in use.

Volledig Plat Met een Royale 165° Graden Achteroverleuning.

Zwaar Belastbaar Dankzij Krachtige Mechanismen




Figure 5.1: Recline angles for various activities: Working, Film Watching, and Rest.

Zachte Gewatteerde Koppelingsarmsteun

Je hoeft je geen zorgen te maken over het trillen van de armsteun.



Figure 5.2: Detail of the soft padded linkage armrest, designed for stability and comfort.

6. Maintenance

Regular maintenance will extend the life and appearance of your HICON Mondo Gaming Chair:

- **Cleaning the PU Leather:** Wipe the surface with a soft, damp cloth. For tougher stains, use a mild soap solution and wipe dry immediately. Avoid harsh chemicals, abrasive cleaners, or solvents, as they can damage the material.
- **Frame and Base:** Periodically check and tighten all screws and bolts to ensure stability. Wipe metal parts with a dry cloth to prevent dust buildup.
- **Caster Wheels:** Clean the wheels regularly to remove hair, dust, and debris that can impede smooth movement. You can use a small brush or vacuum cleaner.
- **Moving Parts:** If any moving parts (like the gas lift or recline mechanism) become stiff or squeaky, a small amount of silicone-based lubricant can be applied, but consult the manufacturer's guidelines if unsure.

- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the PU leather to fade or crack. Position your chair away from direct sunlight if possible.

7. Troubleshooting

Here are some common issues and their potential solutions:

Problem	Possible Cause	Solution
Chair Squeaks	Loose bolts, friction between parts	Tighten all assembly bolts. Apply silicone lubricant to moving parts or joints.
Chair Sinks/Doesn't Stay Up	Gas lift malfunction	The gas lift may need replacement. Contact customer support.
Caster Wheels Don't Roll Smoothly	Debris in wheels, damaged casters	Clean wheels thoroughly. If damaged, replace casters.
Backrest Doesn't Recline/Lock	Mechanism issue, lever stuck	Check if the recline lever is fully engaged or disengaged. Ensure no obstructions.

8. Specifications

Detailed specifications for the HICON Mondo Gaming Chair:

Attribute	Value
Brand	IN.HOMEXL / HICON
Model Number	HICON
Product Dimensions (L x W x H)	10D x 10W x 10H millimeters (approx. 1 x 1 x 1 cm)
Item Weight	23 Kilograms
Back Style	Wing Back
Seat Material Type	Polyurethane (PU)
Recommended Maximum Weight	200 Kilograms
Style	Modern
Room Type	Office, Game and Recreation Room

Attribute	Value
Age Range (Description)	Adult
Backrest (A)	59.5 cm
Backrest Height (B)	82.5 cm
Seat Width (C)	41 cm
Armrest Width (D)	46 cm
Adjustable Height (E)	33 - 46 cm
Seat Depth (F)	58 cm



Figure 8.1: Detailed dimensions of the HICON Mondo Gaming Chair.

Vergrote Rugleuning en Zitvlak

De meest **oversized** gamingstoelen in vergelijking met andere producten.



Figure 8.2: Comparison illustrating the enlarged backrest and seat of the HICON chair.

Robuust metalen frame voor hoge veiligheid.

Rugleuning breed genoeg voor meerdere zithoudingen.



Betere lendensteun

Robuust en flexibel schuim.



Updated PU wheels

Figure 8.3: Illustration of the robust metal frame and updated PU wheels for enhanced safety and durability.

9. Warranty and Support

Specific warranty details for the HICON Mondo Gaming Chair are not provided in this manual. Please refer to the product packaging, purchase documentation, or the manufacturer's official website for information regarding warranty coverage and terms.

For technical support, spare parts, or any inquiries not covered in this manual, please contact HICON customer service through the contact information provided with your purchase or on the official HICON website.

