

NACON Revolution 5 Pro

NACON Revolution 5 Pro Wireless Gaming Controller User Manual

Model: Revolution 5 Pro

1. INTRODUCTION

The NACON Revolution 5 Pro is a high-performance wireless gaming controller officially licensed for PlayStation platforms. It is designed for use with PlayStation 5, PlayStation 4, and PC. This manual provides instructions for setting up, operating, customizing, and maintaining your controller.

2. WHAT'S IN THE BOX

Verify that all components are present in the packaging:

- Revolution 5 PRO controller
- USB-C to USB-A controller cable (3 meters)
- 3 joysticks (various sizes)
- 2 D-pads (specialized and traditional)
- 3 weight sets
- Two joystick sleeve sizes
- External microphone
- Carry case

3. SETUP

3.1 Wireless Connection (PS5, PS4, PC)

To connect your Revolution 5 Pro controller wirelessly, use the included USB-A wireless adapter. Insert the adapter into an available USB-A port on your PlayStation 5, PlayStation 4, or PC. The controller will automatically pair with the adapter. The controller offers up to 10 hours of battery-powered gaming in wireless mode.

WIRELESS CONTROL

OFFICIALLY LICENSED FOR PLAYSTATION
WITH UP TO 10 HOURS OF BATTERY POWERED
GAMING WITH INCLUDED ADAPTER



INCLUDES 3M USB-C TO USB-A CABLE FOR WIRED PLAY

Image: The NACON Revolution 5 Pro controller in use, highlighting its wireless capabilities and official PlayStation licensing.

3.2 Wired Connection (PS5, PS4, PC)

For competitive play or when battery is low, connect the controller directly using the included 3-meter USB-C to USB-A cable. Plug the USB-C end into the controller and the USB-A end into your console or PC.

3.3 Bluetooth Audio Connectivity (PS4, PS5)

Connect your Bluetooth earbuds or headset to the Revolution 5 Pro for wireless game audio when gaming in PS4 or PS5 mode. An optional plug-in microphone is included for in-game chat. A 3.5mm wired headset connection port is also available for PS4/PS5 mode. Please note that audio is not available in PC Mode via Bluetooth.



Image: The external microphone adapter connected to the controller, demonstrating audio input options.

4. OPERATING THE CONTROLLER

4.1 Basic Controls

The Revolution 5 Pro features standard PlayStation button layouts, including directional buttons, action buttons (Triangle, Circle, Cross, Square), L1/R1 bumpers, L2/R2 triggers, and two analog sticks. The touchpad is also functional.

4.2 Onboard Controls

Utilize the built-in touchpad and selector switches on the controller to select profiles, adjust audio settings, and control RGB lighting effects without needing external software.

4.3 Vibration Feedback

Experience immersive feedback with integrated vibration motors when playing on PS4 and PC. **Note:** Vibration functionality is not available when using the controller with PlayStation 5 consoles.



Image: The controller in use, illustrating the haptic feedback feature.

5. CUSTOMIZATION

5.1 Hall Effect Technology

The joysticks and triggers incorporate magnetic Hall Effect sensors. This technology eliminates stick drift and enhances both precision and durability over time.



HALL EFFECT TECHNOLOGY

MAGNETIC SENSORS ELIMINATE STICK DRIFT
AND INCREASE PRECISION AND DURABILITY

Image: A detailed view of the controller's joystick, emphasizing the Hall Effect sensor technology.

5.2 Trigger Blockers

Adjust the L2 and R2 triggers using the integrated trigger blockers. This allows you to select between long or short trigger pulls, adapting the response to different gaming styles or in-game requirements.



TRIGGER BLOCKERS

ADAPT TO ANY IN-GAME SITUATION
WITH CUSTOMIZABLE SHORT AND
LONG TRIGGER PULLS

Image: Hands demonstrating the adjustment of the trigger blockers on the controller's underside.

5.3 Remappable Shortcuts

The controller features four Omron micro-switch back paddles. These shortcuts can be remapped to provide quick reactions and a distinct tactile feel during gameplay.



REMAPPABLE BUTTONS

FOUR OMRON® MICRO-SWITCH
BACK SHORTCUTS DELIVER FAST
REACTIONS AND UNMATCHED FEEL

Image: The rear of the controller, highlighting the four remappable shortcut buttons.

5.4 Specialized D-Pad

The controller includes a specialized D-pad design, developed in collaboration with professional fighting game player Mister Crimson. This D-pad can be easily swapped with a traditional D-pad design, both included in the package, to suit your preference.



SPECIALIZED D-PAD

REVOLUTIONARY INTERCHANGEABLE D-PAD
DESIGN CREATED IN PARTNERSHIP WITH PRO
ESPORTS PLAYER MISTER CRIMSON

TRADITIONAL D-PAD DESIGN ALSO INCLUDED.

Image: A detailed view of the specialized D-pad, designed for enhanced precision.

5.5 Hardware Customization

The Revolution 5 Pro offers extensive hardware customization. This includes interchangeable weights, various thumbstick sizes, and different thumbstick heads. All these accessories are stored in the included carry case, allowing you to tailor the controller's feel and ergonomics.



Image: The controller and its customization kit, including weights and various stick options.

5.6 Software Customization

For advanced customization, download the dedicated PC/Mac application from the NACON Gaming website. This application allows for programmable buttons, individual profile settings, software updates, and more, providing granular control over your controller's functions.

6. MAINTENANCE

To ensure the longevity and optimal performance of your NACON Revolution 5 Pro controller, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the controller regularly. For stubborn grime, a slightly damp cloth can be used, ensuring no moisture enters openings. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, store the controller and its accessories in the provided carry case to protect them from dust, spills, and physical damage.
- **Battery Care:** Avoid fully draining the battery frequently. For optimal battery life, charge the controller when the low battery indicator appears.
- **Cable Management:** Store the USB-C cable neatly to prevent kinks or damage.

7. TROUBLESHOOTING

If you encounter issues with your Revolution 5 Pro controller, refer to the following common problems and solutions:

- **Wireless Connection Drops:**

Ensure the USB-A wireless adapter is securely plugged into a port that is not exposed to excessive heat, especially on consoles like the PS5 where rear ports can get warm. Try moving the adapter to a different USB port or using a USB extension cable to position it away from heat sources. If the connection drops, try toggling the controller's console mode switch (e.g., from PS5 to PS4 and back) to re-establish the connection.

- **Slow Charging:**

Charging times can vary. Ensure you are using the provided USB-C cable and a compatible power source. Avoid playing while charging if you experience frequent disconnections, as this can sometimes exacerbate connection instability.

- **No Vibration on PS5:**

This is an expected limitation. The vibration function is not supported when the Revolution 5 Pro controller is used with PlayStation 5 consoles. Vibration is available on PS4 and PC.

- **Joystick Drift or Gyroscope Issues:**

The controller utilizes Hall Effect sensors designed to prevent stick drift. If you experience drift or gyroscope calibration issues, ensure the controller's firmware is up to date using the dedicated PC/Mac application. If problems persist, contact NACON support.

- **Buttons or Functions Not Responding:**

Verify that the controller is in the correct mode (PS5, PS4, or PC) for your system. Check for any custom profiles that might be interfering with button assignments. Update the controller's firmware via the dedicated application.

- **Bluetooth Audio Not Working on PC:**

Bluetooth audio is specifically designed for PS4 and PS5 modes. It is not available when the controller is operating in PC Mode.

8. SPECIFICATIONS

Feature	Detail
Model Number	Revolution 5 Pro
Connectivity	Wireless (USB-A adapter), Wired (USB-C to USB-A cable)
Compatibility	PlayStation 5, PlayStation 4, PC
Battery Life	Up to 10 hours (wireless)
Joystick Technology	Hall Effect (magnetic sensors)
Trigger Features	Adjustable Trigger Blockers
Back Buttons	4 Remappable Omron Micro-Switch Paddles
D-Pad	Interchangeable Specialized and Traditional designs

Customization	Interchangeable weights, thumbstick sizes, thumbstick heads
Audio	Bluetooth audio (PS4/PS5), 3.5mm wired headset port (PS4/PS5), External microphone included
Dimensions	2.36 x 6.38 x 4.49 inches
Weight	10.58 ounces (approx.)
Manufacturer	Nacon




9. WARRANTY AND SUPPORT



The NACON Revolution 5 Pro controller is manufactured by Nacon. For warranty information, technical support, or service inquiries, please refer to the official Nacon Gaming website or contact their customer support directly. Keep your proof of purchase for warranty claims.

Nacon Gaming Official Website: www.nacongaming.com

© 2023 NACON. All rights reserved. PlayStation, PS5, and PS4 are registered trademarks of Sony Interactive Entertainment Inc.

Related Documents - Revolution 5 Pro

	<p>Nacon Revolution 5 Pro Controller Start Guide</p> <p>A comprehensive start guide for the Nacon Revolution 5 Pro controller, covering setup, features, and troubleshooting for PlayStation 5, PlayStation 4, and PC.</p>
	<p>Nacon Revolution 5 Pro Controller Quick Start Guide</p> <p>A quick start guide for the Nacon Revolution 5 Pro controller, covering setup, wired/wireless connection, charging, vibration, trigger stoppers, and Bluetooth pairing for PlayStation 5 and PlayStation 4 consoles.</p>
	<p>Nacon Revolution 5 Pro : Guide de Démarrage Rapide pour PS5 et PS4</p> <p>Découvrez la manette Nacon Revolution 5 Pro avec ce guide de démarrage rapide. Apprenez à configurer, personnaliser et utiliser votre contrôleur pour PlayStation 5, PlayStation 4 et PC, et explorez ses fonctionnalités avancées.</p>

 The image shows the cover of the 'Nacon Revolution 5 Pro Controller - Start Guide'. It features a black and white photograph of the Nacon Revolution 5 Pro controller. The text 'nacon' is at the top, and 'REVOLUTION 5 PRO' is prominently displayed in the center. At the bottom, it says 'START GUIDE' and 'for PS5, PS4, PC'.	<p>Nacon Revolution 5 Pro Controller - Start Guide</p> <p>Comprehensive start guide for the Nacon Revolution 5 Pro controller, covering setup, features, modes, audio controls, and troubleshooting for PlayStation and PC.</p>
 This is another version of the 'Nacon Revolution 5 Pro Controller - Start Guide' cover, identical to the one in the first row. It shows the controller, the Nacon logo, and the title 'REVOLUTION 5 PRO START GUIDE for PS5, PS4, PC'.	<p>Nacon Revolution 5 Pro Controller Start Guide</p> <p>This guide provides essential information for setting up and using the Nacon Revolution 5 Pro controller, including features, customization options, connectivity for PS5, PS4, and PC, and technical support.</p>
<p>RIG</p> <p>RIG 600 PRO</p> <p>Wireless Gaming Headset</p>	<p>Nacon RIG 600 PRO Wireless Gaming Headset User Guide</p> <p>Comprehensive user guide for the Nacon RIG 600 PRO wireless gaming headset, covering setup for PS5, PS4, PC, and Nintendo Switch, pairing instructions, mode explanations, customization via the Companion App, safety precautions, and support information.</p>