Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > OMNIHIL /
- > OMNIHIL 20 Foot AC Power Cord for KEiiD CD Player Model KD-VD01 User Manual

OMNIHIL OMNI1018023250

OMNIHIL 20 Foot AC Power Cord User Manual

Compatible with KEiiD CD Player Model: KD-VD01

1. Introduction

This manual provides essential instructions for the safe and effective use of your OMNIHIL 20 Foot AC Power Cord. Please read this guide thoroughly before use and retain it for future reference.

2. PRODUCT OVERVIEW

The OMNIHIL 20 Foot AC Power Cord is designed to provide reliable power to compatible electronic devices, such as the KEiiD CD Player Model KD-VD01. It features a standard NEMA 1-15P plug for wall outlets and a C7 (figure-8) connector for the device.



Image 1: The OMNIHIL 20 Foot AC Power Cord, coiled for packaging.

3. SETUP INSTRUCTIONS

3.1 Unpacking

Carefully remove the power cord from its packaging. Inspect the cord for any visible damage. If any damage is observed, do not use the product and contact customer support.

3.2 Connecting the Power Cord

1. Locate the power input port on your KEiiD CD Player Model KD-VD01. This port typically resembles a figure-8 shape.



Image 2: The C7 (figure-8) connector end of the power cord.

- 2. Insert the C7 (figure-8) connector end of the OMNIHIL power cord firmly into the power input port of your KEiiD CD Player.
- 3. Locate a standard AC wall outlet (120V, 60Hz) that is easily accessible.



Image 3: The NEMA 1-15P plug end of the power cord.

- 4. Plug the NEMA 1-15P plug end of the OMNIHIL power cord into the wall outlet. Ensure it is securely seated.
- 5. Verify that the power cord is not kinked, pinched, or obstructed.

4. OPERATING INSTRUCTIONS

4.1 Basic Use

Once the power cord is correctly connected to both the KEiiD CD Player and a power outlet, the CD player is ready for operation according to its own instruction manual. The OMNIHIL power cord provides the necessary electrical connection.

- Ensure the power cord is fully inserted into both the device and the wall outlet.
- Do not force the connectors into incompatible ports.
- Avoid placing heavy objects on the power cord.

5. MAINTENANCE AND CARE

Proper care extends the life of your power cord and ensures safe operation.

- **Cleaning:** Disconnect the power cord from the wall outlet and the device before cleaning. Wipe the cord with a dry, soft cloth. Do not use liquid cleaners or abrasive materials.
- Storage: When not in use, coil the power cord loosely. Avoid tight coiling or bending at sharp angles, which can damage the internal wires. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect the power cord for any signs of wear, cuts, fraying, or damage to the insulation or connectors. If damage is found, discontinue use immediately and replace the cord.
- Safety: Do not attempt to repair a damaged power cord. Always replace it with a new, compatible cord.

6. TROUBLESHOOTING

If you encounter issues, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Device not powering on	Power cord not fully connected	Ensure both ends of the power cord are securely plugged in.
Device not powering on	Wall outlet has no power	Test the outlet with another device or check your circuit breaker.
Power cord feels hot	Overload or internal damage	Immediately disconnect the cord. Do not use it. Replace with a new cord.
Visible damage to cord	Physical wear or accident	Discontinue use and replace the power cord.

7. SPECIFICATIONS

Feature	Detail
Product Model Number	OMNI1018023250
Length	20 Feet (approximately 6.1 meters)
Connector Type (Device)	C7 (Figure-8)
Connector Type (Wall)	NEMA 1-15P (Type A, 2-prong)
Color	Black
Certifications	UL Listed, RoHS Compliant
Item Weight	15 ounces
Manufacturer	Zhongshan Master Light Source Electronic

8. WARRANTY AND SUPPORT

8.1 Warranty Information

This OMNIHIL product comes with a **5 Year Free Replacement Warranty**. This warranty covers defects in materials and workmanship under normal use. For warranty claims, please retain your proof of purchase.



Image 4: OMNIHIL 5 Year Warranty Logo.

8.2 Customer Support

For technical assistance, warranty claims, or any questions regarding your OMNIHIL power cord, please contact OMNIHIL customer support. You can find more information and contact details by visiting the OMNIHIL Store on Amazon.

Documents - OMNIHIL - OMNI1018023250 no relevant documents