

[Manuals.plus](#) /

> [Toro](#) /

> Toro Snow Blower Handle Knob, Bolt, and Washer Kit (114-3779, 136-7130, 107-3844) Instruction Manual

Toro 114-3779, 136-7130, 107-3844

Toro Snow Blower Handle Knob, Bolt, and Washer Kit Instruction Manual

Models: 114-3779 Handle Knob, 136-7130 Bolt, 107-3844 Washer

1. IMPORTANT SAFETY INFORMATION

Always wear appropriate safety gear when operating or maintaining your snow blower. Be aware of rotating parts and keep hands and clothing away from them. Never operate a gasoline-powered snow blower in an enclosed space to prevent carbon monoxide poisoning. Always follow the manufacturer's instructions for safe operation and maintenance.

Before performing any installation or maintenance, ensure the snow blower engine is off, cool, and the spark plug wire is disconnected to prevent accidental starting.

2. KIT CONTENTS

This kit contains genuine Toro replacement parts for your snow blower handle assembly. Please verify all parts are present and undamaged before proceeding with installation.

- **One (1) 114-3779 Handle Knob:** A black, star-shaped knob designed for securing the snow blower handle.



Image: Toro 114-3779 Handle Knob. This is a black, star-shaped knob with a threaded metal insert, used for securing the snow blower handle in position.

- **One (1) 136-7130 Handle Lock Bolt:** A metal L-shaped bolt with threading on one end, used in conjunction with the handle knob to secure the handle.



Image: Toro 136-7130 Handle Lock Bolt. This is a silver-colored, L-shaped metal bolt with threads on one end, designed to pass through the snow blower handle frame.

- **One (1) 107-3844 Washer:** A black, irregularly shaped metal washer designed to provide a secure seating surface for the handle knob and bolt.



Image: Toro 107-3844 Washer. This is a black, somewhat oval-shaped metal washer with a central hole, intended to be used with the handle bolt and knob.

3. COMPATIBILITY

This kit is compatible with many Toro 21" Power Clear Snow Blowers and 24" Snow Master Snow Throwers. Please verify that this kit fits your specific model before purchasing or installing.

Known compatible models include:

- 36001, 36002, 36003
- 38563, 38568
- 38720, 38721
- 38741, 38742, 38744
- 38752, 38753, 38756, 38757
- 39914, 39915, 39915T
- 39921, 39921T

4. INSTALLATION INSTRUCTIONS

Follow these steps to install the handle knob, bolt, and washer kit on your compatible Toro snow blower.

1. **Prepare the Snow Blower:** Ensure the snow blower engine is completely off and cool. Disconnect the spark plug wire to prevent any accidental starting during the installation process.
2. **Locate Handle Assembly:** Identify the area on your snow blower where the handle attaches to the main unit, typically secured by a knob and bolt assembly.
3. **Remove Old Components (if applicable):** If replacing existing parts, carefully unscrew the old handle knob, remove the bolt, and retrieve any old washers. Dispose of old parts responsibly.
4. **Position the Washer:** Place the new 107-3844 Washer onto the handle frame where the bolt will pass through. Ensure it is correctly seated.
5. **Insert the Bolt:** Insert the L-shaped 136-7130 Handle Lock Bolt through the handle frame and the washer. Ensure the L-bend of the bolt is correctly oriented to engage with the handle's design.
6. **Attach the Knob:** Thread the 114-3779 Handle Knob onto the exposed threaded end of the 136-7130

Handle Lock Bolt.

7. **Tighten Securely:** Hand-tighten the knob until the handle is firmly secured and there is no excessive movement. Do not overtighten, as this may damage the knob or handle components.
8. **Verify Stability:** Gently test the handle's stability to ensure it is securely fastened before reconnecting the spark plug wire.
9. **Reconnect Spark Plug:** Once installation is complete and verified, reconnect the spark plug wire.

5. MAINTENANCE

Regularly inspect the handle knob, bolt, and washer for signs of wear, damage, or looseness. If the handle feels loose during operation, stop the snow blower, disconnect the spark plug wire, and re-tighten the handle knob. Replace any worn or damaged components immediately with genuine Toro parts to ensure safe and proper operation of your snow blower.

6. SPECIFICATIONS

Product Type	Snow Blower Handle Knob, Bolt, and Washer Kit
Manufacturer	Toro
Part Numbers Included	114-3779 (Handle Knob), 136-7130 (Handle Lock Bolt), 107-3844 (Washer)
Approximate Kit Dimensions	5.08 x 5.08 x 5.08 cm (packaged)
Item Type Name	Knob Handle (Kit)

7. WARRANTY AND SUPPORT

As genuine Toro parts, these components are manufactured to high standards. For specific warranty information regarding replacement parts, please refer to your original snow blower's owner's manual or contact Toro customer support directly. If you are unsure if this kit fits your model or require further assistance, please contact the seller or an authorized Toro service center.

For additional support or to find an authorized service dealer, visit the official Toro website or consult your snow blower's documentation.