



Manuals.plus /

› EternaHora /

› EternaHora Vibrating Alarm Clock EN8813-1 Instruction Manual

EternaHora EN8813-1

EternaHora Vibrating Alarm Clock Instruction Manual

Model: EN8813-1

Brand: EternaHora

1. INTRODUCTION

The EternaHora Vibrating Alarm Clock is designed to provide effective wake-up assistance, particularly for heavy sleepers or individuals with hearing difficulties. It combines a large digital display with multiple alarm modes, including a powerful bed shaker, a loud buzzer, and a flashing wake-up light. The clock also features dimmable brightness, a snooze function, and integrated USB charging ports for convenience.

2. PACKAGE CONTENTS

- 1 x Desktop Digital Clock
- 1 x Vibrator (Bed Shaker)
- 1 x CR2016 Button Battery (pre-installed for memory backup)
- 1 x USB Cable (for power)
- 1 x Instruction Manual

3. PRODUCT OVERVIEW AND FEATURES

The EternaHora Vibrating Alarm Clock features a 6.5-inch LED display and a sleek mirror surface. It includes a separate bed shaker for silent or enhanced wake-up alerts.




Figure 3.1: The EternaHora Vibrating Alarm Clock with its dimensions (6.22 inches width, 3.4 inches height, 6.5-inch display) and the bed shaker (3.2 inches diameter) with its 5-foot cord. Also highlights the 2 USB charger ports, light sensor, and control buttons (M, +, -) on the side.

6.5 INCH MIRROR SURFACE

It also can be used as a mirror when needed




Figure 3.2: The 6.5-inch mirror surface of the EternaHora Vibrating Alarm Clock can also be used as a mirror. Icons below indicate key features: Bed Shaker, Night Light, USB Charging, Mirror, Dimmer, 12/24 Hours Display, Alarm, Snooze.

Key Features:

- **Large 6.5-inch LED Display:** Easy to read from a distance.
- **Dimmable Brightness:** 3 manual levels and auto-dimming for optimal viewing in various light conditions.
- **Multiple Wake-Up Modes:** Choose from buzzer, powerful bed shaker, or a combination of buzzer, shaker, and flashing light.
- **Adjustable Alarm Volume:** 4 levels for the buzzer.
- **Snooze Function:** Adjustable snooze duration from 5 to 60 minutes.
- **Night Light:** 4 levels of soft white light.
- **Dual USB Charging Ports:** Charge two external devices simultaneously.
- **Memory Function:** Built-in CR2016 button battery retains time and settings during power outages.
- **12/24 Hour Format:** Select preferred time display.

4. SETUP

4.1 Power Connection

1. Connect the provided USB cable to the DC power port on the back of the alarm clock.

2. Plug the other end of the USB cable into a 5V1A~5V2A USB power adapter (not included).
3. The clock display will illuminate.

4.2 Battery Backup

A CR2016 button battery is pre-installed to maintain time and settings during a power interruption. No user action is typically required for initial setup.

4.3 Placing the Bed Shaker

Connect the vibrator's cord to the designated port on the alarm clock. The 5-foot cord allows flexible placement. For optimal vibration, place the shaker:

- Under your pillow.
- Under your fitted sheet.
- Between your mattress and box spring.



Figure 4.1: Illustration of various placement options for the bed shaker: under a pillow, under a fitted sheet, or between a mattress and box spring.

5. OPERATING INSTRUCTIONS

5.1 Setting the Time

1. Press and hold the 'M' button (Mode) on the side of the clock until the hour digits begin to flash.
2. Use the '+' and '-' buttons to adjust the hour.
3. Press 'M' again to switch to minute adjustment. Use '+' and '-' to set the minutes.
4. Press 'M' a third time to select 12-hour or 24-hour format. Use '+' or '-' to toggle.
5. Press 'M' once more or wait a few seconds for the setting to save automatically.

5.2 Setting the Alarm

1. Press the 'M' button once to enter alarm setting mode. The alarm icon will appear, and the alarm time will flash.
2. Use the '+' and '-' buttons to adjust the alarm hour.
3. Press 'M' again to switch to alarm minute adjustment. Use '+' and '-' to set the minutes.
4. Press 'M' a third time to select the alarm mode:
 - **Buzzer:** Alarm sounds.
 - **Shaker:** Bed shaker activates.
 - **Buzzer + Shaker + Flashing Light:** All three activate.

Use '+' or '-' to cycle through the modes.

5. Press 'M' once more or wait a few seconds for the setting to save. The alarm icon will remain on the display, indicating the alarm is active.

5.3 Snooze Function

When the alarm sounds, press the large 'SNOOZE' button on the top of the clock to temporarily silence the alarm. The alarm will sound again after the set snooze duration.



SNOOZE MODE

Big Button Design At The Top Easy to close,
Alarm again after 5-60 minutes



Figure 5.1: The large snooze button located on the top of the EternaHora Vibrating Alarm Clock, designed for easy access to activate snooze mode.

Adjusting Snooze Duration:


The snooze time can be adjusted from 5 to 60 minutes. Refer to the full instruction manual for specific steps on adjusting this setting, typically done within the alarm setting mode or a dedicated snooze setting mode.

5.4 Display Brightness and Night Light

The clock offers both manual and automatic brightness adjustment for its display, along with a night light function.

0-100 Adjustable Brightness

Adjust by manual/auto



Low Light



Medium Light



High Light




Figure 5.2: Demonstrates the 0-100 adjustable brightness of the EternaHora Vibrating Alarm Clock, showing low, medium, and high light settings. The light sensor for automatic adjustment is also indicated.

Manual Brightness Adjustment:

Press the '+' or '-' buttons (outside of setting modes) to cycle through the 3 manual brightness levels (L0, L1, L2, L3). L0 is the darkest setting.

Automatic Brightness Adjustment:

The clock features a light sensor that can automatically adjust the display brightness based on ambient light conditions. Consult the full manual for instructions on enabling/disabling auto-dimming.

Night Light Function:

The clock can also function as a night light, offering 4 levels of soft white light. Specific controls for the night light are detailed in the comprehensive manual.



Figure 5.3: Shows the four brightness levels of the EternaHora Vibrating Alarm Clock's display, from 10% to 100% intensity.

5.5 USB Charging Ports

The clock is equipped with two USB charging ports on its side, allowing you to charge smartphones, tablets, or other USB-powered devices.



Figure 5.4: The two USB charger ports on the EternaHora Vibrating Alarm Clock, demonstrating their use for charging external devices.

Simply connect your device's USB charging cable to one of the ports. The clock must be powered on for the USB charging ports to function.

6. MAINTENANCE

6.1 Cleaning

To clean the clock, gently wipe the surface with a soft, dry cloth. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish or display.

6.2 Battery Replacement (Memory Backup)

The CR2016 button battery provides backup power for time and settings. If the clock consistently loses time or settings after a power outage, the backup battery may need replacement. Refer to the full manual for instructions on safely replacing the CR2016 battery.

7. TROUBLESHOOTING

- **Clock not powering on:** Ensure the USB power cable is securely connected to both the clock and a functional power adapter. Verify the power outlet is active.

- **Alarm not sounding/vibrating:** Check that the alarm is set and activated (alarm icon visible). Ensure the correct alarm mode (buzzer, shaker, or both) is selected. Verify the bed shaker is properly connected.
- **Display too dim/bright:** Adjust the brightness manually using the '+' or '-' buttons. If auto-dimming is enabled, ensure the light sensor is not obstructed.
- **Time/settings lost after power outage:** The CR2016 backup battery may be depleted and require replacement.
- **USB charging not working:** Ensure the clock is powered on. Check the USB cable connecting your device to the clock. Try a different USB port or device.

8. SPECIFICATIONS

Feature	Specification
Brand	EternaHora
Model Number	EN8813-1
Display Type	Digital LED
Display Size	6.5 inches
Product Dimensions (Clock)	6.22"W x 3.43"H
Vibrator Dimensions	3.2" Diameter
Vibrator Cord Length	5 ft
Power Source	Corded Electric (5V1A~5V2A DC)
Backup Battery	1 x CR2016 (included)
USB Charging Ports	2 ports
Material Type	Acrylonitrile Butadiene Styrene (ABS)
Item Weight	0.5 Pounds

9. WARRANTY INFORMATION

This EternaHora product comes with a limited warranty. For details regarding the warranty period and coverage, please refer to the warranty card included in your product packaging or contact customer support.

10. CUSTOMER SUPPORT

If you encounter any issues or have questions regarding your EternaHora Vibrating Alarm Clock, please contact our customer support team. We aim to provide a solution within 24 hours.

Contact: Please refer to the contact information provided in your product packaging or on the official EternaHora website.

