

[manuals.plus](#) /› [PocketBook](#) /› [PocketBook Charge Cover Instruction Manual for InkPad Color 3 and InkPad 4](#)**PocketBook HN-QI-PU-743G-NB-WW**

PocketBook Charge Cover Instruction Manual for InkPad Color 3 and InkPad 4

1. INTRODUCTION

This manual provides essential information for the proper use and care of your PocketBook Charge Cover. This cover is specifically designed to protect your PocketBook InkPad Color 3 and InkPad 4 e-readers while offering convenient wireless charging capabilities.

The PocketBook Charge Cover features a slim and elegant design, protecting your e-reader from dirt and scratches. All necessary connections on your e-reader remain freely accessible when the cover is installed. A key feature is its integrated wireless charging functionality, compatible with Qi chargers.




Figure 1: The PocketBook Charge Cover in blue, shown closed, protecting the e-reader.

2. SETUP AND INSTALLATION

To install your PocketBook e-reader into the Charge Cover, align the e-reader with the cover's internal frame. The e-reader is secured by a magnetic attachment system on the back, ensuring a firm fit. Gently press the e-reader into place until it is securely seated within the cover.

Ensure that the e-reader is correctly positioned to allow for proper alignment with the cover's features,

including the sleep/wake function and wireless charging coil.

3. OPERATING INSTRUCTIONS

3.1. Automatic Sleep/Wake Function

The PocketBook Charge Cover is equipped with an automatic sleep/wake function. When you close the cover, your e-reader will automatically enter sleep mode, conserving battery power. Opening the cover will wake the e-reader, allowing you to resume reading instantly.



Figure 2: Illustration showing the e-reader entering sleep mode when the cover is closed and waking up when opened, conserving battery.

3.2. Wireless Charging

The Charge Cover enables wireless charging of your PocketBook e-reader. To charge wirelessly, place the e-reader (with the cover attached) onto a compatible Qi wireless charging pad. The cover supports 5-watt charging power and is compatible with all Qi wireless chargers from version 1 onwards.

Ensure the e-reader is centered on the charging pad for optimal charging efficiency. The charging process will begin automatically.

Allows wireless **charging**




Figure 3: An illustration indicating the wireless charging area on the back of the cover, allowing for convenient power replenishment.

Qi standard compatible




Figure 4: The PocketBook InkPad 4 e-reader inside the Charge Cover, highlighting its compatibility with the Qi wireless charging standard.

4. MAINTENANCE

To maintain the appearance and functionality of your PocketBook Charge Cover, follow these guidelines:

- **Cleaning:** Use a soft, damp cloth to gently wipe the exterior of the cover. Avoid abrasive cleaners or solvents, as these can damage the material.
- **Protection:** While the cover is designed to protect your e-reader, avoid exposing it to extreme temperatures, direct sunlight for prolonged periods, or harsh chemicals.
- **Handling:** Handle the cover with care to prevent unnecessary wear and tear. The material is durable and pleasant to touch.



**Durable and pleasant
to touch material**

Figure 5: A hand holding the PocketBook Charge Cover, with a magnified inset showing the durable and pleasant-to-touch texture of the material.

5. TROUBLESHOOTING

- **Cover Detachment:** If the cover appears to detach easily from the e-reader, ensure that the e-reader is firmly seated and the magnetic attachment points are clean and unobstructed. Re-seat the e-reader if necessary.
- **Wireless Charging Inconsistency:** If wireless charging is not initiating or is intermittent, verify that the e-reader (within its cover) is precisely aligned with the center of the Qi charging pad. Obstructions between the cover and the charging pad can also interfere with charging.
- **Sleep/Wake Function Not Working:** Check that the e-reader is correctly installed in the cover and that no debris is preventing the cover from closing completely.

6. SPECIFICATIONS

Product Dimensions	5.59 x 0.51 x 8.15 inches
--------------------	---------------------------


Item Weight	6.7 ounces
Item Model Number	HN-QI-PU-743G-NB-WW
Special Features	Lightweight, Wireless Charging
Form Factor	Cover
Color	Blue
Manufacturer	PocketBook
Compatible Devices	PocketBook InkPad Color 3, PocketBook InkPad 4
Shell Type	Firm

7. WARRANTY AND SUPPORT

For information regarding warranty coverage and technical support for your PocketBook Charge Cover, please refer to the documentation provided with your original e-reader or visit the official PocketBook website. You may also contact PocketBook customer service directly for assistance.

Related Documents - HN-QI-PU-743G-NB-WW

 InkPad Lite 	<p><u>PocketBook InkPad Lite User Manual: Features, Setup, and Troubleshooting</u></p> <p>Comprehensive user manual for the PocketBook InkPad Lite e-reader, covering setup, device management, applications, reading features, settings, and troubleshooting. Learn about its specifications and how to get the most out of your device.</p>
 Color 	<p><u>PocketBook Color User Manual: Comprehensive Guide to Features and Operation</u></p> <p>Detailed user manual for the PocketBook Color e-reader. Covers setup, applications, reading features, settings, network connectivity, troubleshooting, and safety guidelines. Visit www.pocketbook.ch for support.</p>
 InkPad EO 	<p><u>PocketBook InkPad EO: User Manual and Guide</u></p> <p>Comprehensive user manual for the PocketBook InkPad EO e-reader, covering setup, features, specifications, and support. Learn to maximize your device's capabilities.</p>

<p>Quick Start Guide PocketBook®</p>	<p><u>PocketBook InkPad Lite Quick Start Guide</u> A concise and accessible quick start guide for the PocketBook InkPad Lite e-reader, covering device setup, operation, charging, and personalization. Includes essential information for new users.</p>
 <p>PocketBook® Era User Manual</p>	<p><u>PocketBook Era User Manual</u> Comprehensive user manual for the PocketBook Era e-reader, covering setup, features, applications, reading functions, settings, troubleshooting, and compliance information.</p>
 <p>PocketBook SENSE Felhasználói kézikönyv Firmware 5.14</p>	<p><u>PocketBook SENSE Felhasználói Kézikönyv</u> Ez a PocketBook SENSE e-olvasó felhasználói kézikönyve részletes útmutatást nyújt a készülék biztonságos használatához, beállításához, funkcióihoz és karbantartásához. Fedezze fel az összes funkciót és alkalmazást.</p>