

[Manuals.plus](#) /

› [cimetech](#) /

› cimetech Wireless Keyboard and Mouse Combo (Model: KF002+M013) User Manual

cimetech KF002+M013

cimetech Wireless Keyboard and Mouse Combo (Model: KF002+M013) User Manual

1. INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your cimtech Wireless Keyboard and Mouse Combo. This combo offers a stable 2.4G wireless connection, silent scissor-switch keys, a rechargeable mouse, and an ultra-slim, ergonomic design for enhanced productivity and comfort.

2. PACKAGE CONTENTS

- Wireless Keyboard
- Wireless Mouse
- USB Nano Receiver (stored in the mouse)
- 2 x AA Batteries (for keyboard)
- USB-C Charging Cable (for mouse)

3. PRODUCT OVERVIEW



Image 3.1: The cimotech Wireless Keyboard and Mouse Combo, featuring the full-size keyboard, ergonomic mouse, and the compact USB Nano receiver.



Image 3.2: Detailed dimensions of the wireless keyboard (36.8cm x 13.6cm x 2.0cm) and mouse (6.0cm x 11.7cm x 2.0cm), highlighting their ultra-slim profile.

3.1 Keyboard Features

- **Silent Scissor Switch Keys:** Provides a quiet and comfortable typing experience with responsive tactile feedback.
- **Full-Size Layout:** Includes a numeric keypad and 12 function keys for quick access to multimedia and system controls.
- **Ultra-Slim Design:** Measures only 2.0cm (0.8in) in thickness, saving desk space and enhancing portability.
- **Ergonomic Tilt:** Features an 8-degree tilted angle to help reduce wrist strain during extended use.



Image 3.3: Close-up view of the scissor switch key structure, illustrating the mechanism responsible for silent and stable keystrokes.



Image 3.4: An illustration of the keyboard's 8-degree tilted angle, designed to promote a more natural wrist position and reduce discomfort.

3.2 Mouse Features

- **Rechargeable:** Equipped with a built-in Lithium Polymer battery, rechargeable via USB-C.
- **Silent Clicks:** Designed for quiet operation, minimizing disturbance in shared environments.
- **Adjustable DPI:** Default setting of 1600 DPI, allowing users to customize cursor sensitivity.
- **Nano Receiver Storage:** The USB Nano receiver is conveniently stored in a compartment at the bottom of the mouse.

Type-c Fast Rechargeable



30 DAYS
Standby Time



1 HOURS
Full Charged



Image 3.5: The wireless mouse connected via a Type-C cable for fast recharging, indicating approximately 1 hour for a full charge.



Image 3.6: An overhead view of the mouse, highlighting the DPI adjustment button, advanced scroll wheel, and the compartment for the USB Nano receiver.

3.3 Connectivity and Compatibility

- **2.4G Wireless Connection:** Provides a stable and reliable connection up to 10 meters (33 feet).
- **Single Nano Receiver:** Both the keyboard and mouse connect via a single USB Nano receiver, simplifying setup and maintaining a tidy workspace.
- **Wide Compatibility:** Compatible with Windows XP / ME / Vista / 7 / 8 / 10 / 11 operating systems. Works with devices such as PCs, Laptops, Macbooks, Desktops, Chromebooks, and Smart TVs.



Image 3.7: Diagram showing the 2.4G wireless connection between the keyboard, mouse, and the USB receiver plugged into a laptop, emphasizing a stable connection without delays.



Image 3.8: Icons representing various compatible devices including PC, Laptop, Desktop, TV, and Tablet, demonstrating the broad compatibility of the combo.

4. SETUP INSTRUCTIONS

1. **Insert Keyboard Batteries:** Open the battery compartment on the underside of the keyboard and insert the two AA batteries provided, ensuring correct polarity.
2. **Locate USB Nano Receiver:** The USB Nano receiver is stored in a dedicated slot at the bottom of the wireless mouse. Gently remove it.
3. **Connect Receiver:** Plug the USB Nano receiver into an available USB port on your computer (PC, Laptop, Desktop, etc.).
4. **Power On Devices:** Locate the ON/OFF switches on both the keyboard and the mouse. Slide them to the 'ON' position.
5. **Automatic Connection:** The keyboard and mouse are designed for plug-and-play functionality and should connect automatically to your device within a few seconds. No additional software installation is required.

5. OPERATING INSTRUCTIONS

5.1 Keyboard Function Keys

The keyboard features 12 function keys (F1-F12) that can be used in conjunction with the **Fn** key for quick access to multimedia and system functions. These include volume control, media playback, email, and web browser shortcuts.

- **Fn + F1-F12:** Activate specific functions (e.g., Mute, Volume Down, Volume Up, Play/Pause, Previous Track, Next Track, Stop, Web Browser, Email, My Computer, Search, Favorites).
- **Note:** Some hotkeys may not be fully compatible with Mac operating systems.

5.2 Mouse DPI Adjustment

The mouse allows you to adjust its sensitivity (DPI) to suit your preference. The default setting is 1600 DPI.

- **DPI Button:** Press the DPI button, located near the scroll wheel, to cycle through available DPI settings.

5.3 Mouse Charging

The wireless mouse is rechargeable. When the battery is low, connect it to a power source.

- **Charging Port:** Use the provided USB-C charging cable to connect the mouse's Type-C port to a USB power adapter or a computer's USB port.
- **Charging Time:** Approximately 1 hour for a full charge.
- **Usage Time:** A full charge provides over 1 month of usage, depending on usage conditions.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the surfaces of the keyboard and mouse. Avoid using harsh chemicals or abrasive materials. Do not spray liquid cleaners directly onto the devices.
- **Keyboard Battery Replacement:** When the keyboard's power indicator light signals a low battery, replace the two AA batteries with new ones. Ensure correct polarity during installation.
- **Mouse Charging:** Regularly recharge the mouse when its power indicator shows low battery to ensure uninterrupted operation.
- **Storage:** When not in use for extended periods, turn off both the keyboard and mouse to conserve battery life. Store the USB Nano receiver in its designated slot within the mouse to prevent loss.

7. TROUBLESHOOTING

- **No Connection or Lag:**
 - Ensure the USB Nano receiver is securely plugged into a working USB port on your computer.
 - Verify that both the keyboard and mouse are turned ON using their respective power switches.
 - Check the battery levels. Replace the AA batteries in the keyboard or recharge the mouse if necessary.
 - Move the keyboard and mouse closer to the USB receiver to ensure they are within the 10-meter (33-foot) wireless range.
 - Try plugging the USB receiver into a different USB port on your computer.
- **Mouse Not Responding or Glitchy:**

- Recharge the mouse fully.
 - Adjust the DPI settings using the DPI button.
 - Turn the mouse off and then on again.
- **Keyboard Function Keys Not Working on Mac:**
 - Some multimedia hotkeys may have limited or no functionality when used with Mac operating systems. This is an expected compatibility characteristic.

8. SPECIFICATIONS

Feature	Detail
Model	KF002 (Keyboard) + M013 (Mouse)
Connectivity Technology	2.4G Radio Frequency, USB
Wireless Range	Up to 10 meters (33 feet)
Keyboard Dimensions	14.5 x 5.4 x 0.8 inches (36.8 x 13.6 x 2.0 cm)
Mouse Dimensions	2.4 x 4.6 x 0.8 inches (6.0 x 11.7 x 2.0 cm)
Item Weight	1.46 pounds (approx. 0.66 kg)
Keyboard Batteries	2 x AA batteries (included)
Mouse Battery	1 x Lithium Polymer battery (rechargeable)
Mouse Charging Port	USB Type-C
Mouse DPI	1600 (Default, adjustable)
Compatible Devices	Laptop, Personal Computer (PC, Mac, Desktop, Chromebook, Smart TV)
Operating Systems	Windows XP / ME / Vista / 7 / 8 / 10 / 11, Mac OS
Special Features	Ergonomic, Lightweight, Portable, Rechargeable Mouse, Silent Scissor Switch Keys
Date First Available	October 19, 2023
Manufacturer	cntorich

9. WARRANTY AND SUPPORT

The cimeteck Wireless Keyboard and Mouse Combo is covered by a **2-Year Warranty**. If any quality issues arise with your product within two years from the date of purchase, the manufacturer will provide a free replacement.

For further assistance or warranty claims, please contact cimeteck customer support through your purchase platform or the official cimeteck website.

