

[Manuals.plus](#) /

› [Pentel](#) /

› Pentel BLN75-L7 EnerGel Ballpoint Pen 0.5mm Limited Edition 7 Colors Set User Manual

## Pentel BLN75-L7

# Pentel BLN75-L7 EnerGel Ballpoint Pen 0.5mm Limited Edition 7 Colors Set User Manual

**Brand:** Pentel | **Model:** BLN75-L7

## INTRODUCTION

Thank you for choosing the Pentel BLN75-L7 EnerGel Ballpoint Pen 0.5mm Limited Edition 7 Colors Set. This set offers a superior writing experience with its quick-drying, smooth-flowing gel ink. Designed for comfort and precision, these retractable pens are perfect for various writing tasks, from detailed notes to creative projects. This manual provides essential information on setting up, operating, maintaining, and troubleshooting your new pen set.



Image: The Pentel EnerGel Limited Edition 7 Colors Pen Set, showcasing the elegant packaging and the vibrant assortment of pens.

## PRODUCT FEATURES

- **Quick-Drying Gel Ink:** The EnerGel ink formula dries rapidly, minimizing smudges and making it ideal for left-handed writers or quick note-taking.
- **Smooth Writing Experience:** Enjoy effortless and consistent ink flow for clear, dark, and precise lines.
- **Retractable Design:** A convenient click mechanism retracts the pen tip, eliminating the need for a cap and preventing accidental marks.
- **0.5mm Fine Point:** The 0.5mm tip provides a fine line, perfect for detailed work, journaling, and precise writing.
- **Limited Edition 7-Color Set:** A curated selection of seven distinct colors to add vibrancy and organization to your writing.
- **Durable Construction:** Made with recycled PC for the rear axis and crown, ABS for the knock and front shaft, elastomer grip, and iron clip for longevity.

# 様々な彩りを楽しめる 7色セット

ブルーブラック

青

0.5mm

セピア

茶

0.5mm

バーガンディー

赤

0.5mm

フォレスト  
グリーン

緑

0.5mm

オリーブ  
ブラック

黒

0.5mm

インディゴ  
ブラック

黒

0.5mm

ボルドー  
ブラック

黒

0.5mm




手帳などのスケジューリングに最適な 0.5mm

Image: A hand demonstrating the use of a Pentel EnerGel pen on a planner, highlighting the pen's suitability for scheduling and the variety of colors available in the set, along with close-ups of different ink colors and their 0.5mm line size.

# 速乾性インキ

すぐ乾くから  
手が汚れにくい



一般的な  
ゲルインキボールペン

乾きが速い

エナージェル

乾きが速い

※使用製品：エナージェル 0.7mm（黒）

Image: A visual comparison illustrating the quick-drying properties of Pentel EnerGel ink, showing how it prevents smudging on hands compared to conventional gel ink ballpoint pens.

美文字もなめらかに

龍



※使用製品：エナージェル 0.5mm インディゴブラック

Image: A close-up shot demonstrating the smooth writing capability of the Pentel EnerGel pen, showing a character being written cleanly on grid paper.

指紋ピッチグリップ

滑りにくく握りやすい

※使用製品：  
エナージェル 0.7mm

きらめくメタリックパーツ

Image: A detailed view highlighting the ergonomic, non-slip elastomer grip and the shimmering metallic clip of the Pentel EnerGel pen, emphasizing its comfortable hold and premium design elements.



Image: An organized display of multiple Pentel EnerGel pens, each showcasing its unique color and a corresponding sample of its 0.5mm ink line, illustrating the full spectrum of colors available in the set.

## SETUP

Your Pentel EnerGel pens are ready for immediate use right out of the box. No assembly or special setup is required.

1. **Unpack:** Carefully remove the pens from their packaging.
2. **Inspect:** Check each pen for any visible damage.
3. **Prepare for Use:** Simply click the top button to extend the pen tip.

## OPERATING INSTRUCTIONS

Using your Pentel EnerGel pen is straightforward and intuitive.

1. **Extend the Tip:** Press the push-button at the top of the pen firmly until the tip extends and locks into place.

2. **Write:** Hold the pen comfortably and apply light pressure to write on your desired surface. The smooth gel ink requires minimal effort.
3. **Retract the Tip:** When finished writing, press the side clip or the top button again (depending on the specific pen design) to retract the tip. This protects the tip and prevents ink from drying out or marking surfaces.

For optimal performance, store pens horizontally when not in use for extended periods.

## MAINTENANCE


The Pentel EnerGel pens are designed for durability and ease of use. The primary maintenance involves replacing the ink refill when it runs out.

### Replacing the Ink Refill:

1. **Unscrew the Barrel:** Gently twist the pen barrel counter-clockwise, usually at the grip section, to separate the front and back halves of the pen.
2. **Remove Old Refill:** Carefully pull out the empty ink refill from the front section.
3. **Insert New Refill:** Take a new Pentel EnerGel LR5 (0.5mm) refill. Ensure the small plastic cap on the tip of the new refill is removed before insertion. Insert the new refill firmly into the front section until it is seated correctly.
4. **Reassemble:** Align the two halves of the pen and twist clockwise until securely fastened.

Always use genuine Pentel EnerGel LR5 refills for best performance and compatibility.

# リフィル交換ができます



## ■ 適合リフィル：エナージェル 0.5mm



Image: A visual guide demonstrating the process of replacing the ink refill in a Pentel EnerGel pen, highlighting the needle chip and the "LRN5" engraving on the refill, along with a display of compatible EnerGel 0.5mm refills.

## TROUBLESHOOTING

| Problem                               | Possible Cause                                                                                                                             | Solution                                                                                                                                                                                                                                                             |
|---------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Ink not flowing smoothly or skipping. | <ul style="list-style-type: none"><li>Pen tip is dry.</li><li>Ink refill is running low or empty.</li><li>Air bubble in the ink.</li></ul> | <ul style="list-style-type: none"><li>Try scribbling on a scrap piece of paper to get the ink flowing.</li><li>Check the ink level. If low, replace the refill.</li><li>Hold the pen tip down and gently shake it a few times to dislodge any air bubbles.</li></ul> |

| Problem                           | Possible Cause                                                                                                                       | Solution                                                                                                                                                                                                                             |
|-----------------------------------|--------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Pen tip does not retract.         | <ul style="list-style-type: none"><li>◦ Mechanism jammed.</li><li>◦ Internal component misalignment.</li></ul>                       | <ul style="list-style-type: none"><li>◦ Ensure the pen is fully extended before attempting to retract.</li><li>◦ Gently twist the barrel to ensure it's securely assembled. If the issue persists, the pen may be damaged.</li></ul> |
| Ink smudges easily after writing. | <ul style="list-style-type: none"><li>◦ Writing surface is non-absorbent.</li><li>◦ Excessive ink flow (rare for EnerGel).</li></ul> | <ul style="list-style-type: none"><li>◦ Allow a few extra seconds for ink to dry on glossy or coated papers.</li><li>◦ Ensure you are using genuine Pentel EnerGel refills.</li></ul>                                                |

## SPECIFICATIONS

|                         |                                                  |
|-------------------------|--------------------------------------------------|
| Brand                   | Pentel                                           |
| Model Number            | BLN75-L7                                         |
| Writing Instrument Form | Ballpoint Pen (Gel Ink)                          |
| Point Type              | Ballpoint                                        |
| Line Size               | 0.5mm                                            |
| Ink Color               | Multicolor (7 Limited Edition Colors)            |
| Closure Type            | Retractable                                      |
| Grip Type               | Smooth Elastomer                                 |
| Material Type           | ABS, Recycled PC, Elastomer, Iron, Resin Plating |
| Item Weight             | 4.2 ounces (for the set)                         |
| Product Dimensions      | 0.6 x 0.4 x 5.8 inches (per pen, approximate)    |
| Number of Items         | 1 (Pack of 7 pens)                               |
| Date First Available    | October 21, 2023                                 |

## WARRANTY AND SUPPORT

Pentel products are manufactured to high-quality standards. For specific warranty information or support inquiries regarding your Pentel EnerGel pens, please refer to the official Pentel website or contact their customer service directly.

**Pentel of America, Ltd.**

[Official Website](#)

For contact details and FAQs, please visit the support section of their website.

## ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

### Name

Anonymous

### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question