

[Manuals.plus](#) /

› [Dreyoo](#) /

› Dreyoo 600/300W Dog House Heater with Thermostat User Manual

Dreyoo DR-Dreyoo-0827

Dreyoo 600/300W Dog House Heater with Thermostat User Manual

Model: DR-Dreyoo-0827

1. INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Dreyoo 600/300W Dog House Heater. Designed to provide warmth for pets in various outdoor shelters, this heater features a thermostat, two heating modes, and safety protections. Please read this manual thoroughly before installation and operation to ensure proper function and the safety of your pets.



Image: The Dreyoo pet house heater, black in color, shown with various animals including a dog, chicken, rabbit, and cat, indicating its multi-species application. The heater emits a warm glow.

2. SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons or pets.

- Ensure the heater is connected to a 120V AC power supply.
- Do not operate the heater with a damaged cord or plug.
- Keep the heater away from flammable materials.
- Do not immerse the heater in water or other liquids.
- Ensure proper ventilation around the heater.
- The heater features an insulated surface and anti-scalding protection, but direct prolonged contact should still be avoided.

- The power cord is steel-wrapped for bite resistance; however, regularly inspect the cord for any signs of damage.
- Unplug the heater when not in use or before cleaning.

3. PRODUCT FEATURES

- **Dual Heating Modes:** Select between 300W and 600W power settings.
- **Integrated Thermostat:** Automatically maintains a comfortable temperature range. Heating element stops at 78.8°F (26°C) and restarts below 68°F (20°C).
- **Fast Heating:** PTC heating element provides rapid warmth within 3 seconds.
- **Safety Protections:** Features temperature limiting, overheat protection, and an insulated surface to prevent burns.
- **Anti-Chew Cord:** 6-foot steel-wrapped power cord for enhanced durability and pet safety.
- **Quiet Operation:** Operates at less than 45dB, ensuring a peaceful environment for pets.
- **Easy Maintenance:** Magnetic removable hair guard on the back for convenient cleaning.
- **Compact Design:** Measures 6.7 x 6.3 x 4.7 inches, suitable for various pet shelters.



Image: A collage highlighting key features: a hand removing the magnetic anti-frizz net for cleaning, a close-up of the steel-protected cord, the waterproof power switch, and the anti-scalding grill design.

4. SETUP AND INSTALLATION

The Dreyoo pet house heater is designed for easy wall-mounting. Follow these steps for secure installation:

1. **Choose Location:** Select a position inside the pet house or enclosure that is higher than your pet's reach to prevent accidental contact. Ensure the area is clear of obstructions and flammable materials.
2. **Mount Bracket:** Use the provided safety bracket. Mark and drill holes for the screws. Securely attach the bracket to the wall using appropriate fasteners.
3. **Attach Heater:** Align the heater with the mounted bracket. Use the adjustable knobs to firmly attach the heater to the bracket. Ensure it is stable and cannot be easily dislodged.
4. **Plug In:** Connect the power cord to a standard 120V AC outlet. Ensure the outlet is protected from weather if used outdoors.



Step 1: Mount the bracket.



Step 2: Attach the heater.



Step 3: Secure the heater.

5. OPERATING INSTRUCTIONS

The Dreyoo pet house heater is designed for simple operation with its integrated thermostat and dual power modes.

1. **Power On/Off:** Use the inline switch on the power cord to turn the heater ON (I) or OFF (O).
2. **Select Heating Mode:** The heater offers two power settings: 300W and 600W. The switch allows you to select the desired wattage. For smaller spaces or milder cold, 300W may suffice. For larger spaces or colder conditions, use 600W.
3. **Thermostat Function:** The built-in thermostat automatically regulates the temperature.
 - The heating element will activate when the ambient temperature falls below 68°F (20°C).
 - The heating element will stop when the ambient temperature reaches or exceeds 78.8°F (26°C).
 - During periods when the heating element is off, the fan may continue to operate to circulate air.
4. **Monitoring:** Periodically check the temperature within the pet's enclosure to ensure it is comfortable.



Image: A visual representation of the heater's benefits, including quick heating, thermostat control, safety certification, and quiet operation, with a dog and cat resting comfortably nearby.

6. MAINTENANCE

Regular maintenance ensures the longevity and efficient operation of your Dreyoo pet house heater.

- **Cleaning the Hair Guard:** The heater features a magnetic removable hair guard on the back. Periodically remove this guard to clean accumulated pet hair and dust. This helps maintain airflow and heating efficiency.
- **Exterior Cleaning:** Wipe the exterior of the heater with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water. Ensure the heater is unplugged before cleaning.
- **Cord Inspection:** Regularly inspect the 6-foot steel-wrapped power cord for any signs of wear, cuts, or damage. If damage is found, discontinue use immediately and contact customer support.
- **Storage:** When not in use, store the heater in a dry, safe place, away from extreme temperatures and moisture.



Image: A close-up of the magnetic removable hair guard being detached from the heater, demonstrating the ease of cleaning pet fur and dust.

7. TROUBLESHOOTING

If you encounter issues with your Dreyoo pet house heater, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Heater not turning on.	No power, switch off, or thermostat not triggered.	<ul style="list-style-type: none">◦ Check if the power cord is securely plugged into a 120V outlet.◦ Ensure the inline power switch is in the "ON" (I) position.◦ Verify that the ambient temperature is below 68°F (20°C) for the heating element to activate.◦ Check the circuit breaker.
Heater blowing cold air, not heating.	Ambient temperature is above the thermostat's upper limit.	<ul style="list-style-type: none">◦ The heating element stops when the temperature reaches 78.8°F (26°C). The fan may continue to run to circulate air. This is normal operation.◦ The heating element will restart when the temperature drops below 68°F (20°C).
Reduced heating efficiency.	Blocked air intake/output, dirty hair guard.	<ul style="list-style-type: none">◦ Ensure the heater's air intake and output are not obstructed.◦ Clean the magnetic removable hair guard on the back of the unit.◦ Verify the selected heating mode (300W vs. 600W).
Unusual noises or odors.	Internal issue, dust accumulation.	<ul style="list-style-type: none">◦ Immediately unplug the heater.◦ Inspect for any visible damage or foreign objects.◦ If the issue persists after cleaning and inspection, discontinue use and contact customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	Dreyoo
Model Number	DR-Dreyoo-0827
Power Output	300W / 600W (Dual Mode)
Voltage	120V AC

Feature	Detail
Heating Element	PTC (Positive Temperature Coefficient)
Thermostat Range	Activates below 68°F (20°C), stops above 78.8°F (26°C)
Cord Length	6 feet (Steel-wrapped, Anti-Chew)
Product Dimensions (LxWxH)	6.7 x 6.3 x 4.7 inches
Item Weight	2.55 pounds
Heating Coverage	Up to 105 square feet (depending on insulation)
Special Features	Thermostat, Lightweight, Overheat Protection, Fast Heating, Noiseless, Magnetic Removable Hair Guard
Certifications	ROHS, UL
Indoor/Outdoor Usage	Outdoor

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact Dreyoo customer service directly. Contact details are typically available on the product packaging or the official Dreyoo website.

Please retain your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question