

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

> [Aanyhoh](#) /

> Aanyhoh LED Wall Lamp with Battery, USB Rechargeable Indoor Wall Sconces, Dimmable Cordless Wall Lamp with Remote Control, 360° Rotation, Battery Operated Wall Light for Bedroom, Black – 60CM Adjustable 60 cm User Manual

## Aanyhoh 1099-WG60

# Aanyhoh LED Wall Lamp User Manual

Model: 1099-WG60 | Brand: Aanyhoh

## 1. INTRODUCTION

---

Thank you for purchasing the Aanyhoh LED Wall Lamp. This battery-operated, USB rechargeable wall sconce offers versatile lighting with dimmable brightness, adjustable color temperature, and 360° rotation, controlled conveniently by a remote. This manual provides essential information for safe installation, operation, and maintenance of your new wall lamp.

### Package Contents:

- 2 x LED Wall Lights
- 2 x Battery Packs (built-in 3600mAh)
- 2 x USB to Type-C Charging Cables
- 2 x Fixing Screws sets
- 1 x Installation Manual

## 2. SAFETY INFORMATION

---

**Important Warning: Do not use a charger with more than 5V/2A to charge the wall lamp. Fast chargers can easily cause damage to the battery.**

- Ensure the product is used indoors only.
- Keep the lamp away from high temperatures and flammable objects.
- Do not attempt to disassemble or modify the lamp.
- Always ensure the battery pack is securely inserted before use.
- Keep out of reach of children.

## 3. PRODUCT OVERVIEW

---

The Aanyhoh LED Wall Lamp features a sleek, minimalist design with a rotatable light bar and a magnetic, removable battery compartment for easy charging.



Image: Overview of the Aanyhoh LED Wall Lamp, showing its main components and an example of it installed in a bedroom setting.



Image: Detailed dimensions of the wall lamp and a visual representation of the included remote control and USB-C charging cables.

### Key Features:

- **USB Rechargeable:** Built-in 3600mAh battery for cordless operation.
- **Removable Battery Compartment:** Easily detach the battery for charging without removing the entire lamp.
- **Dimmable Brightness:** Adjust light intensity from 10% to 100%.
- **Adjustable Color Temperature:** Switch between 3000K (warm white) and 6000K (cool white).
- **360° Rotation:** The light bar can be rotated to direct light as needed.
- **Remote Control:** Conveniently manage all functions from a distance.
- **Eye-Friendly Light:** Designed to be flicker-free to reduce eye fatigue.

## 4. SETUP & INSTALLATION

---

### Mounting the Lamp:

1. Choose a suitable location on your wall.
2. Use the provided fixing screws to securely attach the mounting base to the wall.
3. Align the wall lamp with the mounting base and slide it into place. The lamp is held by a rubber ring around the base.
4. Adjust the light bar to your desired angle using its 360° rotation feature.

# Eye-Friendly Reading light

Flicker free light to avoid fatigue or strain



Image: Examples of the Aanyhoh LED Wall Lamp installed in different interior spaces, demonstrating its versatile application.

## Charging the Battery:

1. Gently pull the magnetic battery compartment from the lamp body.
2. Connect the provided USB to Type-C charging cable to the charging port on the battery pack.
3. Connect the other end of the USB cable to **5V/1A or 5V/2A** USB power adapter (not included).
4. The charging indicator light will illuminate. Charging typically takes 4-5 hours.
5. Once fully charged, the indicator light may change or turn off. Disconnect the cable and reinsert the battery pack into the lamp body.



## Night Light Mode

You can safely find your way around at night without directing into eyes



### Multi-functional keys

Short press: Night light mode

Long press: lock the remote control

Image: Close-up view of the removable magnetic battery compartment and the USB-C charging port.

## 5. OPERATING INSTRUCTIONS

---

The Aanyhoh LED Wall Lamp can be operated using the included remote control or the power button on the battery pack.

### Using the Remote Control:




Image: Visual demonstration of the lamp's adjustable color temperature (3000K-6000K) and stepless dimming (10%-100%).

- **ON/OFF Button:** Press to turn the lamp on or off.
- **Brightness Adjustment (Sun Icon):** Press the '+' button to increase brightness, '-' button to decrease brightness (10%-100% stepless dimming).
- **Color Temperature Adjustment (WW/M/CW):**
  - **WW (Warm White):** Sets the light to 3000K.
  - **M (Mixed):** Sets the light to 4000K.
  - **CW (Cool White):** Sets the light to 5000K or 6000K.
- **Night Light Mode (Moon Icon):** Short press to activate a low-brightness, soft light mode, ideal for night use without harsh glare. Long press to lock the remote control.



Image: Illustration of the Night Light Mode feature and the multi-functional keys on the remote control.

### **Manual Operation:**

A power button is located on the battery pack. Press this button to manually turn the lamp on or off.

## **6. MAINTENANCE**

---

### **Cleaning:**

To clean the lamp, gently wipe it with a soft, dry cloth. Do not use abrasive cleaners, solvents, or liquids that could damage the finish or electrical components.

### **Battery Care:**

- Charge the battery fully before first use.
- Recharge the battery when the light output becomes noticeably dim.
- Avoid completely draining the battery frequently, as this can reduce its lifespan.
- If storing the lamp for an extended period, charge the battery to about 50% and recharge every 3-6 months to maintain battery health.

## **7. TROUBLESHOOTING**

---

- **Lamp does not turn on:**
  - Ensure the battery pack is fully charged and correctly inserted.
  - Check if the remote control batteries need replacement.
  - Verify the lamp's manual power button is in the ON position.
- **Light flickers or is unstable:**
  - This may indicate a low battery. Recharge the battery pack.
  - Ensure you are using a charger that does not exceed 5V/2A. Using an incompatible charger can cause damage and erratic behavior.
- **Remote control not responding:**
  - Check and replace the remote control batteries if necessary.
  - Ensure there are no obstructions between the remote and the lamp.

- If the remote was locked (long press of moon icon), long press it again to unlock.
- **Brightness or color temperature cannot be adjusted:**
  - Ensure the remote control is functioning correctly (see above).
  - The lamp may be in a specific mode that limits adjustment; try turning it off and on again.

## 8. SPECIFICATIONS

---

| Attribute             | Value                                      |
|-----------------------|--|
| Brand                 | Aanyhoh                                    |
| Model Number          | 1099-WG60                                  |
| Light Fixture Form    | Sconce                                     |
| Style                 | Minimalist                                 |
| Material              | Aluminum / Acrylic                         |
| Input Voltage         | USB to Type-C (5V/1A recommended)          |
| Light Source          | LED  |
| Consumption           | 6W   |
| Color Temperature     | 3000K-6000K (Dimmable)                     |
| Dimmable              | Yes (10%-100%)                             |
| Fixture Color         | Black                                      |
| Battery Capacity      | 3600mAh (Lithium Metal)                    |
| Charging Time         | Approx. 4-5 hours                          |
| Continuous Work Time  | More than 10 hours (at highest brightness) |
| Recommended Room Size | 5-10 m <sup>2</sup>                        |
| Product Dimensions    | 10 x 6 x 60 cm                             |
| Product Weight        | Approx. 950 g                              |

For detailed energy efficiency information, please refer to the EPREL database:

<https://eprel.ec.europa.eu/qr/1841766>

## 9. WARRANTY & SUPPORT

---

For information regarding product warranty, please refer to the terms and conditions provided at the time of purchase or contact your seller directly. If you encounter any issues not covered in this manual, please reach out to the manufacturer or seller for assistance.