

## Garvee Electric Fireplace 60 Inch

# GARVEE 60-Inch Wall Mounted Electric Fireplace Instruction Manual

Model: Electric Fireplace 60 Inch | Brand: Garvee

---

[Introduction](#)   [Safety Information](#)   [Package Contents](#)   [Setup & Installation](#)   [Operating Instructions](#)   [Maintenance](#)   [Troubleshooting](#)   [Specifications](#)   [Warranty & Support](#)

## 1. INTRODUCTION

Thank you for choosing the GARVEE 60-inch Electric Fireplace. This manual provides essential information for the safe and efficient operation of your new appliance. This electric fireplace is designed for wall-mounted or recessed installation, offering adjustable flame colors, brightness levels, and two heating modes (750W/1500W) to provide supplemental zone heating for up to 400 square feet. It features both a touch screen control panel and a remote control for convenient operation, along with a timer function for automatic shut-off.

## 2. SAFETY INFORMATION

Please read all instructions carefully before installation and operation. Failure to follow these instructions may result in fire, electric shock, or personal injury.

- This appliance is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the fireplace.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect heater, turn controls to off, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.

- This fireplace is equipped with an auto-heat kill safety feature to prevent overheating.
- Ensure the power source is appropriate for the appliance (120V AC, 60Hz).

### 3. PACKAGE CONTENTS

---

Upon opening the package, please ensure all components are present and undamaged:

- GARVEE Electric Fireplace Unit (60 Inch)
- Remote Control
- Clear Crystal Media (for flame bed decoration)
- Log Pieces (for flame bed decoration)
- Mounting Hardware (screws, brackets for wall mounting)
- Instruction Manual

The fireplace offers two decorative options for the flame bed: clear crystals or log pieces. You can choose the option that best suits your aesthetic preference or switch them out depending on the season.

### 4. SETUP & INSTALLATION

---

The GARVEE Electric Fireplace offers versatile installation options to fit various room designs. It can be installed as a wall-mounted unit, recessed into a wall, or framed into a custom TV feature wall.

#### 4.1. Wall-Mounted Installation

For wall-mounted installation, ensure you have a sturdy wall capable of supporting the fireplace's weight. Use the provided mounting brackets and screws. Mark the desired height and position on the wall, ensuring it is away from combustible materials and has access to a power outlet. Secure the mounting bracket to wall studs, then carefully lift and attach the fireplace unit to the bracket.



Figure 1: Wall-mounted and recessed installation options. The diagram illustrates how the fireplace can be mounted directly onto a wall or integrated into a recessed opening, showing air intake and outlet for proper ventilation.

## 4.2. Recessed Installation

Recessed installation requires creating an opening in your wall. Refer to the product specifications for precise dimensions (e.g., 6.3"D x 60"W x 17.72"H for the 60-inch model). Ensure adequate clearance around the unit for ventilation and maintenance. The unit is designed to be slim, approximately 4.3 inches deep, allowing for a clean, flush finish when recessed. Secure the fireplace within the framed opening according to the detailed instructions provided in the full manual.

## CORRESPONDING DIMENSION



Figure 2: Detailed dimensions for the 60-inch fireplace, showing its ultra-thin design and illustrating both recessed and wall-mounted installation methods with corresponding mounting hardware.

### 4.3. Framed TV Feature Wall Installation

For a custom built-in look, the fireplace can be integrated into a framed TV feature wall. This method combines the recessed installation with custom carpentry to create a seamless aesthetic. Plan your framing carefully to accommodate the fireplace dimensions and ensure proper ventilation. This approach provides a modern and polished appearance, making the fireplace a central design element.



Figure 3: The GARVEE electric fireplace integrated into a stone feature wall in a modern living room, showcasing a recessed installation with a TV mounted above.

#### 4.4. Media Bed Setup

After installation, place your preferred decorative media (clear crystals or log pieces) into the flame bed. Ensure they are evenly distributed for the best visual effect.



Figure 4: The flame bed of the fireplace, illustrating the choice between crystal stone effect and carbon log rock effect for customization.

## 5. OPERATING INSTRUCTIONS

The GARVEE Electric Fireplace can be operated using either the touch screen control panel located on the unit or the included remote control.

### 5.1. Control Panel & Remote Control

The touch screen control panel provides direct access to all functions. The remote control offers the convenience of adjusting settings from a distance.

## Remote Control & LED Touch Screen



### Timer

Timer 1-8 Hours



### Temperature

Temperature 62°F-82°F



### Heater

Heater 750/1500W



### Flame

Dimmer L1-L5  
Brightness



### Color

Flame Color 12 colors



### Power

ON/OFF




Figure 5: The remote control and the LED touch screen panel, detailing buttons for timer, temperature, heater, flame, color, and power.

### 5.2. Functions

- **Power On/Off:** Use the power button on the unit or remote to turn the fireplace on or off.
- **Flame Color Adjustment:** Cycle through 12 different flame colors using the dedicated button on the remote or touch panel.
- **Flame Brightness/Speed:** Adjust the flame brightness (L1-L5) and speed to create your desired ambience.
- **Heating Modes:** Select between 750W and 1500W heating modes. The 750W mode is suitable for maintaining warmth, while the 1500W mode provides faster heating for larger areas. The heating function can be operated independently of the flame effect.
- **Temperature Control:** Set your desired room temperature between 62°F and 82°F. The fireplace will automatically adjust its heating output to maintain this temperature.
- **Timer Function:** Set an automatic shut-off timer for 1 to 8 hours. This is ideal for nighttime use or when you want the fireplace to turn off after a specific duration.
- **Sleep Mode:** Utilize the sleep mode function for reduced light output during rest periods.

### 5.3. Visual Effects

The fireplace offers a variety of flame colors and brightness levels to suit any mood or decor. You can switch

between vibrant reds, cool blues, serene greens, and more, creating a dynamic visual experience.

Your browser does not support the video tag.

Video 1: Demonstration of the GARVEE Electric Fireplace's 12 adjustable flame colors. This video showcases the various color options available, allowing users to customize the ambiance of their space.

Your browser does not support the video tag.

Video 2: A short video highlighting the superior flame quality and various flame color options of the GARVEE electric fireplace, demonstrating its visual appeal.

## 6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your electric fireplace.

- Cleaning:** Always unplug the fireplace before cleaning. Use a soft, damp cloth to wipe down the exterior surfaces. For the glass panel, use a glass cleaner and a soft, lint-free cloth. Do not use abrasive cleaners or sprays directly on the unit.
- Ventilation:** Ensure that the air inlets and outlets are not blocked by dust or debris. Periodically clean the vents with a soft brush or vacuum cleaner attachment.
- Storage:** If storing the fireplace for an extended period, ensure it is clean and dry. Store it in a cool, dry place, preferably in its original packaging.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Fireplace does not turn on.	No power to the unit; power switch off; remote control batteries dead.	Check power outlet and circuit breaker. Ensure the main power switch on the unit is on. Replace remote control batteries.
No heat output.	Heating function is off; temperature setting is too low; safety cut-off activated.	Activate heating function. Increase desired temperature. Unplug unit for 15 minutes to reset safety cut-off, then plug back in.
Flame effect not working.	Flame effect is off; LED lights malfunction.	Activate flame effect. If issue persists, contact customer support.
Unusual noise from the unit.	Fan noise during heating; foreign object in fan.	A slight fan noise is normal during heating. If noise is excessive or unusual, turn off and unplug the unit, then inspect for obstructions.

## 8. SPECIFICATIONS

- Brand:** Garvee
- Model Name:** Electric Fireplace
- Product Dimensions:** 6.3"D x 60"W x 17.72"H
- Material:** Metal
- Finish Type:** Polished
- Installation Type:** Wall Mount, Recessed
- Power Source:** Corded Electric

- **Heat Output:** 750 Watts / 1500 Watts (adjustable)
- **Heating Coverage:** Up to 400 sq ft
- **Special Features:** Adjustable Flame, LED Flame, Timer, Touch Screen, Remote Control
- **Flame Colors:** 12 options
- **Flame Brightness Levels:** 5 options
- **Temperature Range:** 62°F - 82°F
- **Included Components:** Remote Control, Crystal Media, Log Pieces
- **Item Weight:** 68.1 pounds
- **Ventilation Type:** Vent Free
- **Certifications:** ETL Certified

## 9. WARRANTY & SUPPORT

---

The GARVEE Electric Fireplace comes with a Limited Warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included in your product packaging or contact GARVEE customer support directly.

For technical assistance, troubleshooting, or parts replacement, please contact GARVEE customer support. Contact information can typically be found on the product packaging or the official GARVEE website.

- **Returns:** This product is eligible for 30-day easy returns.
- **Customer Support:** Available for assistance with product inquiries and issues.