**NOMA 2521037NG**

# NOMA Circle of Light - Instruction Manual

Model: 2521037NG

## Introduction

This manual provides comprehensive instructions for the safe and efficient use of your NOMA Circle of Light. This battery-operated decorative light features 45 warm white LEDs within a 30cm black metal frame, designed to enhance both indoor and outdoor spaces with its elegant illumination and convenient timer function.

## Safety Information

- Ensure the product is placed in a stable location, especially when hanging.
- This product is water resistant and suitable for outdoor use, but avoid submerging it in water.
- Do not dispose of batteries in a fire.
- Keep batteries out of reach of children.
- Use only the specified battery type (3 x AA batteries).
- Do not mix old and new batteries, or different types of batteries.

## Package Contents

- 1 x NOMA Circle of Light (30cm diameter, 45 Warm White LEDs)

## Setup

1. **Battery Installation:** Locate the battery compartment. Remove the cover and insert 3 x AA batteries, ensuring they are placed with the negative (-) or flat end against the spring. Duracell® alkaline batteries are recommended for optimal performance. Replace the battery compartment cover securely.
2. **Placement:** The NOMA Circle of Light is designed for both indoor and outdoor use. Choose a suitable location where it can be hung securely. The product features a 1.5m lead cable from the battery box to the light circle, offering flexibility in placement.



*Figure 1: Close-up view of the battery compartment and control switch. This image illustrates where to insert batteries and how to access the ON/OFF/TIMER switch.*

## Operating Instructions

The NOMA Circle of Light features a multi-function switch located next to the battery compartment:

- **ON Position:** Slide the switch to the 'ON' position to keep the lights continuously illuminated.
- **TIMER Position:** Slide the switch to the 'TIMER' position to activate the built-in timer function. In this mode, the lights will remain lit for 6 hours, then automatically turn off for 18 hours, before coming back on at the same time the next day.
- **OFF Position:** Slide the switch to the 'OFF' position to turn the lights off completely and disable the timer function.




*Figure 2: The NOMA Circle of Light in operation, showcasing its warm white illumination. This image demonstrates the product's appearance when lit.*

## Maintenance

- **Battery Replacement:** When the lights begin to dim, it is time to replace the batteries. Follow the battery installation steps in the Setup section. Always replace all three batteries at once with new ones.
- **Cleaning:** To clean the light circle, gently wipe it with a soft, dry cloth. Do not use abrasive cleaners or immerse the product in water.
- **Storage:** When not in use for extended periods, remove the batteries to prevent leakage and store the light circle in a cool, dry place.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|

| Problem | Possible Cause | Solution |
|---|---|---|
| Lights do not turn on. | Batteries are dead or incorrectly installed. Switch is in 'OFF' position. | Replace batteries, ensuring correct polarity. Slide switch to 'ON' or 'TIMER' position. |
| Lights are dim or flicker. | Batteries are low. | Replace all three AA batteries with fresh ones. |
| Timer function not working. | Switch is not in 'TIMER' position. | Ensure the switch is firmly set to the 'TIMER' position. |

## Specifications

| Feature | Detail |
|---|---|
| Model Number | 2521037NG |
| Diameter | 30 cm |
| Light Source | 45 Warm White LEDs |
| Power Source | Battery Powered (3 x AA batteries, not included) |
| Voltage | 4.5 Volts |
| Color Temperature | 2700 Kelvin |
| Material | Metal |
| Indoor/Outdoor Usage | Outdoor (Water Resistant) |
| Special Feature | 6-hour Timer |
| Lead Cable Length | 1.5m |
| Item Weight | 0.28 Kilograms (approx. 9.9 ounces) |
| Manufacturer | LeisureGrow |

## Additional Product Views




*Figure 3: Multiple NOMA Circle of Light units displayed together, illustrating potential decorative arrangements.*



*Figure 4: Another perspective of the NOMA Circle of Light, highlighting its circular design and LED arrangement.*

## Warranty and Support

Please retain this instruction manual for future reference, as it contains important information regarding the product's operation and maintenance.
For support or inquiries, please contact LeisureGrow Products Ltd., the manufacturer of NOMA products:

**Address:** Dewmead Farm, New Inn Road, Hinxworth, Hertfordshire SG7 5HG, United Kingdom

**Email:** consumerservices@leisuregrow.com

**Phone:** +44 (0) 1462 744 500

**Website:** www.noma.co.uk

For more information about the "Fit & Forget battery box" feature, you can scan the QR code found on the product packaging or visit: https://qrco.de/bbpAzz

© 2024 NOMA. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question