

- [Manuals.plus](#) /
- › [warmiplanet](#) /
 - › Warmiplanet 52-Inch Flush Mount Ceiling Fan User Manual

warmiplanet WICF06-4

Warmiplanet 52-Inch Flush Mount Ceiling Fan User Manual

Model: WICF06-4 | Brand: warmiplanet

1. INTRODUCTION

Thank you for choosing the warmiplanet 52-inch Flush Mount Ceiling Fan. This fan is designed to provide optimal air circulation and lighting for your indoor spaces. Featuring a quiet, reversible DC motor, a dimmable LED light with adjustable color temperature, and a convenient multi-function remote control, this fan combines modern design with advanced functionality. Please read this manual thoroughly before installation and operation to ensure safe and efficient use.



Image: Two warmiplanet 52-inch flush mount ceiling fans with lights, a remote control, and interchangeable fan blades.

2. IMPORTANT SAFETY INFORMATION

To reduce the risk of electric shock, fire, or injury to persons, always follow these basic precautions:

- Read all instructions carefully before installing the fan.
- Ensure the power is turned off at the circuit breaker before beginning installation or performing any maintenance.
- All wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.
- The fan must be mounted to a ceiling outlet box or support system capable of supporting a fan weight of 31.7 pounds (14.4 kg).
- Do not operate the fan with a dimmer switch. Use only the provided remote control for speed and light adjustments.

- Maintain a minimum clearance of 7 feet from the bottom edge of the fan blades to the floor.
- This fan operates on 120 Volts AC.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged:

- Ceiling Fan Motor Assembly
- Fan Blades (3)
- LED Light Kit
- Remote Control (requires 4 AAA batteries, included)
- Mounting Bracket
- Canopy and Canopy Screws
- Hardware Pack (screws, wire nuts, washers)
- Instruction Manual

4. SETUP AND INSTALLATION

For a detailed visual guide, please refer to the official installation video provided by warmiplanet:

Your browser does not support the video tag.

Video: Warmiplanet 52 inch ceiling fan installation video. This video demonstrates the step-by-step process of installing the ceiling fan, including wiring and assembly.

Installation Steps:

1. **Turn Off Power:** Before starting, ensure the power supply to the ceiling fan location is turned off at the main circuit breaker.
2. **Install Mounting Bracket:** Secure the mounting bracket to the ceiling outlet box. Ensure it is firmly attached and can support the fan's weight.
3. **Connect Wiring:** Connect the home wires to the receiver. Typically, Black is for Live Wire, White for Neutral Wire, and Green for Ground Wire. Follow the wiring diagram provided in the manual.
4. **Hang Motor Assembly:** Carefully hang the fan motor assembly onto the mounting plate. Rotate it until it is fixed securely.
5. **Attach Fan Blades:** Securely attach the three fan blades to the motor housing using the provided screws.
6. **Install LED Light Kit:** Connect the LED light kit wires and attach the light kit to the bottom of the fan motor assembly.
7. **Install Canopy:** Raise the canopy to cover the mounting bracket and secure it with the canopy screws.
8. **Restore Power:** Once installation is complete, turn the power back on at the circuit breaker.

Space-Saving Designed for Low Floors



The Height of the Whole Machine is Only **11.3in**



Ours

**Easy modular installation
reduces electrician costs**



Other

Complex and time-consuming
installation steps

Image: Illustration showing the space-saving design (11.3 inches height) and easy modular installation of the fan, reducing electrician costs compared to traditional fans.

5. OPERATING INSTRUCTIONS

Your warmiplanet ceiling fan is controlled by a multi-function remote. Ensure the remote has fresh AAA batteries installed.

Multi-functional Remote Control



Timer Setting

Easy-to-use Timer Option



6 Wind Speeds



3 Color Temperature
& Dimmable



Natural Breezes



Reversible
Function

Image: Close-up of the multi-functional remote control, highlighting buttons for 6 wind speeds, 3 color temperatures, dimmable light, natural breeze mode, and timer options (1H, 4H).

Remote Control Functions:

- **Power On/Off:** Press the power button to turn the fan and light on or off.
- **Fan Speed:** Select from 6 available speeds (buttons 1-6) to adjust airflow.

- **Light Control:**

- Press the light button to turn the light on/off.
- Change Color Temperature: Cycle through cool white (6000K), natural light (4000K), and warm white (3000K) by pressing the light color temperature button.
- Dimmable Light: Press and hold the light button to adjust brightness from 10% to 100%. The light has a memory function and will retain the last brightness setting.

- **Timer Function:** Set the fan to turn off automatically after 1 hour (1H) or 4 hours (4H).

- **Reversible Motor:** The fan features a reversible DC motor. A switch on the motor housing allows you to change the direction of the blades.

- **Summer Mode (Counter-Clockwise):** Downward airflow creates a cooling effect.
- **Winter Mode (Clockwise):** Upward airflow circulates warm air trapped near the ceiling.

More Lighting Options



3000K Warm Light



4000K Natural Light



6000K Cool White Light



Image: The ceiling fan demonstrating its three color temperature options: 3000K Warm Light, 4000K Natural Light, and 6000K Cool White Light, along with 10-100% dimmable functionality.

Suitable for All Seasons



Image: Illustration showing the fan's reversible function for summer (counter-clockwise updraft for cooling) and winter (clockwise downdraft for warmth).

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the finish or electrical components.
- **Blade Cleaning:** Dust the fan blades regularly to prevent dust buildup, which can affect airflow and balance.
- **Tighten Screws:** Periodically check all screws and connections on the fan and mounting hardware to ensure they are secure.
- **Light Source:** The LED light source is designed for long-term use. If replacement is ever needed, please contact warmiplanet customer support.

7. TROUBLESHOOTING

If you experience issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low or not paired.	Check circuit breaker; Ensure all wire connections are secure; Replace remote batteries or re-pair remote.
Light does not work	Loose wire connection to light kit; LED light kit failure; Remote control issue.	Check light kit wiring; Contact customer support for replacement; Check remote batteries.
Fan is noisy	Loose screws; Fan blades unbalanced; Motor issue.	Tighten all screws; Ensure blades are securely attached and balanced; Contact customer support if noise persists.
Fan wobbles	Loose mounting bracket; Unbalanced blades; Loose blade screws.	Ensure mounting bracket is secure; Check and tighten all blade screws; Balance blades if necessary.
Remote not responding	Low or dead batteries; Remote not paired; Interference.	Replace batteries (4 AAA); Re-pair remote with fan (refer to pairing instructions in full manual); Ensure no strong interference sources nearby.

8. SPECIFICATIONS

Feature	Detail
Brand	warmiplanet
Model Name	WICF06-4
Product Dimensions	52"D x 52"W x 11"H
Item Weight	31.7 Pounds
Number of Blades	3
Blade Material	Engineered Wood
Power Source	DC
Voltage	120 Volts

Feature	Detail
Wattage	28.00 Watts
Light Type	LED
Luminous Flux	2200 Lumen
Color Temperature	3000K (Warm), 4000K (Natural), 6000K (Cool)
Control Method	Remote Control
Installation Method	Flush Mount
Special Features	Dimmable, Reversible Motor, Timer Function, Memory Function

Product Dimension



7ft

From Bottom Edge of
Blade to the Floor

Room Size

12ft.×12ft.to18ft.×18ft.

Image: Diagram showing the 52-inch diameter and 11.3-inch height of the ceiling fan, along with recommended room sizes for optimal air circulation.

9. WARRANTY AND CUSTOMER SUPPORT

warmiplanet stands behind the quality of its products:

- **Motor Warranty:** The fan motor is covered by a 10-year limited warranty.
- **Whole Fan Warranty:** The entire fan (excluding the motor) has a 2-year limited warranty.
- **Customer Support:** We offer 24-hour customer support. If you have any questions, require assistance with installation, or need to address any issues, please do not hesitate to contact us. We are committed to providing prompt and helpful responses.

© 2024 warmiplanet. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CLDK7W28>

More documents and user manuals: <https://manuals.plus/>