

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Bewinner](#) /

› [Bewinner USB 2.0 Data Charger Cable for MP3/MP4 Players \(A, S, X Series\) - 120cm Instruction Manual](#)

Bewinner Bewinner1masro38ez

Bewinner USB 2.0 Data Charger Cable for MP3/MP4 Players (A, S, X Series)

Instruction Manual - Model: Bewinner1masro38ez

1. INTRODUCTION

This manual provides essential information for the proper use and maintenance of your Bewinner USB 2.0 Data Charger Cable. This 2-in-1 cable is designed to facilitate both charging and data transfer for compatible MP3 and MP4 players, specifically those in the A, S, and X series. Please read this manual thoroughly before use to ensure optimal performance and longevity of your cable.



A black USB 2.0 data and charger cable, coiled neatly, showing both the standard USB-A connector and the proprietary connector for MP3/MP4 players.

2. PRODUCT FEATURES

- **Broad Compatibility:** Specifically designed for MP3/MP4 players from the A, S, and X series.
- **High-Speed Data Transfer:** Supports USB 2.0 standard, enabling data transmission speeds of up to 480 M/s for quick file transfers.
- **2-in-1 Functionality:** Allows simultaneous charging of your device and transfer of music or other data.
- **Durable Construction:** Manufactured with quality materials for enhanced durability and long-term reliability.
- **Convenient Length:** Features a practical 120 cm (1.2 meter) cable length for flexible use, combined with a lightweight design for portability.

3. SETUP

Follow these steps to set up your Bewinner USB 2.0 Data Charger Cable:

1. **Identify Connectors:** The cable has two distinct ends: a standard USB-A connector (rectangular) and a

proprietary connector designed for your MP3/MP4 player.

2. **Connect to MP3/MP4 Player:** Carefully insert the proprietary connector into the corresponding port on your MP3/MP4 player. Ensure it is oriented correctly to avoid damage.
3. **Connect to Power/Computer:** Insert the standard USB-A connector into a compatible USB port on your computer or a USB wall charger.
4. **Driver Installation (if necessary):** Most modern operating systems will automatically recognize the connected device. If prompted, allow your computer to install any necessary drivers.



A detailed view of the two ends of the cable: a standard USB-A connector on the right and a rectangular proprietary connector, typically used for older MP3/MP4 players, on the left.

4. OPERATING INSTRUCTIONS

4.1 Charging Your Device

To charge your MP3/MP4 player:

1. Connect the proprietary end of the cable to your MP3/MP4 player.
2. Connect the USB-A end to a powered USB port on a computer or a USB wall adapter.
3. Your device should indicate that it is charging. Charging times may vary depending on the device's

battery level and the power source.

4.2 Transferring Data

To transfer files between your computer and MP3/MP4 player:

1. Connect the proprietary end of the cable to your MP3/MP4 player.
2. Connect the USB-A end to an available USB port on your computer.
3. Your computer should recognize the MP3/MP4 player as a removable storage device.
4. Open 'My Computer' or 'This PC' (Windows) or 'Finder' (macOS) and locate your device.
5. Drag and drop files (e.g., music, videos) between your computer and the device's storage folders.
6. Once data transfer is complete, safely eject the device from your computer's operating system before disconnecting the cable.

5. MAINTENANCE

Proper care will extend the life of your cable:

- **Storage:** Store the cable in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid sharp bends, kinks, or excessive pulling on the cable, especially near the connectors.
- **Cleaning:** If necessary, gently wipe the cable and connectors with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- **Disconnection:** Always grasp the connector head when plugging or unplugging the cable, rather than pulling on the cable itself.

6. TROUBLESHOOTING

If you encounter issues with your cable, try the following solutions:

- **Device Not Charging:**
 - Ensure both ends of the cable are securely connected.
 - Try a different USB port on your computer or a different USB wall adapter.
 - Verify that your MP3/MP4 player is functioning correctly with its original charger (if available).
- **Device Not Recognized by Computer:**
 - Check all cable connections.
 - Try connecting to a different USB port on your computer.
 - Restart your computer and your MP3/MP4 player.
 - Ensure your computer's operating system is up to date.
- **Slow Data Transfer:**
 - Ensure you are connected to a USB 2.0 compatible port on your computer.
 - Avoid running multiple data-intensive applications during transfer.

7. SPECIFICATIONS

Feature	Detail
---------	--------

Model Number	Bewinner1masro38ez
Cable Length	120 cm (1.2 meters)
Net Weight	20 g
USB Standard	USB 2.0
Transmission Speed	Up to 480 M/s
Functionality	2-in-1 (Charging & Data Transfer)
Compatibility	MP3/MP4 Players (A, S, X Series)
Manufacturer	Bewinner



The black USB cable laid out, indicating a total length of 1.2 meters (120 cm). Dimensions for the USB-A connector (1.5cm width) and the proprietary connector (1.8cm width) are also shown.

8. WARRANTY AND SUPPORT

Specific warranty information for this product is not available in this manual. For details regarding warranty

coverage, returns, or technical support, please refer to the retailer where the product was purchased or visit the official Bewinner website. Please have your model number (Bewinner1masro38ez) and proof of purchase ready when contacting support.

© 2023 Bewinner. All rights reserved.