

[Manuals.plus](#) /

› [Roku](#) /

› Roku 65-Inch Select Series 4K HDR Smart TV User Manual

Roku 65R4A5R

Roku 65-Inch Select Series 4K HDR Smart TV User Manual

Your guide to setting up, operating, and maintaining your Roku Smart TV.

1. PRODUCT OVERVIEW

The Roku Select Series 4K TV is designed to provide a brilliant streaming experience with superior picture quality. This 65-inch model features 4K HDR picture optimized for room lighting with automatic brightness. It includes built-in sound features like auto speech clarity and night mode, and supports Headphone Mode. The TV allows seamless access to streaming apps and inputs directly from the home screen, and comes with an enhanced voice remote for easy navigation and content search.



Image: The Roku 65-Inch Select Series 4K HDR Smart TV displayed with its retail packaging.

Video: An overview of the Roku Select Series 4K TV, highlighting its design and smart features.

Key Features:




- **Brilliant 4K Picture:** Stunningly sharp 4K resolution with four times the resolution of HD.
- **HDR10+ Color:** Incredible color, contrast, and brightness for lifelike entertainment.
- **Automatic Brightness:** Screen adjusts automatically based on room lighting.
- **Seamless Streaming:** Fast Wi-Fi and quick app launches.
- **Customizable Home Screen:** Favorites, inputs, and free live TV are front and center.
- **Enhanced Voice Remote:** Voice search, personal shortcuts, Headphone Mode, and lost remote finder.
- **Built-in Sound Features:** Auto speech clarity and night mode.

2. WHAT'S IN THE BOX

Upon opening your Roku Smart TV package, please ensure all the following components are present:

- Roku 65" Select Series 4K Smart TV
- TV Stands and screws
- Roku enhanced voice remote with batteries
- Quick Start Guide


What's in the box




TV stands

Roku Select Series 4K TV

Power cable
for 75" model
only




43"/50"/55"/75"
model x 4 screws



65" model x 6 screws

Stand screws



AA batteries
x 2



Roku Enhanced
Voice Remote

Image: A visual representation of the Roku 65-inch Select Series 4K TV and its included accessories, such as the remote, stands, and screws.

3. SETUP GUIDE

3.1 Attaching the TV Stands

1. Carefully place the TV screen-down on a soft, clean surface to prevent scratches.
2. Align each stand with the corresponding screw holes on the bottom of the TV.
3. Secure the stands using the provided screws. Ensure they are tightened firmly but do not overtighten.


3.2 Initial Power-Up and Network Connection

1. Connect the power cord to the TV and then to a power outlet.
2. Insert the included AA batteries into the enhanced voice remote.

3. Press the power button on the remote to turn on the TV.
4. Follow the on-screen instructions to complete the initial setup, including selecting your language, connecting to your Wi-Fi network, and activating your Roku account. An active internet connection is required for smart TV features.

4. OPERATING YOUR TV

Your Roku Smart TV offers a user-friendly interface for accessing all your entertainment.



The smart TV that makes sense

Image: The Roku TV home screen, showing a selection of popular streaming applications and input options.

Video: A brief demonstration of the Roku TV home screen, emphasizing how streaming apps and inputs are easily accessible.

4.1 Home Screen Navigation

- The home screen provides quick access to your streaming channels, connected devices (like cable boxes or game consoles), and live TV.
- Use the directional pad on your remote to navigate through the menu options.
- Press the **OK** button to select an item.

4.2 Streaming Content

- Select any installed streaming app icon from the home screen to launch it.
- If an app is not installed, navigate to the 'Streaming Store' to browse and add new channels.

4.3 Using Inputs

- To switch to a connected device (e.g., a game console or Blu-ray player), select the corresponding input tile on the home screen.
- Ensure your external devices are properly connected to the TV's HDMI or other input ports.

4.4 Audio Features

- **Auto Speech Clarity:** Enhances dialogue for clearer understanding.
- **Night Mode:** Automatically lowers loud sounds and boosts quiet ones, ideal for late-night viewing.
- **Headphone Mode:** Plug headphones into the enhanced voice remote for private listening.

5. ENHANCED VOICE REMOTE

The Roku enhanced voice remote provides intuitive control over your TV and streaming experience.



App shortcut buttons may vary

Image: A detailed diagram of the Roku enhanced voice remote, indicating the function of each button.

Video: A demonstration of the enhanced voice remote, showcasing its voice search capabilities and other features.

Remote Features:

- **Voice Search:** Press and hold the microphone button to search for movies, shows, or control your TV using voice commands.
- **Personal Shortcuts:** Assign custom shortcuts to your favorite streaming apps for quick access.
- **Headphone Jack:** Located on the side of the remote for private listening.
- **Lost Remote Finder:** Use the Roku mobile app to locate a misplaced remote.
- **App Shortcut Buttons:** Dedicated buttons for popular streaming services.

6. CONNECTIVITY

Your Roku Smart TV offers various ports for connecting external devices and networks.



Image: A detailed view of the connectivity ports located on the back of the Roku TV.

Available Ports:

- **HDMI:** Multiple HDMI ports for connecting high-definition devices like game consoles, Blu-ray players, and soundbars. One port supports ARC for simplified audio return.
- **USB:** For connecting USB storage devices to view media.
- **Ethernet (LAN):** For a wired internet connection, providing stable streaming.
- **Antenna/Cable:** For connecting an antenna for over-the-air broadcasts or a cable TV connection.
- **Optical Audio Out:** For connecting to external audio systems.
- **Composite Video (RCA):** For connecting older devices with red, white, and yellow cables.

7. ADVANCED FEATURES

7.1 Brilliant 4K Picture and HDR10+

Experience entertainment in stunning 4K resolution, offering four times the detail of Full HD. HDR10+ technology enhances color, contrast, and brightness, bringing scenes to life with vibrant hues and deep blacks.



A treat for the eyes

Sharp 4K HDR10+ with auto brightness brings out rich detail while colors pop in lifelike clarity.

Image: The Roku TV screen displaying a high-definition image of two parrots, illustrating the vibrant 4K HDR10+ picture quality.

Video: A short clip demonstrating the visual quality of the Roku TV, emphasizing sharp 4K HDR10+ and automatic brightness.

7.2 Automatic Brightness

The TV features an automatic brightness sensor that adjusts the screen's luminance based on your room's ambient lighting conditions. This ensures optimal viewing comfort and picture quality without manual adjustments.

7.3 Backdrops (Digital Gallery)

Transform your TV into a digital gallery when not in use. Browse famous artists and photographers or upload your personal photos to display as a backdrop.




Image: The Roku TV screen showcasing an abstract painting, demonstrating its digital gallery feature.

Video: A short video illustrating the 'Backdrops' feature, which allows the TV to display artwork or personal photos when not actively streaming.

8. TROUBLESHOOTING

If you encounter issues with your Roku Smart TV, try the following common solutions:

- **No Power:** Ensure the power cord is securely plugged into both the TV and a working electrical outlet. Try a different outlet.
- **No Picture/Sound:** Verify that the correct input source is selected on the TV. Check all cable connections (HDMI, audio) are secure.
- **Remote Not Responding:** Replace the batteries in the remote. Ensure there are no obstructions between the remote and the TV.
- **Network Connection Issues:** Restart your Wi-Fi router. On the TV, go to Settings > Network > Check connection to diagnose and reconnect.
- **App Not Loading:** Try restarting the app. If the issue persists, remove the channel (app) and re-add it from the Streaming Store.
- **Picture Quality Issues:** Ensure you are viewing 4K content for optimal resolution. Check your internet speed if streaming.
- **Factory Reset:** As a last resort, a factory reset can resolve many software issues. Go to Settings > System > Advanced system settings > Factory reset. Note that this will erase all your settings and installed channels.

9. MAINTENANCE

Proper care will extend the life of your Roku Smart TV:

- **Cleaning the Screen:** Gently wipe the screen with a soft, dry microfiber cloth. For stubborn smudges, lightly dampen the cloth with water or a screen-cleaning solution specifically designed for electronics. Do not spray liquid directly onto the screen.
- **Cleaning the Frame and Stand:** Use a soft, dry cloth to wipe dust from the TV frame and stand.
- **Ventilation:** Ensure the TV's ventilation openings are not blocked to prevent overheating. Maintain adequate space around the TV for airflow.
- **Power Off When Not in Use:** Turn off the TV when not in use to conserve energy and prolong component life.

10. SPECIFICATIONS

Feature	Specification
Brand Name	Roku
Model Number	65R4A5R

Feature	Specification
Screen Size	65 Inches
Display Technology	LED
Resolution	4K (3840 x 2160)
Refresh Rate	60 Hz
Special Features	Bezel-Less Design, HDR10+, Voice Remote, Automatic Brightness
Speaker Type	Built-In
Aspect Ratio	16:9
Connectivity Technology	Wi-Fi, USB, Ethernet, HDMI
Product Dimensions (D x W x H)	13.2 x 57.1 x 35.6 inches
Item Weight	51.9 pounds
Color	Black
Wattage	248W

11. WARRANTY AND SUPPORT

For detailed warranty information, please refer to the documentation included with your product or visit the official Roku support website. Roku provides customer support for product assistance and technical inquiries.

You can also refer to the official User Guide (PDF) for more comprehensive information:

Download Official User Guide
(PDF)

© 2024 Roku, Inc. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question