

[manuals.plus](#) /

› [ZONEKIZ](#) /

› [ZONEKIZ Toy Shelf \(Model 311-059V80GN\) Instruction Manual](#)

ZONEKIZ 311-059V80GN

ZONEKIZ Toy Shelf Instruction Manual

Model: 311-059V80GN | Brand: ZONEKIZ

1. INTRODUCTION

Thank you for choosing the ZONEKIZ Toy Shelf. This organizer is designed to help children aged 3 and up develop good tidying habits by providing a dedicated space for their toys, books, and other items. It features a sturdy frame and six removable non-woven fabric storage boxes, making organization simple and accessible for young users.



Image 1.1: Child interacting with the ZONEKIZ Toy Shelf.

2. SAFETY INSTRUCTIONS

Please read and follow these safety instructions carefully to ensure safe use of the product.

- **Adult Supervision:** Always supervise children when they are using the toy shelf.
- **Age Recommendation:** This product is suitable for children aged 3 years and older.
- **Weight Limits:** Do not exceed the maximum weight capacities. The total maximum load is 5 kg (11 lbs). Individual basket capacities are: small baskets 0.5 kg (1.1 lbs), medium baskets 1 kg (2.2 lbs), large basket 1.5 kg (3.3 lbs). Overloading can cause instability and damage.
- **Stability:** Ensure the shelf is placed on a flat, stable surface. Do not allow children to climb on the shelf.
- **Rounded Edges:** The shelf features rounded edges to minimize the risk of injury. However, always inspect for any damage before use.
- **Assembly:** Assembly must be performed by an adult. Ensure all parts are securely fastened before allowing children to use the product.
- **Material Safety:** The product is made from MDF, steel, and non-woven fabric. Keep away from open flames or excessive heat.

3. PACKAGE CONTENTS

Please check that all components are present before beginning assembly.

- 1 x Toy Shelf Frame (MDF and Steel components)
- 6 x Removable Non-Woven Fabric Storage Boxes (various sizes)
- 1 x Hardware Pack (screws, connectors, etc.)
- 1 x Instruction Manual



Image 3.1: All components included in the package.

4. SETUP (ASSEMBLY)

Assembly is required for this toy shelf. Please follow these steps carefully. It is recommended to have a clear, spacious area for assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, clean surface to prevent scratches. Refer to Image 3.1 to identify all parts.
2. **Assemble Frame:** Connect the MDF panels and steel tubes according to the provided diagrams in the hardware pack. Ensure all screws are tightened securely but do not overtighten.

- 3. Insert Shelves:** Once the main frame is assembled, slide the shelf panels into their designated slots.
- 4. Place Fabric Boxes:** Fold and shape the non-woven fabric boxes. Place them onto the shelves as desired. The boxes are designed to be easily removable for access and cleaning.
- 5. Final Check:** Before use, ensure the shelf is stable, all connections are secure, and there are no loose parts.



Image 4.1: Assembly diagram for the toy shelf.

5. OPERATING (USAGE)

The ZONEKIZ Toy Shelf is designed for versatile storage in children's bedrooms, nurseries, playrooms, or living areas. Its open design and removable boxes make it easy for children to access and put away their belongings.

- Storage:** Use the six fabric boxes to store toys, books, art supplies, clothes, and other small items. The different box sizes allow for organized storage of various items.
- Accessibility:** The shelf's height is suitable for children aged 3 and up, promoting independence in tidying up.
- Removable Boxes:** The fabric boxes can be easily removed from the shelf, allowing children to take them to their play area and return them when finished.

USO VERSÁTIL

Guardería



Habitación de invitados



Sala de juegos



Aula



Image 5.1: Detail of a removable fabric storage box.



Image 5.2: Examples of versatile use in different environments.

6. MAINTENANCE

Regular cleaning and maintenance will help prolong the life of your ZONEKIZ Toy Shelf.

- **Frame Cleaning:** Wipe the MDF and steel frame components with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish. Dry immediately.
- **Fabric Box Cleaning:** The non-woven fabric boxes can be spot cleaned with a mild detergent and a damp cloth. Do not machine wash or tumble dry. Allow to air dry completely before returning to the shelf.
- **Regular Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary. Inspect fabric boxes for any tears or damage.

7. TROUBLESHOOTING

If you encounter any issues with your toy shelf, please refer to the following common solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Shelf feels wobbly or unstable.	Loose screws or uneven surface.	Ensure all assembly screws are tightened. Move the shelf to a flat, level surface.
Fabric boxes do not fit correctly.	Boxes not fully unfolded or incorrect placement.	Ensure boxes are fully unfolded and shaped. Verify correct box size for each shelf compartment.
Damage to components during assembly.	Excessive force or incorrect tools.	Contact customer support for replacement parts. Always follow assembly instructions carefully.

8. SPECIFICATIONS

Detailed specifications for the ZONEKIZ Toy Shelf (Model 311-059V80GN).

Feature	Detail
Model Name	Toy Rack
Item Model Number	311-059V80GN
Brand	ZONEKIZ
Color	Green
Material	MDF, Steel, Nonwoven Fabric
Overall Dimensions (LxWxH)	63 x 30 x 66 cm (24.8 x 11.81 x 25.98 inches)
Small Basket Dimensions (LxWxH)	19 x 23 x 12 cm
Medium Basket Dimensions (LxWxH)	29 x 23 x 12 cm
Large Basket Dimensions (LxWxH)	59 x 25 x 23 cm
Total Weight Capacity	5 kg (11 lbs)
Small Basket Weight Capacity	0.5 kg (1.1 lbs)
Medium Basket Weight Capacity	1 kg (2.2 lbs)
Large Basket Weight Capacity	1.5 kg (3.3 lbs)
Recommended Age	3 years and up
Assembly Required	Yes
Installation Type	Freestanding



Image 8.1: Product dimensions.

9. WARRANTY AND SUPPORT

For warranty information or if you require further assistance, please contact ZONEKIZ customer support. Keep your purchase receipt and model number (311-059V80GN) handy for faster service.

You can typically find contact information on the product packaging or the retailer's website where you purchased the item.