

[manuals.plus](#) /

› [vidaXL](#) /

› [vidaXL 3-Seater Sofa with Pillows \(Light Grey, 180 cm\) - Instruction Manual](#)

vidaXL 3200790

vidaXL 3-Seater Sofa with Pillows (Light Grey, 180 cm) - Instruction Manual

Model: 3200790 | Brand: vidaXL

INTRODUCTION

This manual provides detailed instructions for the assembly, use, and maintenance of your new vidaXL 3-Seater Sofa. Please read these instructions carefully before assembly and use to ensure safe and proper operation. Keep this manual for future reference.



Image: The vidaXL 3-Seater Sofa in light grey fabric, featuring a modern design with decorative pillows.

SAFETY INFORMATION

WARNING: Use only appropriate care materials and follow washing instructions to avoid damage or fire hazards. Keep small parts away from children to prevent choking hazards.

- Ensure all components are securely fastened before use.
- Do not exceed the maximum weight capacity of 110 kg per seat.
- Avoid standing or jumping on the sofa.
- Keep away from open flames and heat sources.
- Regularly check all connections and tighten if necessary.

PACKAGE CONTENTS

Before beginning assembly, please verify that all parts listed below are present and undamaged.

- 1 x 3-Seater Sofa Frame (Metal)
- 3 x Seat Cushions (Foam filled)
- 3 x Backrest Cushions (Foam filled)
- 2 x Decorative Pillows (Cylindrical, Foam filled, 15 x 50 cm)
- Assembly Hardware (screws, bolts, tools if included)
- Legs (typically wooden or metal)



Image: One of the decorative cylindrical pillows included with the sofa.

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is required for this sofa. It is recommended to have two people for assembly. Please follow these steps carefully.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent scratches.
2. **Assemble the Frame:** Connect the main metal frame sections using the provided hardware. Ensure all bolts are finger-tightened initially.
3. **Attach Legs:** Securely attach the sofa legs to the designated points on the bottom of the frame. Use a wrench to tighten them firmly.
4. **Place Seat Cushions:** Position the seat cushions onto the sofa frame.
5. **Add Backrest Cushions:** Place the backrest cushions against the back of the sofa.
6. **Arrange Decorative Pillows:** Place the two decorative cylindrical pillows as desired for additional comfort.
7. **Final Tightening:** Once all parts are in place, go back and fully tighten all bolts and screws using the provided tools. Do not overtighten.




Image: Technical diagram illustrating the sofa's overall dimensions and component placement for assembly reference.

OPERATING INSTRUCTIONS (USAGE)

Your vidaXL 3-Seater Sofa is designed for comfortable seating and relaxation. Its durable fabric and robust metal frame ensure stability and longevity.

- Comfortable Seating:** The sofa features well-padded seats, armrests, and backrest pillows for a comfortable sitting experience.
- Decorative Pillows:** Use the included decorative pillows for additional lumbar support or comfort when sitting or lying down.
- Capacity:** Designed to comfortably seat three individuals.

MAINTENANCE

Proper maintenance will extend the life and appearance of your sofa.

- Cleaning Fabric:** The fabric is breathable and durable. For general cleaning, vacuum regularly to remove dust and debris.
- Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. Do not rub. Use a mild fabric cleaner if necessary, testing on an inconspicuous area first.
- Removable Pillow Covers:** The covers of the decorative pillows are removable thanks to a zipper, making them easy to clean. Follow the washing instructions on the label.
- Frame Care:** Wipe the metal frame with a damp cloth as needed. Avoid harsh chemicals.
- Sunlight Exposure:** Avoid prolonged direct sunlight exposure to prevent fabric fading.




Image: Detailed view of the light grey fabric, highlighting its texture and weave.

TROUBLESHOOTING

If you encounter any issues with your sofa, please refer to the following common solutions.

Problem	Possible Cause	Solution
Sofa feels unstable or wobbly.	Loose connections or uneven legs.	Check all bolts and screws and tighten them securely. Ensure legs are evenly placed on the floor.
Cushions feel uncomfortable.	Cushions not properly positioned or need fluffing.	Adjust cushions for optimal comfort. Fluff decorative pillows.
Fabric appears stained.	Spill or dirt accumulation.	Refer to the "Maintenance" section for spot cleaning instructions.

If the problem persists, please contact vidaXL customer support for assistance.

SPECIFICATIONS

Feature	Detail
Brand	vidaXL
Model Number	3200790
Color	Light Grey
Material	Fabric (100% Polyester), Metal Frame, Textilene
Filling Material	Foam
Overall Dimensions (W x D x H)	198 x 77 x 80 cm (78" x 30.3" x 31.5")
Seat Width	180 cm (70.9")
Seat Depth	50 cm (19.7")
Seat Height from Floor	41 cm (16.1")
Armrest Height from Floor	56.5 cm (22.2")
Max. Load Capacity (per seat)	110 kg
Decorative Pillow Dimensions (Dia. x H)	15 x 50 cm
Assembly Required	Yes
Item Weight	29.8 Kilograms

WARRANTY AND SUPPORT

vidaXL products come with a standard manufacturer's warranty. For specific warranty details, please refer to the documentation included with your purchase or visit the official vidaXL website.

If you require technical assistance, have questions about assembly, or need to report a missing/damaged part, please contact vidaXL customer support. You can usually find contact information on the vidaXL website or your purchase receipt.

Online Support: [Visit vidaXL Customer Service](#)