

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [JUMMICO](#) /

› [JUMMICO Fireplace TV Stand User Manual](#)

JUMMICO 101WM2EF

JUMMICO Fireplace TV Stand User Manual

Model: 101WM2EF

PRODUCT OVERVIEW

The JUMMICO Fireplace TV Stand is a versatile entertainment center designed to accommodate TVs up to 65 inches. It features a built-in 26-inch electric fireplace, ample storage with adjustable shelves, and convenient sliding barn doors. This manual provides essential information for assembly, operation, and maintenance to ensure safe and optimal use of your new TV stand.



Image: The JUMMICO Fireplace TV Stand, a bright white media console with a central electric fireplace and sliding barn doors, supporting a large television.

IMPORTANT SAFETY INSTRUCTIONS

Please read and follow all safety instructions carefully before assembling or operating the product. Failure to do so may result in injury or damage.

- Always follow assembly instructions carefully.
- This product has sliding barn doors and adjustable shelves, which can tip over if not properly assembled or used.
- Keep the product away from children and pets.
- Do not place heavy objects on the top board to avoid damage or tip-over.
- Always unplug the product before making any adjustments or cleaning.

PACKAGE CONTENTS

Your JUMMICO Fireplace TV Stand is shipped in two separate packages: one for the TV stand components and one for the electric fireplace insert. Please ensure you have received both packages before beginning assembly.

- TV Stand Components (Panels, Hardware, Sliding Door Tracks)
- 26-inch Electric Fireplace Insert
- Assembly Instructions Manual
- Remote Control for Fireplace



Image: An illustration depicting the separate delivery of the TV cabinet and the fireplace, indicating that delivery times may vary for each package.

ASSEMBLY INSTRUCTIONS

Assembly of the JUMMICO Fireplace TV Stand is designed to be straightforward with numbered parts and clear instructions. For optimal ease and safety, it is recommended that two people assemble the unit.

Preparation

- Unpack all components and verify against the parts list in the included assembly manual.
- Lay out all parts on a soft, clean surface to prevent scratches.
- Ensure you have the necessary tools (e.g., screwdriver, hammer) as specified in the assembly manual.

Assembly Steps

Follow the step-by-step diagrams and instructions provided in the separate assembly manual. Key steps include:

1. Assembling the main frame of the TV stand.
2. Installing the sliding barn door tracks.
3. Attaching the back panels and ensuring proper cable management openings are aligned.

4. Inserting the adjustable shelves into desired positions.
5. Mounting the barn doors onto the tracks.
6. Carefully inserting the electric fireplace into its designated compartment.



Sliding Barn Door



More Storage Space



Adjustable Shelves



Cable Management

Image: Detailed view highlighting the smooth operation of the sliding barn doors, the flexibility of adjustable shelves, and integrated cable management solutions.



Image: An assembly illustration demonstrating the initial steps of constructing the base frame of the TV stand.

OPERATING INSTRUCTIONS

Electric Fireplace Operation

The 26-inch electric fireplace provides both aesthetic flame effects and heating capabilities. It comes with a remote control for convenient operation.

- **Power On/Off:** Use the power button on the fireplace unit or remote control to turn the fireplace on or off.
- **Flame Brightness:** Adjust the flame brightness (L1, L2, L3) using the dedicated button on the remote or control panel.
- **Heat Function:** Activate the heating function to warm up to 400 square feet. You can adjust the heat temperature as desired. The fireplace is designed to be cool to the touch.
- **Flame Only Mode:** The fireplace can operate with flame effects only, without heat, for year-round ambiance.
- **Timer:** Utilize the timer function for automatic shut-off.

Wide Electric Fireplace



Image: A detailed view of the electric fireplace insert, showing its control panel, remote control, and illustrating different flame brightness levels (L1, L2, L3).

Image: A close-up of the 26-inch electric fireplace, emphasizing its 4600 BTU heating capacity, ability to heat up in 3 seconds, and coverage for up to 400 square feet, along with its remote control functions.

Sliding Barn Doors

The two movable barn doors allow you to conceal either the central fireplace or the side storage cabinets, providing flexible display and storage options. Simply slide the doors along the top track to open or close the desired sections.

Adjustable Shelves

The side storage compartments feature adjustable and removable shelves with three levels of height adjustment. To adjust, carefully lift the shelf, reposition the support pegs to the desired height, and then place the shelf back onto the pegs.

CARE AND MAINTENANCE

To maintain the appearance and longevity of your JUMMICO Fireplace TV Stand, follow these simple care instructions:

- **Cleaning:** Wipe surfaces with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Dusting:** Regularly dust the unit with a soft, dry cloth.
- **Spills:** Clean up spills immediately to prevent staining or damage to the wood finish.
- **Fireplace:** Ensure the fireplace is unplugged before cleaning. Wipe the exterior with a soft, damp cloth. Do not spray liquids directly into the unit.

TROUBLESHOOTING GUIDE

If you encounter any issues with your JUMMICO Fireplace TV Stand, please refer to the following common troubleshooting tips:

- **Fireplace Not Turning On:** Ensure the power cord is securely plugged into a working electrical outlet. Check the circuit breaker. Verify the power button on the unit or remote is pressed.
- **No Heat from Fireplace:** Confirm the heat function is activated and the temperature setting is appropriate. Ensure the air vents are not obstructed.
- **Sliding Doors Sticking:** Check the tracks for any debris or obstructions. Ensure the doors are properly aligned on the tracks.
- **Wobbling/Unstable Stand:** Verify all assembly hardware is tightened securely. Ensure the stand is placed on a flat, level surface.

If problems persist, please contact JUMMICO customer support for further assistance.

PRODUCT SPECIFICATIONS

Feature	Specification
Brand	JUMMICO
Model Number	101WM2EF
Color	Bright White
Material	Wood (High-grade manufactured wood)
Product Dimensions (L x W x H)	64.37 x 18.7 x 7.68 inches
Item Weight	111.4 pounds

Feature	Specification
Maximum TV Size Supported	Up to 65 inches
Fireplace Size	26 inches
Fireplace Heat Output	4600 BTU
Heating Area	Up to 400 Square Feet
Number of Cabinets	2
Adjustable Shelves	Yes (3 levels)
Weight Capacity (Top Board)	220 lbs (approximate, inferred from image)
Country of Origin	China



Image: A diagram illustrating the overall dimensions of the TV stand: 59 inches in length, 32 inches in height, and 15.4 inches in depth.




Image: A visual representation showing the compatibility of the TV stand with various TV sizes, including 43, 50, 55, and up to 65 inches.

WARRANTY AND CUSTOMER SUPPORT

JUMMICO is committed to providing quality products and customer satisfaction. While specific warranty details may vary, please retain your proof of purchase for any warranty claims.

For any questions, concerns, or assistance with assembly, operation, or troubleshooting, please contact JUMMICO customer support. Refer to the contact information provided with your purchase or visit the official JUMMICO website for support resources.

You can also visit the JUMMICO Store on Amazon for more information and support: [JUMMICO Store](#)

