



Manuals.plus /

› STEAMIFY /

› Pressurized Handheld Steam Cleaner Instruction Manual

STEAMIFY WHL-601

STEAMIFY Pressurized Handheld Steam Cleaner Instruction Manual

Model: WHL-601

Brand: STEAMIFY

INTRODUCTION

This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your STEAMIFY Pressurized Handheld Steam Cleaner. This versatile appliance uses high-temperature steam for chemical-free cleaning across various surfaces in your home and vehicle.

IMPORTANT SAFETY INFORMATION

Read all instructions carefully before use.

- Always ensure the unit is unplugged before filling or emptying the water tank.
- Do not overfill the water tank. Recommended capacity is 370ML.
- Allow the unit to cool completely before storing.
- Keep out of reach of children and pets.
- Do not direct steam at people, animals, or electrical appliances.
- Use only clean tap water. Distilled water is recommended to prevent mineral buildup.
- Do not use any cleaning solutions or chemicals inside the water tank.
- Ensure the safety lock is engaged when not actively steaming.

PACKAGE CONTENTS

Your STEAMIFY Handheld Steam Cleaner package includes:

- Handheld Steam Cleaner Unit
- Bent Nozzle
- Nylon Brush
- Window Squeegee
- Ironing Brush

- Extension Hose
- Straight Nozzle
- Measuring Cup
- Funnel
- Fabric Steamer Cloth
- Wall Mount Bracket



Image: The STEAMIFY Handheld Steam Cleaner unit displayed with its full set of 10 accessories, including various nozzles, brushes, a squeegee, ironing brush, extension hose, measuring cup, funnel, and fabric cloth.

SETUP

1. Filling the Water Tank:

Ensure the steam cleaner is unplugged and cool. Unscrew the safety cap. Using the provided measuring cup and funnel, fill the water tank with up to 370ML of clean tap water. Do not exceed the MAX fill line. Screw the safety cap back on securely.



3-5 Mins

FAST HEATING STEAM CLEANER



Recommend Max Water Level 12.7OZ

Image: A hand holding the STEAMIFY steam cleaner, with the water tank visible and a measuring cup indicating the recommended maximum water level of 12.7 oz (370ml).

2. Attaching Accessories:

Select the appropriate accessory for your cleaning task. Align the accessory with the nozzle and twist or push firmly until it clicks into place.

3. Powering On:

Plug the power cord into a grounded electrical outlet. The indicator light will illuminate, signifying that the unit is heating up.

4. Heating Time:

The steam cleaner will heat up rapidly in approximately 3-5 minutes. The indicator light will turn off when the optimal steam temperature is reached and the unit is ready for use.

POWERFULLY CLEAN THE TOUGHEST



Powerful handheld steam cleaner is suited for virtually all hard surfaces in your home

Image: The STEAMIFY steam cleaner heating up, with a graphic indicating a fast heating time of 3-5 minutes and a maximum recommended water level of 12.7 oz.

OPERATING INSTRUCTIONS

Once the unit is heated, press the steam trigger to release pressurized steam. For continuous steam, engage the continuous steam lock.

General Cleaning Tips:

- For best results, hold the nozzle close to the surface being cleaned.
- Use a clean cloth to wipe away loosened dirt and moisture after steaming.
- Always test on an inconspicuous area first, especially on delicate surfaces.

Using Specific Attachments:

Bent Nozzle & Nylon Brush:

Ideal for cleaning hard-to-reach areas, grout lines, corners, and stubborn grime on surfaces like kitchen sinks, BBQ grills, and bathroom fixtures.

1200W Powerful

**High-Pressure
Steam Cleaning**



Removes Dirt, Grime, Grease & More

Image: The STEAMIFY steam cleaner being used to clean a greasy stove top, demonstrating its high-pressure steam cleaning capability to remove dirt, grime, and grease.

Window Squeegee:

Attach the squeegee for streak-free cleaning of windows, mirrors, and other smooth glass surfaces. Steam the surface, then use the squeegee to wipe clean.

Ironing Brush & Fabric Steamer Cloth:

Use this attachment with the fabric cloth for refreshing clothing, upholstery, curtains, and pet mattresses. The steam helps to remove wrinkles and odors.

Extension Hose:

Provides extended reach for cleaning floors, high surfaces, or inside vehicles.



Image: An overhead view of a room with the STEAMIFY steam cleaner and its various accessories (straight nozzle, extension hose, ironing brush, nylon brush, bent nozzle, window squeegee) highlighting its versatility for cleaning every corner and surface.

Car Detailing:

The various nozzles and brushes are effective for cleaning car interiors, upholstery, and hard-to-reach areas.

ATTACHMENTS FOR CAR DETAILING

Upholstrey, Sofa, Bathroom, Windows, etc.



Image: A person using the STEAMIFY steam cleaner to clean the engine bay of a car, demonstrating its utility for car detailing on upholstery, sofas, bathrooms, and windows.

Power Cord Length:

The 9.8ft long power cord provides ample reach for cleaning various areas without frequently changing outlets.

9.8FT LONG POWER CORD



Image: A person using the STEAMIFY steam cleaner in a living room, illustrating the 9.8ft long power cord that allows cleaning reach to every corner.

MAINTENANCE

After Each Use:

- Unplug the unit and allow it to cool completely.
- Carefully unscrew the safety cap and empty any remaining water from the tank.
- Wipe down the exterior of the unit and accessories with a damp cloth.
- Store the unit and accessories in a dry, safe place.

Descaling (Monthly or as Needed):

- If you notice reduced steam output or mineral buildup, descaling may be necessary.
- Fill the tank with a solution of equal parts white vinegar and water.
- Allow it to sit for 30 minutes (do not heat).
- Empty the solution and rinse the tank thoroughly with clean water several times.
- Fill with clean water and operate the steamer for a few minutes to flush out any remaining vinegar.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No steam output	No water in tank; Unit not heated; Safety cap not secure	Fill water tank; Wait for indicator light to turn off; Secure safety cap
Weak steam output	Low water level; Mineral buildup	Refill water tank; Perform descaling procedure
Water dripping from nozzle	Unit not fully heated; Overfilled tank	Allow more time to heat; Do not overfill tank (max 370ML)

SPECIFICATIONS

Brand: STEAMIFY

Model Name: EM-308

Item Model Number: WHL-601

Wattage: 1200.0 W

Tank Volume: 350 Centiliters (350 ML)

Recommended Water Capacity: 370 ML

Heat Time: 3-5 minutes

Continuous Steam Time: 7-15 minutes

Maximum Temperature: 230°F (110°C)

Power Source: Corded Electric

Voltage: 110 V

Color: Black & Yellow

Item Weight: 3.76 pounds

Product Dimensions: 0.39 x 0.39 x 0.39 inches

Special Features: Compact, Chemical-Free Steam, Multi-Surface Steamer, 10-Piece Accessories, Powerful High-Pressure Cleaning, Long Power Cord, Continuous Steam, Safe for Pets, Super Fast Heating, Lightweight Portable Use, Safety Lock

Surface Recommendation: Hard Floor, Tile, Grout, Sofa, Window, Car, Furniture, Upholstery, Fabric, Sink, Countertop, Wall, Kitchen and Bath Surfaces.

UPC: 762221860008, 762221860053

WARRANTY AND SUPPORT

For warranty information or technical support, please contact STEAMIFY customer service directly. Refer to the product packaging or the official STEAMIFY website for contact details.

You can also find additional support documents, including a User Manual (PDF) and Installation Manual (PDF), on the product's Amazon listing page.

For general inquiries, visit the STEAMIFY Store on Amazon.