

ODK JJYJZ-CZ1003

ODK Gaming Table Computer Desk User Manual

Model: JJYJZ-CZ1003

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your ODK Gaming Table Computer Desk. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your product. Keep this manual for future reference.

2. SAFETY INFORMATION

Please observe the following safety guidelines:

- The desk has a maximum weight limit of **50 kg (110 lbs)**. Do not exceed this limit.
- Ensure all screws and fasteners are securely tightened during assembly and periodically check for tightness.
- Do not stand or sit on the desk.
- Keep liquids away from the integrated power supply unit to prevent electrical hazards.
- Use only in a dry indoor environment.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer service.

- Desk Panels (L-shaped sections)
- Metal Frame Components (legs, support bars)
- Monitor Shelf
- Integrated Power Supply Unit (with 2 sockets and 2 USB ports)
- Storage Bag and Hooks

- Assembly Hardware (screws, bolts, nuts)
- Assembly Tools (e.g., Allen wrench, screwdriver)
- Instruction Manual

4. SETUP AND ASSEMBLY

Assembly of the ODK Gaming Table is designed to be straightforward. Follow the numbered steps in the included assembly guide. All necessary tools and replacement screws are provided.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Frame:** Begin by connecting the metal frame components. The X-shaped frame design provides enhanced stability. Ensure all connections are firm.
3. **Attach Desk Panels:** Secure the L-shaped desk panels to the assembled frame using the provided hardware. Pay attention to the orientation of the round corner section.
4. **Install Monitor Shelf:** Attach the monitor shelf to the designated area on the desk.
5. **Integrate Power Supply:** Mount the power supply unit into its dedicated slot. Ensure the power cable is routed safely and not pinched.
6. **Attach Storage Bag and Hooks:** Secure the storage bag and hooks to the side of the desk as desired for convenient access to items.
7. **Final Check:** Once assembled, gently shake the desk to ensure all connections are stable and secure. Adjust leveling feet if necessary to prevent wobbling.



This image displays the ODK Gaming Table in its assembled state, showcasing its L-shaped design. On the left side, a curved monitor is set up with a glowing keyboard and mouse. The corner features the integrated power strip with two sockets and two USB ports. The right

side includes a raised shelf holding a laptop, two game controllers, and a side-mounted storage bag filled with snacks. The desk is black with a sturdy metal frame.

5. OPERATING INSTRUCTIONS

Your ODK Gaming Table is designed for optimal functionality in both gaming and home office environments.

5.1 Integrated Power Supply

The desk is equipped with **2 standard power sockets** and **2 USB charging ports**. To use:

- Connect the desk's main power cord to a wall outlet.
- Plug your electronic devices (e.g., monitor, computer, phone, tablet) into the available sockets or USB ports.
- Ensure devices are compatible with the power output.

5.2 Monitor Shelf

The elevated monitor shelf provides an ergonomic viewing height for your display, helping to reduce neck strain. It can also be used to store other small peripherals.

5.3 Storage Bag and Hooks

Utilize the side-mounted storage bag and hooks to keep your workspace organized. The bag is suitable for small items, documents, or snacks, while the hooks can hold headphones or cables.

6. MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your desk.

- **Cleaning:** Wipe the desk surface with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Frame Care:** The metal frame can be cleaned with a damp cloth. Ensure it is dried thoroughly to prevent rust.
- **Hardware Check:** Periodically inspect all screws and bolts to ensure they remain tight. Re-tighten if necessary.
- **Power Unit:** Keep the power sockets and USB ports free from dust and debris. Do not attempt to disassemble the power unit.

7. TROUBLESHOOTING

If you encounter issues with your ODK Gaming Table, refer to the following common solutions:

- **Desk Wobbles:** Check that all assembly hardware is securely tightened. Ensure the desk is on a level surface; adjust the leveling feet if present.
- **Power Sockets/USB Ports Not Working:**
 - Verify the desk's main power cord is securely plugged into a functional wall outlet.
 - Check if the wall outlet itself is receiving power (e.g., by plugging in another device).
 - Ensure the device you are trying to power is functioning correctly.
- **Missing Parts/Damaged Components:** If you discover missing or damaged parts during unpacking or assembly, do not proceed with assembly. Contact ODK customer service immediately for assistance.

8. SPECIFICATIONS

Feature	Detail
Brand	ODK
Model Number	JJYJZ-CZ1003
Manufacturer Part Number	ZJZ-1972
Product Dimensions (D x W x H)	127D x 127W x 76.4H centimeters
Item Weight	15.5 Kilograms
Color	Black with power supply
Shape	Rectangular (L-shaped configuration)
Material Type	Metal (Frame), Wood (Top Material Type)
Number of Sockets	2
Number of USB Charging Ports	2
Special Features	Integrated Power Supply, Monitor Shelf, Storage Bag, Durable Construction

9. WARRANTY AND SUPPORT

ODK is committed to ensuring comprehensive customer satisfaction. Our products are manufactured with outstanding quality. If you have any questions, concerns, or require assistance with your ODK Gaming Table, please do not hesitate to contact our friendly customer service team. Refer to your purchase documentation for specific warranty details and contact information.

© 2024 ODK. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question