

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Aiwa](#) /

› **Aiwa Sound Bar and Wireless Subwoofer ASB-018WS User Manual**

Aiwa ASB-018WS

Aiwa Sound Bar and Wireless Subwoofer

Model: ASB-018WS

INTRODUCTION

This manual provides essential instructions for the safe and efficient operation of your Aiwa Sound Bar and Wireless Subwoofer (Model: ASB-018WS). Please read this manual thoroughly before using the product and retain it for future reference. It covers setup, operation, maintenance, troubleshooting, and product specifications.

SAFETY INFORMATION

- Do not expose the unit to rain, moisture, or extreme temperatures.
- Ensure proper ventilation around the sound bar and subwoofer.
- Do not block any ventilation openings.
- Use only attachments/accessories specified by the manufacturer.
- Unplug the apparatus during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.

PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Aiwa Sound Bar
- 1 x Wireless Subwoofer
- 1 x Remote Control
- Power Cables
- Wall Mounting Kit
- User Manual

PRODUCT OVERVIEW

The Aiwa ASB-018WS system consists of a main sound bar unit and a wireless subwoofer. The sound bar houses the primary speakers and control interface, while the subwoofer provides enhanced bass frequencies wirelessly.

Sound Bar

The sound bar features a sleek design, with a digital display on the front panel indicating the current input mode and

volume level. Control buttons for power, volume, and input selection are typically located on the top or side. Rear panel connections include HDMI, Optical, and Auxiliary inputs, along with the power input.

Wireless Subwoofer

The wireless subwoofer is designed to automatically pair with the sound bar, providing deep bass without the need for a physical audio cable connection. It typically has a power input and a status indicator light.

SETUP

Placement

- **Sound Bar:** Place the sound bar centrally below your TV. Ensure it is on a stable, flat surface or securely mounted to the wall using the provided kit.
- **Wireless Subwoofer:** Position the subwoofer on the floor, preferably in the front corner of the room or near the sound bar for optimal bass response. Ensure it is within range of the sound bar for wireless connection.

Connections

- **HDMI (ARC):** Connect an HDMI cable from the HDMI ARC port on your TV to the HDMI ARC port on the sound bar. This allows audio from your TV to be sent to the sound bar and enables control of the sound bar with your TV remote.
- **Optical:** Connect an optical audio cable from your TV's optical output to the OPTICAL input on the sound bar. This is a common digital audio connection.
- **Auxiliary (AUX):** Use a 3.5mm audio cable to connect external devices (e.g., MP3 players) to the AUX input on the sound bar.
- **Power:** Connect the power cables to the sound bar and the wireless subwoofer, then plug them into a wall outlet.

OPERATING INSTRUCTIONS

Power On/Off

Press the **POWER** button on the sound bar or the remote control to turn the unit on or off. The digital display will illuminate when the unit is powered on.

Input Selection

Press the **INPUT** or **SOURCE** button on the sound bar or remote control repeatedly to cycle through available input sources: HDMI, OPTICAL, AUX, and BLUETOOTH. The selected input will be shown on the digital display.

Bluetooth Pairing

1. Turn on the sound bar and select the BLUETOOTH input mode. The display will show 'BT' and may flash, indicating it is in pairing mode.
2. Enable Bluetooth on your smartphone, tablet, or other device.
3. Search for available devices and select "Aiwa ASB-018WS" from the list.
4. Once connected, the sound bar will indicate a successful pairing, and you can now stream audio wirelessly.

Sound Modes

The sound bar features multiple sound modes (e.g., Movie, Music, News) to optimize audio for different content types. Press the **MODE** button on the remote control to cycle through these options.

Remote Control

The included remote control provides full functionality for power, volume, input selection, sound modes, and bass/treble adjustments. Ensure batteries are correctly inserted.

Maintenance

To maintain the performance and appearance of your sound bar and subwoofer:

- Wipe surfaces with a soft, dry cloth.
- Do not use abrasive cleaners, waxes, or solvents.
- Keep ventilation openings clear of dust and debris.
- Ensure the units are unplugged before cleaning.

Troubleshooting

Problem	Solution
No power	Check if the power cables are securely connected to both the unit and the wall outlet. Ensure the outlet is functional.
No sound	Verify the correct input source is selected. Check audio cable connections. Increase volume on both the sound bar and the connected device.
Subwoofer not connecting	Ensure both the sound bar and subwoofer are powered on. The subwoofer should automatically pair. If not, refer to the manual's pairing section or try restarting both units.
Bluetooth pairing fails	Ensure the sound bar is in Bluetooth pairing mode. Delete "Aiwa ASB-018WS" from your device's Bluetooth list and try pairing again. Move your device closer to the sound bar.
Remote control not working	Check and replace batteries. Ensure there are no obstructions between the remote and the sound bar's sensor.

Specifications

- **Model Number:** ASB-018WS
- **Sound System:** Surround 2.1 with Wireless Subwoofer
- **Connectivity:** Bluetooth, HDMI (ARC), Optical, Auxiliary
- **Color:** Black
- **Included Components:** Sound Bar, Wireless Subwoofer, Remote Control, Power Cables, Wall Mounting Kit
- **Features:** Multiple Sound Modes, Digital Display, Wall-mountable design
- **Product Dimensions:** 85D x 20.5W x 40.5H centimetres (Sound Bar and Subwoofer combined package dimensions)

Warranty and Support

This Aiwa Sound Bar and Wireless Subwoofer (ASB-018WS) comes with a **1 Year Manufacturer's Warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use.

For technical support, warranty claims, or service inquiries, please contact your local Aiwa authorized dealer or visit the official Aiwa website for contact information. Please have your product model number and proof of purchase ready when seeking support.