



[Manuals.plus](#) /

› [Bellemave](#) /

› Bellemave Twin Over Full Loft Bed Instruction Manual

Bellemave B0CLH1MJMY

Bellemave Twin Over Full Loft Bed Instruction Manual

Model: B0CLH1MJMY

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Bellemave Twin Over Full Loft Bed with Desk and Storage Drawers. Please read this manual thoroughly before assembly and use to ensure safe and proper operation.

The Bellemave Twin Over Full Loft Bed is designed to offer versatile sleeping and working space, featuring a twin-size loft bed, a full-size lower bed, an integrated desk, and storage drawers. Its robust construction with solid pine wood and MDF ensures stability and durability.

IMPORTANT SAFETY INFORMATION

Please adhere to the following safety guidelines to prevent injury or damage:

- This bed frame is suitable for children over 6 years old.
- The upper bed has a maximum weight capacity of 300 lbs.
- The lower bed has a maximum weight capacity of 350 lbs.
- Recommended mattress thickness for the upper bed: 6 inches.
- Recommended mattress thickness for the lower bed: 6-8 inches.
- Do not exceed a mattress thickness of 8 inches for either bed.
- Always ensure proper assembly and maintenance. Misuse or failure to follow recommendations may result in hazards such as sharp edges, pinch points, or instability, leading to injury or damage.
- Regularly check all connections and fasteners to ensure they are tight and secure.
- Do not allow children to play on or under the bed without supervision.
- Ensure the ladder is securely attached before use.

PRODUCT SPECIFICATIONS

Feature	Detail
Product Type	Bunk Bed
Size	Twin Over Full
Overall Product Dimension	79.5"L x 42"W x 68.3"H
Color	Gray
Material	Plywood+MDF+Pinewood
Number of Slats (Upper/Lower)	14+14
Overall Product Weight	159.84 lbs
Assembly Required	Yes
Included Components	Installation Manual

Note: Manual measurements may have reasonable errors. Slight chromatic aberration may occur due to lighting or display.

SETUP AND ASSEMBLY

Your Bellemave Twin Over Full Loft Bed requires assembly. An installation manual is included with your product. Please follow the step-by-step instructions provided in the separate manual for proper assembly.

- Ensure all parts are present before beginning assembly. Refer to the parts list in your installation manual.
- Assemble on a soft, clean surface to prevent scratching the furniture.
- Tighten all bolts and screws securely, but do not overtighten.
- It is recommended to have at least two adults for assembly.
- The product typically arrives in two separate boxes, which may not arrive on the same day. Please allow 2-3 additional days for the second box if it does not arrive simultaneously.



Image: Fully assembled Bellemave Twin Over Full Loft Bed, showcasing the twin upper bunk, full lower bed, integrated desk, and storage drawers. The bed is gray and features a ladder for access to the upper bunk.

SIZE: INCH



Image: Detailed diagram showing the dimensions of the Bellemave Twin Over Full Loft Bed, including length, width, and height measurements for both the overall structure and individual components like the desk and ladder.

OPERATING INSTRUCTIONS

The Bellemave Twin Over Full Loft Bed offers versatile configurations to suit your needs:

- **Versatile Design:** This bunk bed can be separated into two completely independent beds: a twin-size loft bed and a full-size bed frame.
- **Lower Bed Placement:** The full-size lower bed can be placed directly underneath the loft bed or positioned on the other side, allowing for flexible room arrangements.
- **Desk and Storage:** The integrated desk and storage drawers are part of the loft bed structure and provide a convenient workstation and storage space. The desk can be set on either side of the bed during assembly.
- **Mattress Usage:** No box spring is required for either bed. Simply place your mattress directly onto the provided slats.
- **Ladder Access:** Use the inclined ladder to safely access the upper twin bunk. Ensure the ladder is stable before climbing.



Image: The Bellemave Twin Over Full Loft Bed disassembled, showing the twin loft bed with desk and the separate full-size bed frame, highlighting its versatile configuration options.



Image: An overhead view of the Bellemave Twin Over Full Loft Bed, illustrating the twin upper bunk, the full lower bed positioned parallel, and the integrated desk with drawers.

MAINTENANCE

Proper maintenance will extend the life and appearance of your Bellemave bed:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Regular Checks:** Periodically inspect all bolts, screws, and connections to ensure they remain tight. Retighten as necessary.
- **Avoid Moisture:** Protect the wood from excessive moisture and direct sunlight to prevent warping or fading.
- **Weight Distribution:** Distribute weight evenly on both beds to prevent undue stress on the frame.

TROUBLESHOOTING

If you encounter any issues with your Bellemave Twin Over Full Loft Bed, please refer to the following common solutions:

Problem	Possible Cause	Solution
Bed feels wobbly or unstable.	Loose connections or improper assembly.	Check all bolts and screws. Tighten any loose fasteners. Ensure all parts are correctly aligned according to the assembly manual.
Missing parts upon delivery.	Parts may be in the second box, or a component was omitted.	Verify if both packages have arrived. If parts are still missing, contact customer support with your purchase details and the specific missing components.
Drawers do not slide smoothly.	Improper drawer runner installation or obstruction.	Ensure drawer runners are installed correctly and are free of debris. Check for any objects obstructing the drawer's path.

WARRANTY AND SUPPORT

For any questions regarding assembly, missing parts, or product performance, please refer to the included installation manual or contact Bellemave customer support. While specific warranty details are not provided in this document, most products come with a manufacturer's warranty against defects in materials and workmanship.

You can often find support information on the Bellemave brand store page on Amazon or by searching for "Bellemave customer service" online.

Visit the official Bellemave Store: [Bellemave Store](#)