

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Bellemave](#) /

› [Bellemave Full Over Full Loft Bed with Desk and Storage Drawers Instruction Manual](#)

Bellemave Full Over Full Loft Bed with Desk and Storage Drawers

Bellemave Full Over Full Loft Bed with Desk and Storage Drawers Instruction Manual

Model: Full Over Full Loft Bed with Desk and Storage Drawers

Brand: Bellemave

1. INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Bellemave Full Over Full Loft Bed with Desk and Storage Drawers. This versatile furniture piece is designed to offer efficient space utilization, featuring a full-size loft bed, an integrated desk, and convenient storage drawers. The unique design also allows for separation into a full-size platform bed and a standalone loft bed, adapting to various room configurations and needs. Please read all instructions carefully before assembly and use to ensure safety and proper function.



Image 1.1: The Bellemave Full Over Full Loft Bed with Desk and Storage Drawers, shown in a bedroom setting.

2. SAFETY INFORMATION

Adherence to these safety guidelines is crucial for preventing injuries and ensuring the longevity of your bed. Keep these instructions for future reference.

- **Age Recommendation:** This bed is recommended for users aged 6 years and older.
- **Weight Capacity:** The upper bed has a maximum weight capacity of 350 lbs. The bottom bed has a maximum weight capacity of 350 lbs. Do not exceed these limits.
- **Mattress Thickness:** For optimal safety and fit, use a mattress with a thickness of 6 inches for the upper bed. For the bottom bed, use a mattress between 6 and 8 inches thick. Do not exceed an 8-inch mattress thickness on either bed.
- **Guardrails:** Always ensure guardrails are properly installed and secured on the upper bunk.
- **Ladder Safety:** Use the ladder for entry and exit from the upper bunk. Do not use the bed as a climbing structure.

- **No Jumping:** Prohibit jumping on the bed, especially the upper bunk.
- **Assembly:** Ensure all components are correctly assembled and all fasteners are tightened according to the assembly instructions. Regularly check and re-tighten fasteners as needed.
- **Ventilation:** Ensure adequate ventilation around the bed.
- **Placement:** Position the bed away from windows, cords, or other items that could pose a strangulation hazard.

3. PACKAGE CONTENTS

Your Bellemave Full Over Full Loft Bed is shipped in two (2) packages. Please ensure you have received both packages before beginning assembly. Refer to the detailed parts list provided in your separate assembly guide to verify all components are present and undamaged. If any parts are missing or damaged, please contact customer support immediately.

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of this product requires two adults. Please follow the step-by-step instructions and diagrams provided in the separate assembly manual included with your purchase. Ensure you have ample space and the necessary tools (typically a Phillips head screwdriver and Allen wrench, often included) before starting.

4.1 General Assembly Steps:

1. **Unpack and Identify:** Carefully unpack all components from both packages. Lay them out on a clean, soft surface (like a carpet) to prevent scratches. Identify each part using the provided parts list and hardware diagram.
2. **Hardware Check:** Verify all hardware (screws, bolts, nuts, washers) is present.
3. **Frame Assembly:** Begin by assembling the main frames for both the loft bed and the platform bed, following the numerical sequence in your assembly guide.
4. **Desk and Drawer Integration:** Attach the desk and drawer components as instructed. Ensure drawers slide smoothly.
5. **Ladder and Guardrails:** Securely attach the ladder and all guardrails to the loft bed frame.
6. **Slat Installation:** Install the bed slats for both the upper and lower beds, ensuring they are evenly spaced and secured.
7. **Final Tightening:** Once fully assembled, go back and gently tighten all fasteners. Do not overtighten.

4.2 Separating the Beds:

This loft bed is designed to be separated into a full-size loft bed and a full-size platform bed. The assembly guide will provide specific instructions for this configuration. Essentially, the lower platform bed is a standalone unit that can be positioned underneath the loft bed or elsewhere in the room.



Image 4.1: Angled view of the assembled loft bed, showcasing the integrated desk and storage drawers.



Image 4.2: The Bellemave bed configured as a separate loft bed and a full-size platform bed.

5. OPERATING INSTRUCTIONS

This section details the proper use of your Bellemave Loft Bed and its features.

- **Using the Loft Bed:** Access the upper bunk using the provided ladder. Ensure the mattress fits snugly within the guardrails.
- **Using the Desk:** The integrated desk provides a dedicated workspace. Keep the desk clear of excessive weight to prevent damage.
- **Using the Storage Drawers:** The drawers are designed for light storage of clothing, books, or personal items. Avoid overloading them to ensure smooth operation and prevent damage to the drawer slides.
- **Separated Configuration:** When separated, the full-size platform bed can be moved independently. Ensure its casters (if present) are locked when the bed is in its desired position to prevent unwanted movement.



Image 5.1: The full-size platform bed component, which can be used independently.

6. MAINTENANCE

Regular maintenance helps preserve the appearance and structural integrity of your bed.

- **Cleaning:** Wipe down wood surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Hardware Check:** Periodically inspect all bolts, screws, and fasteners to ensure they remain tight. Re-tighten as necessary, but do not overtighten.
- **Slat Inspection:** Check bed slats regularly for any signs of damage or cracking. Replace damaged slats immediately.
- **Drawer Slides:** If drawers become stiff, a small amount of silicone lubricant can be applied to the slides.
- **Mattress Care:** Follow the care instructions provided by your mattress manufacturer.

7. TROUBLESHOOTING

If you encounter any issues with your Bellemave Loft Bed, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Bed feels wobbly or unstable.	Loose fasteners. Uneven floor.	Ensure all bolts and screws are securely tightened. Check if the bed is on a level surface; use shims if necessary.
Squeaking noises.	Loose connections. Friction between wood parts.	Tighten all hardware. Apply a small amount of wax or silicone spray to contact points between wood components.

Problem	Possible Cause	Solution
Drawers stick or do not slide smoothly.	Overloaded drawer. Debris in slides. Misaligned slides.	Reduce drawer contents. Clean drawer slides of any dust or debris. Check if drawer slides are properly aligned and secured.
Ladder feels loose.	Ladder attachment bolts are loose.	Re-tighten the bolts securing the ladder to the bed frame.

If the problem persists or is not listed here, please contact Bellemave customer support for further assistance.

8. SPECIFICATIONS

Key dimensions and material specifications for the Bellemave Full Over Full Loft Bed:

Product Type: Bunk Bed / Loft Bed

Size: Full Over Full

Overall Product Dimension: 79.5" L x 57.2" W x 68.3" H

Upper Bed Weight Capacity: 350 lbs

Bottom Bed Weight Capacity: 350 lbs

Recommended Upper Bed Mattress Thickness: 6 inches

Recommended Bottom Bed Mattress Thickness: 6-8 inches

Material: Plywood, MDF, Pinewood

Number of Slats: 14 (Upper Bed) + 14 (Bottom Bed)

Finish Type: Painted

Assembly Required: Yes



Image 8.1: Detailed dimensions of the Bellemave Full Over Full Loft Bed.

9. WARRANTY INFORMATION

Bellemave products are manufactured to high-quality standards. For specific warranty details regarding your Full Over Full Loft Bed, please refer to the warranty card included with your product or contact Bellemave customer support directly. Keep your proof of purchase for any warranty claims.

10. CUSTOMER SUPPORT

Should you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Bellemave customer support. You can typically find contact information on the Bellemave brand store on Amazon or through the documentation included with your product.

Online Support: Visit the [Bellemave Store on Amazon](#) for more information and support resources.

