JVC TH-N322B

JVC 2.0 Channel Bluetooth Soundbar User Manual

Model: TH-N322B | Brand: JVC

Introduction

Thank you for purchasing the JVC 2.0 Channel Bluetooth Soundbar. This soundbar is designed to enhance your home entertainment experience by delivering powerful and immersive sound. Its sleek and compact design allows for seamless integration into any living space. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance and longevity of your device.

Package Contents

- 1 x JVC 2.0 Channel Bluetooth Soundbar
- 1 x Remote Control
- 1 x Power Adapter
- 1 x User Manual
- (Additional cables may be included depending on the specific model variant)

Image: The JVC 2.0 Channel Bluetooth Soundbar, black in color, shown with its accompanying remote control. The soundbar features a sleek, perforated grille and metallic end caps. The remote control is black with various playback and volume buttons.

Key Features

Crystal Clear Sound

Image: A graphic highlighting the JVC 2.0 Soundbar's 30W output and 2.0 channel audio, emphasizing crystal clear sound. Two individuals are shown enjoying music, illustrating the immersive audio experience.

Equipped with dual 2-inch drivers, the JVC Soundbar delivers rich, clear, and immersive audio, enhancing all your media content. Experience every note and dialogue with unmatched clarity and depth.

Effortless Device Pairing

Image: The JVC Soundbar connected wirelessly to a smartphone, tablet, and laptop, illustrating effortless Bluetooth pairing. Icons for HDMI-ARC, Bluetooth, Optical, and AUX connectivity are displayed.

Enjoy quick Bluetooth pairing for instant audio streaming from your smartphone, tablet, or laptop. The soundbar also offers versatile connectivity options including HDMI-ARC, Optical, and AUX input for seamless integration with various devices.

Personalize Your Soundtrack

Image: The JVC Soundbar highlighting its built-in FM radio and USB playback capabilities. Icons indicate support for MP3, WAV, and WMA audio formats, with USB supporting up to 32GB.

Play your favorite tunes directly from a USB drive (up to 32GB) supporting MP3, WAV, and WMA formats. Additionally, enjoy your favorite radio stations with the built-in FM tuner.

Control at Your Fingertips

Image: A hand interacting with the control buttons on top of the JVC Soundbar, with the remote control also visible. This illustrates the ease of switching modes and adjusting volume.

Effortlessly switch modes, adjust volume, and control playback using the included remote control or the intuitive buttons located on the soundbar itself.

Setup Guide

1. Unpacking and Placement

Carefully remove the soundbar and all accessories from the packaging. Place the soundbar on a stable, flat surface, such as a TV stand or shelf, directly in front of your television. Ensure there is adequate ventilation around the unit.

Image: The JVC Soundbar displayed with its physical dimensions: approximately 80 cm in length, 8.9 cm in depth, and 6.5 cm in height. This provides a visual reference for placement.

2. Connecting to Power

1. Connect the power adapter cable to the DC IN port on the back of the soundbar.
2. Plug the other end of the power adapter into a wall outlet (AC 240V, 50/60Hz).
3. The soundbar will enter standby mode, indicated by a specific LED light.

3. Audio Connections

Choose one of the following methods to connect the soundbar to your audio source (e.g., TV, DVD player):

- **HDMI ARC (Recommended):**
  Connect an HDMI cable (not included) from the HDMI ARC port on your TV to the HDMI ARC port on the soundbar. Ensure your TV's HDMI ARC function is enabled in its settings.
- **Optical:**
  Connect an optical audio cable (not included) from the Optical OUT port on your TV to the Optical IN port on the soundbar. Select 'Optical' as the audio output on your TV.
- **AUX (3.5mm):**
  Connect a 3.5mm audio cable (not included) from the headphone jack or AUX OUT port on your device to the AUX IN port on the soundbar.



Image: The rear panel of the JVC Soundbar, displaying the available input ports including HDMI ARC, Optical, and AUX, for connecting to external audio sources.

Operating Instructions

1. Power On/Off

- Press the **Power** button on the remote control or on the soundbar to turn the unit on or off.

2. Mode Selection

- Press the **Mode** button on the remote control or the soundbar to cycle through available input modes: Bluetooth, HDMI ARC, Optical, AUX, and FM.
- The LED indicator on the soundbar will change to reflect the selected mode.

3. Bluetooth Pairing

1. Switch the soundbar to Bluetooth mode. The Bluetooth indicator will flash, indicating it's ready for pairing.
2. On your Bluetooth-enabled device (smartphone, tablet), enable Bluetooth and search for available devices.
3. Select "JVC Soundbar" (or similar name) from the list.
4. Once paired, the Bluetooth indicator will stop flashing and remain solid. You can now stream audio from your device.

4. USB Playback

1. Insert a USB flash drive (up to 32GB, formatted as FAT32) containing MP3, WAV, or WMA audio files into the USB port on the soundbar.
2. The soundbar will automatically switch to USB mode and begin playing the first compatible audio file.
3. Use the **Play/Pause**, **Next**, and **Previous** buttons on the remote control to manage playback.

5. FM Radio Operation

1. Switch the soundbar to FM mode.
2. Press and hold the **Play/Pause** button on the remote control to initiate an automatic station scan. The soundbar will scan and save available FM stations.
3. Use the **Next** and **Previous** buttons to navigate through the saved stations.

6. Volume Control

- Use the **Volume Up (+)** and **Volume Down (-)** buttons on the remote control or soundbar to adjust the volume.
- Press the **Mute** button on the remote control to mute or unmute the sound.

Image: A collage demonstrating the versatility of the JVC Soundbar across different entertainment scenarios, including movie watching, gaming, and music playback.

Maintenance and Care

- **Cleaning:**
  Always unplug the soundbar from the power outlet before cleaning. Use a soft, dry cloth to wipe the exterior surfaces. Do not use liquid cleaners, abrasive cleaners, or chemical sprays, as these may damage the finish or internal components.
- **Ventilation:**
  Ensure that the ventilation openings on the soundbar are not blocked. Proper airflow prevents overheating and prolongs the life of the device.
- **Storage:**
  If storing the soundbar for an extended period, unplug it from the power source and store it in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Handling:**
  Avoid dropping or subjecting the soundbar to strong impacts, as this can cause internal damage.

Troubleshooting

Problem	Possible Cause	Solution
No power	Power cable not connected; Power outlet not active.	Ensure the power cable is securely connected to the soundbar and a working power outlet. Try a different outlet.
No sound	Incorrect input mode; Volume too low; Muted; Incorrect TV audio settings.	Press the **Mode** button to select the correct input. Increase the volume on the soundbar and your connected device. Press the **Mute** button to unmute. Check your TV's audio output settings (e.g., set to External Speaker, PCM for Optical/HDMI ARC).
Bluetooth pairing fails	Soundbar not in pairing mode; Device too far; Interference.	Ensure the soundbar is in Bluetooth pairing mode (flashing indicator). Move your device closer to the soundbar. Turn off other Bluetooth devices nearby to reduce interference. Forget "JVC Soundbar" on your device and try pairing again.
Remote control not working	Batteries low/dead; Obstruction between remote and soundbar.	Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the soundbar's sensor.
Poor FM reception	Weak signal; Antenna not extended.	Adjust the position of the soundbar. Ensure the FM antenna (if external) is fully extended. Perform an auto-scan again.

Specifications

Model Name	TH-N322B
Speaker Type	Soundbar
Audio Channels	2.0 Channel
Speaker Output Power	30 Watts
Connectivity Technology	Bluetooth, HDMI ARC, Optical, AUX, USB, FM Radio
Bluetooth Version	Bluetooth 5.0
USB Support	Up to 32GB
Supported Audio Formats (USB)	MP3, WAV, WMA
Input Voltage	240 Volts
Product Dimensions (L x D x H)	80 cm x 8.9 cm x 6.5 cm
Colour	Black

Material	Plastic
Mounting Type	Tabletop Mount

Warranty Information

The JVC 2.0 Channel Bluetooth Soundbar comes with a **1 Year Manufacturer's Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.
The warranty does not cover:

- Damage caused by accident, abuse, misuse, flood, fire, earthquake, or other external causes.
- Damage caused by operating the product outside the permitted or intended uses described in this manual.
- Damage caused by service performed by anyone who is not an authorized service provider of JVC.
- Products or parts that have been modified to alter functionality or capability without the written permission of JVC.

Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, warranty claims, or general inquiries regarding your JVC 2.0 Channel Bluetooth Soundbar, please contact JVC customer support.
Please visit the official JVC website for the most up-to-date contact information and support resources:

www.jvc.com

When contacting support, please have your product model number (TH-N322B) and proof of purchase readily available.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question