

Manuals.plus /

› JVC /

› JVC 40-Inch LT-40N550 Edgeless Full HD Android Smart TV User Manual

JVC LT-40N550B

JVC 40-Inch LT-40N550 Edgeless Full HD Android Smart TV User Manual

Model: LT-40N550B

1. INTRODUCTION AND OVERVIEW

This manual provides comprehensive instructions for the setup, operation, and maintenance of your JVC 40-Inch LT-40N550 Edgeless Full HD Android Smart TV. Please read this manual thoroughly before using your television to ensure proper operation and to maximize your viewing experience. Keep this manual for future reference.




Image: Front view of the JVC 40-Inch LT-40N550 Edgeless Full HD Android Smart TV. This image displays the television's sleek design with minimal bezels and the integrated stand.

2. KEY FEATURES

- **Edgeless Full HD Display:** Experience vibrant visuals with a 1920x1080 resolution and 220cd/m2 brightness.
- **Android Smart TV Platform:** Access a wide range of applications, games, and streaming services directly from your TV.
- **Dolby Audio Technology:** Enjoy immersive sound quality for an enhanced audio-visual experience.
- **Quadcore Processor:** Ensures smooth performance and responsive navigation through menus and applications.
- **Built-in Wi-Fi:** Seamlessly connect to your home network for online content and updates.
- **Multiple Connectivity Options:** Equipped with 3 HDMI ports, 2 USB ports, and 1 AV input for connecting various external devices.
- **Integrated DVB T2/S2 Receiver:** Provides direct access to digital terrestrial and satellite channels without additional equipment.

3. PACKAGE CONTENTS

Please check the box for the following items. If any items are missing or damaged, contact your retailer.

- JVC 40-Inch LT-40N550 Smart TV

- Remote Control (with batteries)
- TV Stand (2 pieces)
- Screws for TV Stand
- Power Cable
- User Manual (this document)
- Quick Start Guide

Image: Packaging box of the JVC 40-Inch LT-40N550 Smart TV. The box displays key specifications and features of the television, indicating its Full HD and Smart TV capabilities.

4. SAFETY INFORMATION

To ensure safe operation and prevent damage, please observe the following safety precautions:

- Do not block ventilation openings.
- Do not place the TV near heat sources or in direct sunlight.
- Protect the power cord from being walked on or pinched.
- Do not expose the TV to rain or moisture.
- Refer all servicing to qualified service personnel.
- Ensure the TV is placed on a stable, level surface to prevent tipping.

5. SETUP

5.1 Unpacking

Carefully remove the TV and all accessories from the packaging. Retain the packaging materials for future transport or storage.

5.2 Attaching the TV Stand

1. Place the TV face down on a soft, clean surface to prevent screen damage.
2. Align the stand pieces with the corresponding slots on the bottom of the TV.
3. Secure the stand pieces using the provided screws. Ensure they are tightened firmly.

5.3 Connecting Power

Plug the power cable into the AC IN port on the back of the TV, then plug the other end into a wall outlet. The TV will enter standby mode.

5.4 Connecting External Devices

Your JVC Smart TV offers various ports for connecting external devices:

- **HDMI Ports (x3):** For high-definition audio and video devices like Blu-ray players, gaming consoles, or set-top boxes.
- **USB Ports (x2):** For connecting USB storage devices to play media files or for software updates.
- **AV Input (x1):** For older devices using composite video and stereo audio cables.
- **Antenna/Cable Input:** For connecting an antenna or cable TV signal.

Ensure the TV is turned off before connecting or disconnecting any devices.

5.5 Initial Setup (First-Time Use)

When you power on the TV for the first time, a setup wizard will guide you through the initial configuration:

1. **Language Selection:** Choose your preferred language.
2. **Network Connection:** Connect to your Wi-Fi network. Select your network from the list and enter the password.
3. **Google Account Sign-in:** Sign in with your Google account to access the full features of Android TV, including the Google Play Store.
4. **Channel Scan:** Perform an automatic channel scan for DVB T2/S2 or analog channels.
5. **Time Zone and Date:** Set your local time zone and date.

6. OPERATING THE TV

6.1 Remote Control Overview

Familiarize yourself with the buttons on the remote control. Key functions include:

- **Power Button:** Turns the TV on/off or to standby mode.
- **Navigation Buttons (Up/Down/Left/Right/OK):** For navigating menus and selecting options.
- **Volume Up/Down:** Adjusts the sound level.
- **Channel Up/Down:** Changes TV channels.
- **Home Button:** Returns to the Android TV home screen.
- **Input Button:** Selects the input source (HDMI, AV, TV).
- **Back Button:** Returns to the previous screen or menu.
- **App Buttons:** Dedicated buttons for popular streaming services (if available).

6.2 Basic Functions

- **Power On/Off:** Press the Power button on the remote or the TV.
- **Adjusting Volume:** Use the Volume Up/Down buttons.
- **Changing Channels:** Use the Channel Up/Down buttons or enter channel numbers directly.

6.3 Smart TV Features (Android TV)

Your JVC Smart TV runs on the Android TV operating system, providing access to a world of entertainment:

- **Home Screen:** Provides quick access to installed apps, recommended content, and settings.
- **Google Play Store:** Download and install a vast array of apps, games, and streaming services.
- **Google Assistant:** Use voice commands via the remote control (if supported) to search for content, control smart home devices, and get information.
- **Chromecast Built-in:** Cast content from your smartphone, tablet, or computer directly to the TV.

6.4 Input Selection

To switch between connected devices (e.g., Blu-ray player, game console), press the **Input** button on the remote control and select the desired source from the on-screen menu.

6.5 Picture and Sound Settings

Access the settings menu to customize your viewing and listening experience:

- **Picture Mode:** Choose from preset modes (Standard, Dynamic, Movie, Sport) or customize brightness, contrast, color, and sharpness.

- **Sound Mode:** Select from preset audio modes (Standard, Music, Movie, Speech) or adjust bass, treble, and balance.
- **Dolby Audio:** Enable or disable Dolby Audio processing for enhanced sound.

7. MAINTENANCE

- **Cleaning the Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, use a screen cleaner specifically designed for TVs, applied to the cloth, not directly to the screen.
- **Cleaning the Cabinet:** Use a soft, dry cloth to wipe the TV cabinet. Do not use abrasive cleaners or solvents.
- **Storage:** If storing the TV for an extended period, disconnect the power cable and cover the TV to protect it from dust. Store in a cool, dry place.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cable not connected; power outlet not working.	Ensure power cable is securely plugged in. Test the outlet with another device.
No picture, but sound is present	Incorrect input source selected; backlight issue.	Press the Input button on the remote to select the correct source. Contact service if issue persists.
No sound, but picture is present	Volume muted or too low; audio cables not connected properly.	Unmute the TV or increase volume. Check audio cable connections.
Remote control not working	Batteries are dead or inserted incorrectly; obstruction between remote and TV.	Replace batteries. Ensure clear line of sight to the TV's IR sensor.
Cannot connect to Wi-Fi	Incorrect password; router issue; TV too far from router.	Double-check Wi-Fi password. Restart router. Move TV closer to router or use a Wi-Fi extender.

9. SPECIFICATIONS

Feature	Detail
Brand	JVC
Model Number	LT-40N550B
Screen Size	40 Inches (102 cm visible diagonal)
Display Technology	LED
Resolution	1080p (1920x1080 Full HD)
Refresh Rate	60 Hz
Operating System	Android Smart TV
Processor	Quadcore
Audio Technology	Dolby Audio
Connectivity	Wi-Fi, 3 x HDMI, 2 x USB, 1 x AV Input
Special Features	Edgeless Design, Smart TV, Dolby Audio, Android
Product Dimensions (D x W x H)	62.6D x 89.9W x 51.2H centimeters
Item Weight	4.8 kg
Manufacturer	JVC
Date First Available	27 April 2024

10. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the warranty card included with your product or visit the official JVC support website. Keep your purchase receipt as proof of purchase for warranty claims.

For further assistance, you may contact JVC customer service through their official channels.