



[Manuals.plus](#) /

› [TRIUMPHKEY](#) /

› TRIUMPHKEY Height Adjustable Desk (Model 02567) - Instruction Manual

TRIUMPHKEY 02567

TRIUMPHKEY Height Adjustable Desk (Model 02567) - Instruction Manual

Your guide to assembly, operation, and maintenance.

1. INTRODUCTION

Thank you for choosing the TRIUMPHKEY Height Adjustable Desk. This electric standing desk is designed to enhance your workspace with its dual-motor lifting system, customizable height settings, and integrated charging capabilities. This manual provides essential information for safe assembly, operation, and maintenance of your new desk.



Image 1.1: The TRIUMPHKEY Height Adjustable Desk in a modern office environment.

2. SAFETY INFORMATION

- **Weight Limit:** Do not exceed the maximum weight capacity of 125 kg (275 lbs). Overloading can cause damage to the desk and potential injury.
- **Stability:** Ensure the desk is placed on a stable, level surface before use. Verify all fasteners are tightened securely.
- **Clearance:** Keep the area around the desk clear during height adjustments to prevent obstructions or pinching.
- **Power:** Use only the provided power adapter. Disconnect power before cleaning or maintenance.
- **Children and Pets:** Keep children and pets away from the desk during operation to prevent accidents.
- **Liquid Exposure:** Avoid spilling liquids on the control panel or electrical components.

3. WHAT'S IN THE BOX

Carefully unpack all components and verify that you have received the following items:

- Desk Frame (Legs and Crossbar)
- Control Panel
- Power Adapter
- Built-in USB Port
- Headphone Hook
- Cable Management Tray
- Desk Extension (if applicable)
- Assembly Tools
- Instruction Manual

3 Table Frame Colours for You to Choose

Robust and Stable



Image 3.1: All included components for easy installation.

4. ASSEMBLY INSTRUCTIONS

The TRIUMPHKEY Height Adjustable Desk is designed for quick and straightforward assembly, typically taking 10-

15 minutes. Follow these steps carefully:

1. **Unpack Components:** Lay out all parts on a clean, flat surface.
2. **Assemble the Frame:** Connect the desk legs to the crossbar. Ensure all connections are secure.
3. **Attach Feet/Castors:** Secure the feet or optional castors to the bottom of the desk legs.
4. **Mount the Desktop:** Carefully place your chosen desktop onto the assembled frame and secure it using the provided screws.
5. **Connect Electronics:** Connect the control panel, motors, and power adapter according to the wiring diagram.
6. **Install Accessories:** Attach the cable management tray and headphone hook as desired.



Image 4.1: Detail of the desk frame connection during assembly.



Height Adjustment 70-120 cm

Freely Customise Your Comfort Heights



Image 4.2: The desk frame assembly process, highlighting its speed.

Assembly Video

Your browser does not support the video tag.

Video 4.1: A step-by-step guide to assembling your TRIUMPHKEY Height Adjustable Desk frame.

5. OPERATING INSTRUCTIONS

Your TRIUMPHKEY desk features an intelligent control panel for easy height adjustment and personalized settings.

Height Adjustment

Use the up and down arrows on the control panel to smoothly adjust the desk height between 70 cm and 120 cm. The dual-motor system ensures quiet operation, typically below 50 dB.

Intelligent Control Panel



Image 5.1: Visual representation of the desk's height adjustment range.

Memory Functions

The control panel allows you to save up to 4 preferred height settings:

1. Adjust the desk to your desired height.
2. Press the 'M' button, then press one of the number buttons (1, 2, 3, or 4) to save the current height.
3. To recall a saved height, simply press the corresponding number button.

Integrated Charging Ports

The desk includes built-in USB and Type-C charging ports for convenient device charging.


Child Safety Lock

Activate the child safety lock feature on the control panel to prevent accidental adjustments.

Sedentary Reminder

Utilize the sedentary reminder function to prompt you to change positions, promoting a healthier work routine.

DUAL MOTORS



Rotation Speed
4300r/min

Low Noise
≤ 50dB

Load-Bearing
120KG

Image 5.2: The intelligent control panel with its various functions.

5-10 MINUTES

You can assemble the entire table in 5-10 minutes



Image 5.3: The powerful dual-motor system ensuring smooth and quiet operation.

6. MAINTENANCE

- **Cleaning:** Wipe the desk surface and frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals.
- **Cable Management:** Regularly check and organize cables in the cable management tray to prevent tangles and damage.
- **Fasteners:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary.
- **Motor Care:** The dual motors are maintenance-free. Avoid disassembling the motor units.



Image 6.1: The integrated cable management tray helps keep your workspace tidy.

7. TROUBLESHOOTING

If you encounter any issues with your TRIUMPHKEY Height Adjustable Desk, please refer to the following common solutions:

- **Desk Not Moving:**
 - Check if the power cable is securely connected to both the desk and the power outlet.
 - Ensure the child safety lock is not activated.
 - Reset the desk by unplugging it for 30 seconds, then plugging it back in.
- **Uneven Movement:**
 - Verify that the desk is not overloaded and weight is evenly distributed.
 - Check for any obstructions under or around the desk legs.
- **Error Codes on Display:**
 - Refer to the specific error code in the full manual (if provided) or contact customer support.
 - Often, unplugging and replugging the desk can resolve temporary errors.

If the problem persists, please contact TRIUMPHKEY customer support for assistance.

8. SPECIFICATIONS

| Feature | Specification |
|-------------------------|---|
| Brand | TRIUMPHKEY |
| Model Number | 02567 |
| Product Dimensions | 1T x 2B x 1.2H m (Approx. 100 x 200 x 120 cm) |
| Height Adjustment Range | 70 cm - 120 cm |
| Maximum Weight Capacity | 125 kg |
| Motor Type | Dual Motor |
| Noise Level | Less than 50 dB |
| Memory Presets | 4 |
| Charging Ports | USB, Type-C |

| | |
|-------------------|---------------------|
| Material | Alloy Steel (Frame) |
| Assembly Required | Yes |



Image 8.1: Desk frame dimensions and compatible tabletop sizes.

9. WARRANTY & SUPPORT

Warranty Information

Your TRIUMPHKEY Height Adjustable Desk comes with a comprehensive warranty. Please retain your proof of purchase for any warranty claims. For detailed terms and conditions, refer to the warranty card included in your packaging or visit the official TRIUMPHKEY website.

Customer Support

For technical assistance, troubleshooting, or any questions regarding your product, please contact TRIUMPHKEY customer support:

- **Website:** [Visit the TRIUMPHKEY Store on Amazon](#)
- **Email:** (Please refer to your product packaging or official website for contact email)
- **Phone:** (Please refer to your product packaging or official website for contact number)